

2019 Audi Maintenance Schedule - All Models

MY 2019 Audi e-tron Maintenance Intervals - USA

Service intervals in miles												
	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K	110K	120K
Minor Maintenance (Every-1 year) ¹	Х		х		х		Х		х		х	
Standard Maintenance (Every 2 years) ²		Х		х		х		Х		х		х
Additional Maintenance Items	Refer to the Additional Maintenance Items Table below											

¹⁾ First minor maintenance service at 10,000 miles or 1 year after delivery, whichever occurs first. Minor maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last minor maintenance service, whichever occurs first.

NOTE: The intervals shown in this table are based on vehicles operating under normal conditions. In case of severe conditions, such as extremely low temperatures, excessive dust, etc., it is necessary for certain operations to be carried out in between the given intervals. This applies particularly to engine oil changes and the cleaning or replacing of the air cleaner filter element.

Check all completed items

plate lights, and hazard warning lights

sive play

☐ First aid kit - Check and enter expiration date YYYY / MM _____ (if applicable)

•	
Mi	nor Maintenance
	Brake system - Check the thickness of the brake pads Connected box battery - Check state of health with Vehicle Diagnostic Tester in Guided Functions First aid kit - Check and enter expiration date YYYY / MM (if applicable) Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for excessive play
	Instrument cluster - Check warning and indicator lights
	Service reminder indicator display - Reset display
	Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped) Tires - Check condition and tire tread wear; Check and record the tread depth
	Tires - Check tire inflation pressure and adjust if necessary
	Tire repair kit - Check and record the completeness and expiration date (if equipped) Wiper blades - Check condition and replace if necessary
Sta	andard Maintenance (Includes All Minor Maintenance Items)
	Body/chassis - Visually inspect for possible paint damage and corrosion, from the inside and outside, with the doors as well as hood and trunk lids open Brake system - Check the thickness of the brake pads
	Brake system - Check for damage and leaks, condition of brake lines and the presence of the bleeder caps
_	Charging socket - Check for contamination and damage
	Cooling system for electrical components - Check coolant level and add if necessary according to procedure in ElsaPro
	Door hinges (including door stay) - Lubricate
	Exterior lighting - Check front and rear lights, turn signals, cornering lights, reverse lights, brake lights, license

☐ Front and rear axle/suspension components - Check dust seals on ball joints and tie rod ends; check for exces-

1

8/20/2018

²⁾ First standard maintenance service at 20,000 miles or 2 years after delivery, whichever occurs first. Standard maintenance services thereafter occur at intervals of 20,000 miles or every 2 years after the last standard maintenance service, whichever occurs first.



Standard Maintenance (continued)

ш	Front axle drive - drain coolant (with small cover removed)
	Headlights - Check adjustment
	High voltage cooling system - Check for damage and leaks
	High voltage safety instruction labels - Check safety instruction labels for legibility
	High voltage system components - Check for damage and leaks; check cables and insulation for damage and
	proper mounting
	Horn - Check function
	Instrument cluster - Check warning and indicator lights
	Interior lights - Check all interior lights, trunk lights, and glove box compartment illumination
	Motor compartment - Check transmission, final drive, and steering for leaks
	Panoramic sunroof system - Check function and drainage system by fluid check according to Elsa (if equipped)
	Plenum chamber and water drain valves: Check for dirt, and clean if necessary
	NOTE: Time spent cleaning of item is a separate charge for service time
	Road test - Perform
	Rear axle drive - Remove coolant cartridge and empty (with cover removed)
	Safety belts - Check function
	Service reminder indicator display - Reset display
	Space saver spare wheel and tire - Check condition and tire inflation pressure, adjust if necessary (if equipped)
	Tires - Check condition and tire tread wear. Check and record the tread depth
	Tires - Check tire inflation pressure and adjust if necessary
	Tire repair kit - Check and record the completeness and expiration date (if equipped)
	Underbody - Check for damage and leaks, check the wheel well liners, underbody paneling and all lines are
	properly mounted
	Warning triangle - Check if present (if equipped)
	Windshield washer and headlight washing system - Add fluid if necessary. Check adjustment and function
	Wiper blades - Check condition and replace if necessary

Additional Maintenance Items					
Work to be completed	Interval				
☐ Brake fluid - Change	Every 2 years regardless of mileage				
☐ Dust and Pollen filter - Replace	Every 20,000 miles or 2 years, whichever occurs first				
☐ Fragrance Cartridges - Change (if equipped)	Every 2 years regardless of mileage				

2

8/20/2018