METHOD STATEMENT

# Bondmix WB — Water-Based Two-Component Epoxy Primer & Bonding Coat

| | | | |
|---|---|---|---|
| **Project Name** | | **Document No.** | OMX-MS-BONDMIXWB |
| **Main Contractor** | | **Revision** | 01 |
| **Consultant** | | **Date of Issue** | Nov 2026 |
| **Product** | Bondmix WB | **Status** | For Approval |

## 1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Bondmix WB on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

## 2. Scope of Work

This method statement covers surface preparation, mixing and application of Bondmix WB water-based epoxy primer on concrete and cementitious substrates before court systems, micro-cement and waterproofing coatings.

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Priming of the prepared surface.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

## 3. Definitions

| Term | Meaning |
|---|---|
| **Pot life** | Time the mixed material remains workable after Part A and Part B are combined. |
| **Recoat interval** | Minimum and maximum time between coats to achieve inter-coat adhesion. |
| **WFT / DFT** | Wet film thickness measured during application / dry film thickness after cure. |
| **Dew point** | Temperature at which moisture condenses; the substrate must be at least 3 °C above it. |
| **Kit / set** | Pre-weighed Part A and Part B supplied to be mixed completely. |

## 4. Roles & Responsibilities

| Role | Responsibility |
|---|---|
| **Project Manager** | Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor. |

| Role | Responsibility |
|---|---|
| **Site Engineer** | Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records. |
| **QA/QC Inspector** | Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist. |
| **HSE Officer** | Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise. |
| **Foreman / Applicators** | Carry out the work as per this method statement and report any deviation immediately. |
| **Storekeeper** | Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers. |

## 5. Materials

| Material | Description |
|---|---|
| **Bondmix WB** | Water-based epoxy primer, 10 kg and 20 kg sets (A + B) |

### 5.1 Key product data

| Property | Typical Value |
|---|---|
| **Mixing ratio (A : B)** | 1 : 4 by weight — pre-weighed sets, mix as recommended |
| **Appearance** | Milky; dries clear |
| **Density** | 1.05 – 1.15 kg/L |
| **Solids content** | 30 – 55 % |
| **Viscosity** | 500 – 1500 mPa·s |
| **Pot life** | 1 – 2 hours |
| **Touch dry** | 1 – 2 hours |
| **Recoat interval** | 4 – 6 hours |

## 6. Tools & Equipment

- Grinder / shot blaster
- Industrial vacuum
- Slow-speed mixer
- Rollers
- Brushes
- Moisture meter
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Wet-film thickness gauge
- Measuring buckets and scale
- Masking tape and protective sheeting

- Lighting and extension cables

### 6.1 Personal protective equipment

- Gloves
- Goggles
- Overalls

## 7. Storage & Handling

- 12 months in original, unopened packaging. Store dry at +5 °C to +35 °C, away from direct sunlight. Protect from frost.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Keep Part A and Part B of each kit together and do not mix parts from different batches.
- Store away from heat, sparks and ignition sources.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

## 8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

## 9. Surface Preparation

1. Check concrete age (≥ 28 days) and soundness.
2. Grind or shot blast to remove laitance, oil and loose material.
3. Vacuum all dust; damp surface acceptable, no standing water.
4. Measure substrate temperature, air temperature and relative humidity; confirm the substrate is at least 3 °C above dew point.
5. Protect adjacent surfaces, drains and fixtures with masking tape and sheeting.
6. Obtain QA/QC approval of the prepared surface before starting the next step.

## 10. Mixing

1. Condition materials to between +15 °C and +25 °C before mixing.
2. Check the batch numbers and expiry dates of both parts and record them.
3. Pour the complete Part A into Part B (1 : 4 by weight).
4. Mix 2 – 3 minutes with a slow-speed mixer until uniform.

5. Mix complete sets only.
6. Mix only the quantity that can be applied within the pot life.

## 11. Application

1. Apply by roller or brush at 0.15 – 0.30 kg/m² without puddles.
2. Apply a second coat on very porous substrates.
3. Apply the next system layer after 4 – 6 hours and within 24 hours.
4. Work in manageable bays, keeping a wet edge to avoid lap marks.
5. Check consumption by area and wet film thickness regularly during application and record the results.

## 12. Curing & Protection

- Pot life 1 – 2 hours.
- Touch dry 1 – 2 hours; full cure 24 hours.
- Protect from rain and dust until overcoated.
- Protect the applied area from water, dust, other trades and traffic until the stated cure times are reached.
- Barricade the area and display warning signs.

## 13. Quality Control & Inspection

| Check | Stage | Acceptance Criteria | By |
|---|---|---|---|
| **Substrate** | Before priming | Sound, clean, ≥ 28 days | QA/QC |
| **Climate** | During work | +10 °C to +35 °C, RH ≤ 85 % | Site Engineer |
| **Mixing** | Each set | 1 : 4 by weight, complete set | Site Engineer |
| **Consumption** | During application | 0.15 – 0.30 kg/m² | QA/QC |
| **Primed surface** | Before next layer | Uniform, no puddles | QA/QC |

### 13.1 Inspection and test plan

| Activity | Inspection / Test | Frequency | Record |
|---|---|---|---|
| **Material receipt** | Product, batch, expiry, packaging condition | Each delivery | Material inspection report |
| **Climate** | Air / substrate temperature, RH, dew point | Start of shift and every 4 hours | Daily climate log |
| **Surface preparation** | Visual, moisture, soundness | Each area | Inspection request (hold point) |
| **Application** | Consumption, thickness, appearance | Each coat / area | Daily progress report |
| **Final inspection** | Visual, continuity, finish | Each completed area | Handover checklist |

## 14. Defects & Remedies

| Defect | Likely Cause | Remedy |
|---|---|---|
| **Pinholes / bubbles** | Outgassing from porous substrate; air entrapped in mixing | Seal with primer; mix at low speed; de-aerate with spiked roller; sand and recoat |
| **Blushing / tacky surface** | High humidity or low temperature during cure | Wash and abrade; recoat in suitable conditions |
| **Poor adhesion** | Contaminated, weak or damp substrate; recoat window exceeded | Remove, re-prepare surface and reapply |
| **Soft spots** | Incorrect mixing or ratio | Remove affected area and reapply with full kits |
| **Uneven colour / lap marks** | Loss of wet edge; different batches | Abrade and apply a further coat from one batch |

## 15. Health, Safety & Environment

| Hazard | Control Measures |
|---|---|
| **Skin and eye contact** | Gloves, goggles, overalls; eye-wash available |
| **Inhalation of vapours / dust** | Ventilation; masks as required |
| **Slips and trips** | Housekeeping; barricades and signs |
| **Manual handling** | Correct lifting technique; mechanical aids |
| **Electrical tools** | Inspected tools; protected cables |

- Wear gloves and safety goggles.
- Uncured epoxy may cause skin sensitisation; avoid skin and eye contact.
- Ensure ventilation in enclosed areas.
- Eyes: rinse immediately with plenty of clean water for at least 15 minutes and seek medical advice.
- Skin: remove contaminated clothing and wash with soap and water; do not use solvents on skin.

### 15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

## 16. Cleaning

- Clean tools with water immediately after use.

## 17. Limitations

- Ambient and substrate temperature: +10 °C to +35 °C.
- Relative humidity: max. 85 %.
- Do not apply in rain or when rain is expected before the material has set.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

## Appendix A — Inspection Checklist

| Inspection Item | Result | Remarks |
|---|---|---|
| **Substrate verified** | ☐ Yes ☐ No | |
| **Surface prepared and dust-free** | ☐ Yes ☐ No | |
| **Complete sets mixed** | ☐ Yes ☐ No | |
| **Primer applied uniformly** | ☐ Yes ☐ No | |
| **Second coat on porous areas** | ☐ Yes ☐ No | |
| **Overcoated within 24 h** | ☐ Yes ☐ No | |

| Inspected by | Signature | Date |
|---|---|---|
| | | |