METHOD STATEMENT

Decora PU — Clear Matt Polyurethane Top Coat for Decorative Concrete

Project Name		**Document No.**	OMX-MS-DECORAPU
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	Decora PU	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of Decora PU on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers surface preparation, mixing and application of Decora PU clear matt polyurethane top coat on decorative concrete, polished concrete and micro-cement surfaces.

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Priming of the prepared surface.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

3. Definitions

Term	Meaning
Pot life	Time the mixed material remains workable after Part A and Part B are combined.
Recoat interval	Minimum and maximum time between coats to achieve inter-coat adhesion.
WFT / DFT	Wet film thickness measured during application / dry film thickness after cure.
Dew point	Temperature at which moisture condenses; the substrate must be at least 3 °C above it.
Kit / set	Pre-weighed Part A and Part B supplied to be mixed completely.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.

Role	Responsibility
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
Decora PU	Clear matt PU top coat, 5 L and 20 L sets (A + B)
PU thinner	For thinning and cleaning

5.1 Key product data

Property	Typical Value
Mixing ratio (A : B)	5 : 1 by weight
Finish	Clear matt
Solids content	35 %
Recommended DFT	25 – 75 µm
Theoretical coverage	approx. 7 m²/L at 50 µm
Surface dry	30 minutes
Recoat interval	4 hours to 10 days
Pot life	2 hours

6. Tools & Equipment

- Slow-speed mixer
- Short-nap rollers
- Brushes
- Spray equipment
- Sanding pads
- Vacuum
- Wet-film comb
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Wet-film thickness gauge

- Measuring buckets and scale
- Masking tape and protective sheeting
- Lighting and extension cables

6.1 Personal protective equipment

- Chemical-resistant gloves
- Goggles
- Respirator with organic vapour cartridges
- Overalls

7. Storage & Handling

- 12 months in original, unopened packaging. Store dry at +5 °C to +35 °C, away from heat, sparks and direct sunlight.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Keep Part A and Part B of each kit together and do not mix parts from different batches.
- Store away from heat, sparks and ignition sources.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Confirm the substrate is fully cured and dry.
2. Lightly sand micro-cement or polished surfaces where required and remove all dust.
3. Remove grease and contaminants.
4. Prepare a sample area for approval.
5. Measure substrate temperature, air temperature and relative humidity; confirm the substrate is at least 3 °C above dew point.
6. Protect adjacent surfaces, drains and fixtures with masking tape and sheeting.
7. Obtain QA/QC approval of the prepared surface before starting the next step.

10. Mixing

1. Condition materials to between +15 °C and +25 °C before mixing.
2. Check the batch numbers and expiry dates of both parts and record them.
3. Stir Part A.
4. Add Part B to Part A at 5 : 1 by weight.
5. Mix 2 – 3 minutes with a slow-speed mixer.
6. Thin up to 20 % only where required.
7. Mix only the quantity that can be applied within the pot life.

11. Application

1. Apply the first coat by roller or spray in a thin, even layer.
2. Avoid puddles and lap marks; keep a wet edge.
3. Apply the second coat after 12 – 24 hours (minimum 4 hours, maximum 10 days).
4. Apply further coats as specified.
5. Work in manageable bays, keeping a wet edge to avoid lap marks.
6. Check consumption by area and wet film thickness regularly during application and record the results.

12. Curing & Protection

- Surface dry in 30 minutes; recoat after 4 hours.
- Protect from water, dust and traffic during curing.
- Protect the applied area from water, dust, other trades and traffic until the stated cure times are reached.
- Barricade the area and display warning signs.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Substrate	Before coating	Cured, dry, clean	QA/QC
Climate	During work	≥ +8 °C, RH ≤ 85 %, 3 °C above dew point	Site Engineer
Mixing	Each set	5 : 1 by weight	Site Engineer
Film	Each coat	Uniform, 25 – 75 µm DFT	QA/QC
Appearance	Final	Clear matt, no defects	QA/QC + Consultant

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry, packaging condition	Each delivery	Material inspection report

Activity	Inspection / Test	Frequency	Record
Climate	Air / substrate temperature, RH, dew point	Start of shift and every 4 hours	Daily climate log
Surface preparation	Visual, moisture, soundness	Each area	Inspection request (hold point)
Application	Consumption, thickness, appearance	Each coat / area	Daily progress report
Final inspection	Visual, continuity, finish	Each completed area	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Whitening / cloudiness	Moisture in substrate; high humidity	Allow to dry; reapply in suitable conditions
Lap marks	Loss of wet edge	Lightly sand and apply another thin coat
Bubbles	Thick application; porous substrate	Thin first coat; apply thin coats
Poor adhesion	Dust or contamination	Sand, clean and recoat

15. Health, Safety & Environment

Hazard	Control Measures
Skin and eye contact	Gloves, goggles, overalls; eye-wash available
Inhalation of vapours / dust	Ventilation; masks as required
Slips and trips	Housekeeping; barricades and signs
Manual handling	Correct lifting technique; mechanical aids
Electrical tools	Inspected tools; protected cables

- Solvent-based: flammable. Keep away from heat, sparks and open flames; no smoking.
- Wear chemical-resistant gloves, safety goggles and a respirator with organic vapour cartridges in enclosed spaces.
- Contains isocyanates; may cause sensitisation.
- Ensure good ventilation during application and drying.
- Eyes: rinse immediately with plenty of clean water for at least 15 minutes and seek medical advice.
- Skin: remove contaminated clothing and wash with soap and water; do not use solvents on skin.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Clean tools immediately with PU thinner.

17. Limitations

- Minimum substrate and air temperature: +8 °C.
- Substrate dry and at least 3 °C above dew point.
- Do not apply in rain or when rain is expected before the material has set.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Substrate cured and dry	☐ Yes ☐ No	
Surface sanded and dust-free	☐ Yes ☐ No	
Sample approved	☐ Yes ☐ No	
Mixed at 5 : 1	☐ Yes ☐ No	
Thinning within limit	☐ Yes ☐ No	
First coat uniform	☐ Yes ☐ No	
Recoat interval respected	☐ Yes ☐ No	
Final finish approved	☐ Yes ☐ No	

Inspected by	Signature	Date