METHOD STATEMENT

O-Mix SL — Three-Component Self-Levelling Epoxy Floor, 1 – 2 mm

Project Name		**Document No.**	OMX-MS-OMIXSL
Main Contractor		**Revision**	01
Consultant		**Date of Issue**	Nov 2026
Product	O-Mix SL	**Status**	For Approval

1. Purpose

This method statement defines the procedure, sequence, resources, quality checks and safety measures for the supply and application of O-Mix SL on site. It ensures that the work is carried out safely, in line with the approved drawings and project specification, and achieves the performance stated in the O MIX Technical Data Sheet.

2. Scope of Work

This method statement covers surface preparation, priming, filling, mixing and application of O-Mix SL three-component self-levelling epoxy floor at 1 – 2 mm.

- Inspection and acceptance of the substrate and the work area.
- Surface preparation and repair of defects.
- Priming of the prepared surface.
- Mixing and application of the material as described in this document.
- Curing, protection and handover of the completed area.
- Quality control, inspection and documentation of each stage.

3. Definitions

Term	Meaning
Pot life	Time the mixed material remains workable after Part A and Part B are combined.
Recoat interval	Minimum and maximum time between coats to achieve inter-coat adhesion.
WFT / DFT	Wet film thickness measured during application / dry film thickness after cure.
Dew point	Temperature at which moisture condenses; the substrate must be at least 3 °C above it.
Kit / set	Pre-weighed Part A and Part B supplied to be mixed completely.

4. Roles & Responsibilities

Role	Responsibility
Project Manager	Overall responsibility for planning, resources, approvals and coordination with the consultant and main contractor.

Role	Responsibility
Site Engineer	Supervises the work daily; confirms substrate readiness, climate conditions, mixing, consumption and sequence; keeps daily records.
QA/QC Inspector	Carries out inspections and tests at each stage, records results, raises inspection requests at hold points and signs the checklist.
HSE Officer	Conducts toolbox talks, checks PPE, ventilation, access and safe storage; stops work if unsafe conditions arise.
Foreman / Applicators	Carry out the work as per this method statement and report any deviation immediately.
Storekeeper	Receives, stores and issues materials in original packaging under the stated storage conditions; controls batch numbers.

5. Materials

Material	Description
O-Mix SL	40 kg units (A + B + C)
O-Prime SF	Primer
O-Putty	Filling layer

5.1 Key product data

Property	Typical Value
Components	Part A + Part B + Part C (filler)
Mixing ratio	A : B ≈ 2 : 1 by volume + Part C — complete units, as recommended
Solids content	100 %
Density	1.95 kg/L
Viscosity	3000 – 4000 mPa·s
Pot life	30 min
Number of coats	1
Foot traffic	24 hours

6. Tools & Equipment

- Grinder / shot blaster
- Industrial vacuum
- Slow-speed mixer (300 – 500 rpm)
- Notched trowel / gauge rake
- Spiked roller
- Spiked shoes
- Thermo-hygrometer and surface thermometer (dew point check)
- Moisture meter
- Wet-film thickness gauge

- Measuring buckets and scale
- Masking tape and protective sheeting
- Lighting and extension cables

6.1 Personal protective equipment

- Gloves
- Goggles
- Overalls
- Spiked shoes

7. Storage & Handling

- 24 months in original, unopened packaging. Store dry at +5 °C to +35 °C.
- Store on pallets, off the ground, in a dry, covered and ventilated area.
- Keep containers closed until use; use materials on a first-in, first-out basis.
- Keep Part A and Part B of each kit together and do not mix parts from different batches.
- Store away from heat, sparks and ignition sources.
- Handle with care to avoid damage to packaging; do not stack beyond the safe height.

8. Pre-Start Requirements

- Material submittal, this method statement and the inspection plan approved by the consultant.
- Work area handed over clean, free of other trades and with safe access.
- Adequate lighting, power supply and ventilation available.
- Climate conditions checked and recorded before work starts.
- A trial area prepared and approved where required by the project.
- Toolbox talk held with the work team covering this method statement and the safety measures.

9. Surface Preparation

1. Check concrete strength, pull-off and moisture.
2. Grind or shot blast; vacuum all dust.
3. Prime with O-Prime SF and leave 24 hours.
4. Fill defects with O-Putty and sand lightly.
5. Measure substrate temperature, air temperature and relative humidity; confirm the substrate is at least 3 °C above dew point.
6. Protect adjacent surfaces, drains and fixtures with masking tape and sheeting.
7. Obtain QA/QC approval of the prepared surface before starting the next step.

10. Mixing

1. Condition materials to between +15 °C and +25 °C before mixing.
2. Check the batch numbers and expiry dates of both parts and record them.
3. Mix Part A and Part B for 1 minute at 300 – 500 rpm.
4. Add Part C gradually and mix for 1 more minute until uniform.
5. Mix complete units only.
6. Mix only the quantity that can be applied within the pot life.

11. Application

1. Pour the mix in strips on the primed floor.
2. Spread with a notched trowel or gauge rake to 1 – 2 mm.
3. De-aerate with a spiked roller within 10 – 15 minutes.
4. Broadcast aggregate into the wet layer where an anti-slip finish is specified.
5. Work in manageable bays, keeping a wet edge to avoid lap marks.
6. Check consumption by area and wet film thickness regularly during application and record the results.

12. Curing & Protection

- Pot life 30 minutes.
- Foot traffic after 24 hours; full cure 7 days.
- Protect from water, dust and traffic during curing.
- Protect the applied area from water, dust, other trades and traffic until the stated cure times are reached.
- Barricade the area and display warning signs.

13. Quality Control & Inspection

Check	Stage	Acceptance Criteria	By
Substrate	Before priming	≥ 25 N/mm², pull-off ≥ 1.5, moisture < 4 %	QA/QC
Primer	Before SL layer	Applied, 24 h cured	QA/QC
Thickness	During application	1 – 2 mm (2 – 4 kg/m²)	QA/QC
Finish	After curing	Glossy, level, no bubbles	QA/QC + Consultant

13.1 Inspection and test plan

Activity	Inspection / Test	Frequency	Record
Material receipt	Product, batch, expiry, packaging condition	Each delivery	Material inspection report
Climate	Air / substrate temperature, RH, dew point	Start of shift and every 4 hours	Daily climate log

Activity	Inspection / Test	Frequency	Record
Surface preparation	Visual, moisture, soundness	Each area	Inspection request (hold point)
Application	Consumption, thickness, appearance	Each coat / area	Daily progress report
Final inspection	Visual, continuity, finish	Each completed area	Handover checklist

14. Defects & Remedies

Defect	Likely Cause	Remedy
Pinholes / bubbles	Outgassing from porous substrate; air entrapped in mixing	Seal with primer; mix at low speed; de-aerate with spiked roller; sand and recoat
Blushing / tacky surface	High humidity or low temperature during cure	Wash and abrade; recoat in suitable conditions
Poor adhesion	Contaminated, weak or damp substrate; recoat window exceeded	Remove, re-prepare surface and reapply
Soft spots	Incorrect mixing or ratio	Remove affected area and reapply with full kits
Uneven colour / lap marks	Loss of wet edge; different batches	Abrade and apply a further coat from one batch

15. Health, Safety & Environment

Hazard	Control Measures
Skin and eye contact	Gloves, goggles, overalls; eye-wash available
Inhalation of vapours / dust	Ventilation; masks as required
Slips and trips	Housekeeping; barricades and signs
Manual handling	Correct lifting technique; mechanical aids
Electrical tools	Inspected tools; protected cables

- Wear chemical-resistant gloves, safety goggles and overalls.
- Uncured epoxy may cause skin sensitisation; avoid skin and eye contact.
- Ensure good ventilation in enclosed areas.
- Eyes: rinse immediately with plenty of clean water for at least 15 minutes and seek medical advice.
- Skin: remove contaminated clothing and wash with soap and water; do not use solvents on skin.

15.1 Waste & environment

- Collect empty containers and residues in designated bins.
- Do not discharge material or washings into drains or soil.
- Allow small quantities of leftover mixed material to cure before disposal; dispose of according to local regulations.

16. Cleaning

- Clean tools with epoxy thinner before the material cures.

17. Limitations

- Ambient and substrate temperature: +10 °C to +35 °C.
- Substrate at least 3 °C above dew point.
- Do not apply in rain or when rain is expected before the material has set.
- Any deviation from this method statement must be approved by the Site Engineer and the consultant.

Appendix A — Inspection Checklist

Inspection Item	Result	Remarks
Substrate verified	☐ Yes ☐ No	
Surface prepared	☐ Yes ☐ No	
Primer cured 24 h	☐ Yes ☐ No	
Defects filled	☐ Yes ☐ No	
Complete units mixed	☐ Yes ☐ No	
Thickness controlled	☐ Yes ☐ No	
De-aerated	☐ Yes ☐ No	
Final finish approved	☐ Yes ☐ No	

Inspected by	Signature	Date