

SURVITEC ZODIAC LIFERAFT TEST AND SURVEY REPORT n° PAGE No 1/3

Date: __/__/__ **Station N°:** _____ **REINSPECTION CERTIFICATE N°:** _____

Type of liferaft		Ship name	
Capacity		Owner	
Serial n°		Flag state	
Pack		IMO N°	
Date of Manufacture		Last service	
Painter Line length		By station n°	
Stowage height		Last certificate n°	

Information if MES SIS raft (mini slide)	Left	Right
Position of container on board	Port side	Starboard
Firing Line Length (if EBL)		
Mooring springs position for SIS slide connection	1 2 3	4 5 6

1. BLAST TEST on inflation hoses

2. OVERPRESSURE VALVES *

Start:	TUBES						ARCHES					
End:	UP / F1	LOW / F2	F3	F4	F5	F6	A1	A2	A3	A4	A5	A6
Opening												
Reset												

* Opening/reset pressures of the over pressure valves according to the color of the dot on the valve. Refer to Manual MS003, page 4 in PART I - Controls, Solas Tests

LIFERAFT FITTED WITH VENTURI: VENTURI PROTECTIVE TUBE		
Overpressure valves test	UPPER	LOWER
Opening (max 296)		
Reset (mini 206)		

3. WORKING PRESSURE TEST (WP test) Tolerance 5% of start pressure

		Time	Temperature	Atmospheric pressure
Start			T1:	P1:
End			T2:	P2:
Difference				
Correction				

	TUBES						ARCHES					
	UP / F1	LOW / F2	F3	F4	F5	F6	A1	A2	A3	A4	A5	A6
Start												
End												
Result (after correction)												
Valid test YES/NO												

LIFERAFT FITTED WITH VENTURI: VENTURI PROTECTIVE TUBE			
Pressure Test	Time	UP (~235 mbar)	LOW (~235 mbar)
Start			
End (test on 10 mn)			
Final Result (OK if loss < 130 mbar)			

SURVITEC ZODIAC LIFERAFT TEST AND SURVEY REPORT n° PAGE No 2/3

4. CYLINDERS						
Cylinder N°						
CO2 Weight						
N2 Weight						
Full Weight						
Weight reading						
Last Hydro test						
Cylinder refilling date						
Firing head Type & n°						

5. TESTS CARRIED OUT	Yes	No
NAP TEST		
GI test		
Floor seam test		
Over load test (DL)		
Cylinder hydro test		
Hoses replaced		

6. LIFERAFT INSPECTION								
Main buoyancies	Check	R*	Canopy	Check	R*	Inner floor	Check	R*
Buoyancy			Canopy			Automatic bailer		
Reflective tape			Reflective tape			Vacuum breaker		
Outer lifeline			Rainwater collector			Insulating foam/rem. floor		
Inner lifeline			Entrances			Outer floor	Check	R*
Painter patch			External flashing light			Reflective tape		
Towing patch			Arches			Water pockets		
Bowsing lines			Shackle / Ring (DL)			CO ² cyl. pocket/Velcro straps		
Ramp / Ladder			Webbings (DL)			Righting straps		
Overpressure valves								
Overpressure valves caps			Container / Valise	Check	R*	Inflation system	Check	R*
Labels			Upper shell			CO ² valves		
Floating knife			Lower shell			Hoses		
Sea Anchor			Foam / plastic sheet			Inflation valves		
Quoit + Line			Painter line					
Painter line retrieving line			Labels			If raft fitted with Venturi	Check	R*
Signal card			Identification tube			Venturi		
Immediate actions card			Shackle access cover (DL)			Venturi caps		
Lighting system						Venturi flap cover		

R* = replacement

7. IF MES LIFERAFT: CONNECTION LINES						
MES SIS LIFERAFT (Mini slide)						
Extremity Bowsing Line (EBL)	Check	R*	Central Bowsing Line (CBL)	Check	R*	
EBL system good condition (Bowsing lines + Shock absorbers)			CBL system good condition (Shock absorber + Safety line)			
Bowsing lines attached with 35kg zip ties			4 rings (per side) connected			
2 B. lines with connected shock absorber (one per side)			Shackles secured			
Slings connected to the EBL system			Bowsing line + Painter connected to the CBL system			
MES MIS LIFERAFT (Super slide)						
PRIMARY	Check	R*	SECONDARY / ADDITIONNAL	Check	R*	
Blue Tether line attached with 9 kg (x2) zip ties			Extremity connection lines fixed with 9 kg (x2) zip ties			
Bowsing lines V connected with shackle + secured			Short connection lines OR shackles connected (in vacuum pouch)			
Slings connected to the Bowsing V			Pre-connection lines connected (out of vacuum pouch)			

SURVITEC ZODIAC LIFERAFT TEST AND SURVEY REPORT n° **PAGE No 3/3**

8. ACCESSORIES INSPECTION

Equipment	Check	R*	Expiry date	Other equipment	Check	R*
In the pack:				Leak stopper		
Hand flares				Foot pump		
Rocket parachute				Bailer		
Smoke signal				Sponge		
Food				Tin opener		
Water				Fishing kit		
First aid kit				Torch		
Seasickness tablets				Spare bulb		
Batteries 1,5V				Signal mirror		
Glue in repair kit				Whistle		
EPIRB				Drinking vessel		
				Seasickness bags		
				Sea anchor		
Outside of the pack:				Paddles		
Radar transponder				Rainwater collector		
HRU				Servicing history		
Lighting system (battery + flashing light)				T.P.A.		
				Radar reflector		

R* = replacement

9. LIFERAFT AND EQUIPMENT CONDITION INFORMATION

	Yes	No		Yes	No
Was the raft wet?			Was the liferaft damaged?		
Was the container damaged?			Had the liferaft been fired		
<u>Nature and extent of the damages:</u>					
<u>Nature and extent of the defects:</u>					
<u>Repairs carried out / remarks:</u>					

10. REPACKING WITH SAFETY CHECK - PACKER / CHECKER

DOCUMENTS	Packer	Checker	DOCUMENTS	Packer	Checker
Liferaft label completed			Container label completed		
ID card completed			Servicing history completed		
Re-inspection certificate completed					
CONNECTIONS	Packer	Checker.	For liferaft with VENTURI	Packer	Checker
Light connected			Venturi flap cover in position		
Painter line connected			Venturi caps removed		
Quick firing line connected			Venturis opened / secured		
			Venturi protection rolled		
DL container: shackle access cover glued			Venturi protection held in central pos. on container (Not on MIS R302)		

Station n°:

Technician's name:

Signature:

Checker's name:

Signature:

IMPORTANT - The « Technician or Packer » as well as the « Checker » must be approved by SurvitecZodiac. Please contact SurvitecZodiac for approval if an exemption is needed.

- The fields « Packer » and « Checker » must be always filled with the initials or with « N/A ».