



CHECKLIST

SMALL CRAFT - OWNER'S MANUAL

Ref.: EN ISO 10240:2020 [Note: not harmonised for RCD 2013/53/EU]

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



Subject to check	Clause	Requirements	Checked ?
1 The general introduction as per Annex A is provided.	Annex A	[Yes ?]	
2 Owner's Manual delivered in hardcopy.	4.2	[Yes ?]	
3 Owner's Manual in language of the country of intended use.	4.2	[Yes ?]	
4 If more than 4 pages, the Owner's Manual has an index.	4.2	[Yes / NA ?]	
5 All symbols used are in accordance with ISO 8999 and ISO 11192.	4.2	[Yes ?]	
6 SI units shall be used in accordance with ISO 1000; other units in brackets.	4.3	[Yes ?]	
7 Introductory paragraph informing the owner about his/her responsibility.	5.2	[Yes ?]	
8 If safety labels are used, meaning explained as follows: DANGER -indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is to be limited to the most extreme situations.	5.2	[Yes / NA ?]	
9 If safety labels are used, meaning explained as follows: WARNING - indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.	5.2	[Yes / NA ?]	
10 If safety labels are used, meaning explained as follows: CAUTION - indicates a potentially hazardous situation that, if not avoided, could result in minor or moderate injury.	5.2	[Yes / NA ?]	
11 If safety labels are used, meaning explained as follows: NOTICE - indicates information considered important, but not hazard-related, for example, relating to property damage.	5.2	[Yes / NA ?]	
12 Name of craft manufacturer, company or person responsible for putting craft on the market.	5.3	[Yes ?]	
13 Name of the model or type.	5.3	[Yes ?]	
14 Explanation of craft design category:			
15 Category A: A craft given design category A is considered to be designed to operate in winds of less than Beaufort force 10 and the associated significant wave heights.	5.3	[Yes / NA ?]	
16 Category B: A craft given design category B is considered to be designed to operate in winds of Beaufort force 8 or less and the associated significant waves heights of up to 4 m.	5.3	[Yes / NA ?]	
17 Category C: A craft given design category C is considered to be designed to operate in typical steady winds of Beaufort force 6 or less and the associated significant waves heights of up to 2 m.	5.3	[Yes / NA ?]	

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



18	Category D: A craft given design category D is considered to be designed to operate in typical steady winds of Beaufort force 4 or less and the associated significant waves heights of up to 0,3 m and occasional waves of 0,5 m height.	5.3	[Yes / NA ?]	
19	Mass of craft in light condition (kg). Note for craft with outboard engine: this mass includes the mass of the heaviest recommended outboard engine.	5.3	[Yes ?]	
20	Maximum load for the builder's plate (m_{MBP}), including a note to the loading provisions (see Cl. 5.5)	5.3	[Yes ?]	
21	Mass of craft in fully loaded condition (kg).	5.3	[Yes ?]	
22	Main dimensions of the craft.	5.3	[Yes ?]	
23	Drafts (in light craft condition and in the fully loaded condition).	5.3	[Yes ?]	
24	Type of main propulsion.	5.3	[Yes ?]	
25	If sailing boat: basic information on sail and rigging.	5.3	[Yes / NA ?]	
26	Nominal fixed fuel tank(s) capacity (litres), with a statement mentioning that all of its capacity may not be usable according to trim and loading and that a 20 % reserve should be kept, type of fuel and position of filling point(s) and draining point (if fitted).	5.3	[Yes / NA ?]	
27	Fixed fresh water tank(s) capacity (litres), with a statement mentioning that all of its capacity may not be usable according to trim and loading, and position of filling point(s) and draining point (if fitted).	5.3	[Yes / NA ?]	
28	Fixed holding tank(s) capacity (litres), and position of through hull or deck fitting(s) and draining point (if fitted).	5.3	[Yes / NA ?]	
29	Fixed oil tank(s) capacity (litres), clean and used, and position of filling and emptying point(s).	5.3	[Yes / NA ?]	
30	Ballast tanks.	5.3	[Yes / NA ?]	
31	Statement: "Builder's plate — Part of the information is given on the builder's plate affixed on the craft. A full explanation of this information is given in the relevant sections of this manual."	5.3	[Yes ?]	
32	The maximum recommended number of persons as per to ISO 14946 and ISO 12217 is stated.	5.4	[Yes ?]	
33	WARNING - Do not exceed the maximum recommended number of persons. Regardless of the number of persons on board, the total weight of persons and equipment must never exceed the maximum recommended load. Always use seats/seating spaces provided.	5.4	[Yes ?]	
34	Information of all weights of the maximum recommended load for builder's plate.	5.5	[Yes ?]	
35	WARNING - When loading the craft, never exceed the maximum recommended load. Always load the craft carefully and distribute loads appropriately to maintain design trim (approximately level). Avoid placing heavy weights high up.	5.5	[Yes ?]	
36	Maximum recommended engine power (kW) is provided.	5.6	[Yes / NA ?]	
37	Maximum recommended engine mass is provided if relevant.	5.6	[Yes / NA ?]	
38	Routine servicing and maintenance instructions of the engine(s).	5.6	[Yes / NA ?]	
39	Maintenance of the exhaust system.	5.6	[Yes / NA ?]	
40	Location of through-hull fittings.	5.7.2	[Yes / NA ?]	

compliant: Yes or V

not applicable: NA

follow up on variation report: Rpt or X

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



41	Bilge pumps and bailing	5.7.3		
42	Location of each bilge pump by a plan, sketch, layout grid or other means and the capacity rated by the pump manufacturer.	5.7.3	[Yes / NA ?]	
43	If relevant, operation instructions	5.7.3	[Yes / NA ?]	
44	Bilge pumps and bailing: If only a bucket or bailer is required: It is the responsibility of the owner/operator to have at least one bucket/bailer on board, secured against loss.	5.7.3	[Yes / NA ?]	
45	If only a bucket or bailer is required: It is the responsibility of the owner/operator to have at least one bucket/bailer on board, secured against loss.	5.7.3	[Yes / NA ?]	
46	If boat has no upright and level flotation: WARNING - The bilge pumping system is not designed for damage control.	5.7.3	[Yes / NA ?]	
47	NOTE - check the function of all bilge pumps at regular intervals. Clear pump inlets from debris. If seacocks are fitted in the fore and aft peak bulkheads, they shall be kept closed and shall only be opened to let water drain into the main bilges.	5.7.3	[Yes / NA ?]	
48	ISO 12217-1/2/3: Opening appliances located in the topsides and comply with ISO 12216 are referenced as watertight closure to be kept shut when underway.	5.7.4 - 5.7.6	[Yes / NA ?]	
49	12217-1/3: If some areas are excluded from the "crew area" or limiting the number of people on any given level, it is indicated in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	
50	12217-1/3: If a heavier mass is used for the level flotation test of an outboard engine, it is recorded in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	
51	12217-1: maximum load used for the stability assessment including: -maximum recommended load [kg]; -fuel, fresh water, other fluids of fixed tanks [kg]; -maximum load.	5.7.4 - 5.7.6	[Yes / NA ?]	
52	12217-1/2/3 "This boat has been assessed as capable of supporting the crew even when swamped."	5.7.4 - 5.7.6	[Yes / NA ?]	
53	12217-1/2/3: "The following openings are marked KEEP SHUT WHEN UNDER WAY, and care shall be taken to observe this warning. "under way" has the meaning "not at anchor, or made fast to the shore or aground"".	5.7.4 - 5.7.6	[Yes / NA ?]	
54	12217-1/3: IMPORTANT - FAILURE to observe the limitations may result in the boat capsizing	5.7.4 - 5.7.6	[Yes / NA ?]	
55	12217-1: If crew areas restricted by offset-load test: For stability reasons, the following parts of the boat should only be accessed by people in exceptional circumstances: (insert list of relevant locations). Such locations are indicated by the safety sign.	5.7.4 - 5.7.6	[Yes / NA ?]	



1

2

Key

1 sign P004 "No thoroughfare" from ISO 7010

2 supplementary text to read "No access"

compliant: Yes or V

not applicable: NA

follow up on variation report: Rpt or X

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



56	12217-1/3: If crew areas restricted by offset-load test: For stability reasons, the following parts of the boat should only be accessed by more than the indicated number of persons in exceptional circumstances: (insert list of relevant locations, e.g. deck, coachroof, flybridge, and limit on each location). Such locations are indicated by the safety sign and/or a sign at each control position.	5.7.4 - 5.7.6	[Yes / NA ?]	
	 Key 1 sign W001 "General warning" from ISO 7010 2 supplementary text to read "Max N persons on (location)" expressed for example as "flybridge" or "coachroof"			
57	12217-2: minimum operating condition with any centerboard or keel in lowered position when an instruction is given.	5.7.4 - 5.7.6	[Yes / NA ?]	
58	12217-2: Maximum load. Any centerboard or keel is in raised position unless it can be affixed in the lowered position and an instruction is given in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	
59	12217-2/3: Knockdown recovery test: Any centerboard or keel is in raised position unless it can be affixed in the lowered position and an instruction is given in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	
60	12217-2/3: Wind stiffness test: Any centerboard or keel is in raised position unless it can be affixed in the lowered position and an instruction is given in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	
61	12217-2/3: The owner's manual shall clearly state the apparent wind speed at which reefing becomes necessary (given in either knots or metres per second), and the possible consequences of failing to reef at the appropriate time.	5.7.4 - 5.7.6	[Yes / NA ?]	
62	12217-2/3: IMPORTANT - If not sailed with care, the boat may swamp or capsize unless the sail area is adjusted to suit the prevailing wind conditions and the main sheet is not belayed.	5.7.4 - 5.7.6	[Yes / NA ?]	
63	12217-2/3: Capsize-recovery test information: -the likelihood of capsize when in normal use; -the righting technique which is most successful; -the minimum necessary crew mass [kg].	5.7.4 - 5.7.6	[Yes / NA ?]	
64	12217-2/3: Safety signs for capsized recoverable boats where there is no cabin:  Key 1 Sign W001 "General warning" from ISO 7010 2 Supplementary text to read "Risk of capsizing!"	5.7.4 - 5.7.6	[Yes / NA ?]	
65	12217-2/3: Safety signs for capsized recoverable boats where boat is fitted with a cabin:  Key 1 Sign W001 "General warning" from ISO 7010 2 Supplementary text to read "Risk of capsizing! Persons in cabin may be trapped!"	5.7.4 - 5.7.6	[Yes / NA ?]	
66	12217-2: Where a break-out panel is used, the method is explained in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	

compliant: Yes or V

not applicable: NA

follow up on variation report: Rpt or X

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	




67	12217-2: Vertical center of gravity: Any centerboard or keel is in raised position unless it can be affixed in the lowered position and an instruction is given in the owner's manual.	5.7.4 - 5.7.6	[Yes / NA ?]	
68	12217-2: IMPORTANT - The water ballast tanks located are intended to be completely full whenever the boat is afloat.	5.7.4 - 5.7.6	[Yes / NA ?]	
69	12217-2/3: IMPORTANT : This boat is only intended to be sailed with the centreboard or drop keel locked in the lowered position (where the stability has only been assessed in this condition).	5.7.4 - 5.7.6	[Yes / NA ?]	
70	12217-2: "The ballast tanks located may be filled with variable amounts of liquid to suit the sailing conditions. When using this ballast, the boat still satisfies the requirements for its design category, even with the ballast positioned to leeward".	5.7.4 - 5.7.6	[Yes / NA ?]	
71	12217-2: "The position of movable solid ballast may be varied to suit the sailing conditions. When using this ballast, the boat still satisfies the requirements for its design category, even when the ballast is deployed to leeward".	5.7.4 - 5.7.6	[Yes / NA ?]	
72	12217-2: This boat has been assessed using the Stability Index (STIX), which is a measure of the overall stability safety and considers the effects of boat length, displacement, hull proportions, stability characteristics and resistance to downflooding. This assessment has yielded the following data: -STIX (minimum operating condition and loaded arrival condition); -angle of vanishing stability (minimum operating condition and loaded arrival condition).	5.7.4 - 5.7.6	[Yes / NA ?]	
73	12217-2: Table 2, option 5: This boat may swamp or capsize if excessive sail is carried. It may sink if this occurs. The working sail plan should be reduced if the apparent wind exceeds ... knots/metres per second. Particular care should be taken in gusty wind conditions.	5.7.4 - 5.7.6	[Yes / NA ?]	
74	12217-2/3: Table 2, option 6: This boat may swamp or capsize if excessive sail is carried. It is designed not to sink if this occurs. The working sail plan should be reduced if the apparent wind exceeds ... knots/metres per second. Particular care should be taken in gusty wind conditions.	5.7.4 - 5.7.6	[Yes / NA ?]	
75	12217-2: This boat may capsize and remain inverted if excessive sail is carried. It is designed not to sink if this occurs. The working sail plan should be reduced if the apparent wind exceeds ... knots/metres per second. Other stability hazards are ... (see 7.5 and insert as appropriate).	5.7.4 - 5.7.6	[Yes / NA ?]	
76	12217-2/3: Reefing safety sign for fully enclosed boats: Key 1 sign W001 "General warning" from ISO 7010 2 supplementary text to read "Reef sails at <i>N</i> knots (or m/s) apparent wind speed", where <i>N</i> is the relevant wind speed	5.7.4 - 5.7.6	[Yes / NA ?]	

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



77	12217-2/3: Reefing safety sign for other boats:	5.7.4 - 5.7.6	[Yes / NA ?]	
	 Key 1 sign W001 "General warning" from ISO 7010 2 supplementary text to read "Reef sails before water enters, or boat will flood and may not recover"			
78	12217-2: Stability data table using ISO 12217-2 Clause 6.5.2 or Clause 7 is provided.	5.7.4 - 5.7.6	[Yes / NA ?]	
79	12217-2: Wind speed limit for stability data for each sail combination and load condition	5.7.4 - 5.7.6	[Yes / NA ?]	
80	12217-3: Risk of capsize or swamping sign:	5.7.4 - 5.7.6	[Yes / NA ?]	
	 Key 1 sign W001 "General warning" from ISO 7010 2 supplementary text to read "Risk of capsize or swamping"			
81	12217-3: This boat will capsize or swamp if a load of 85 kg is placed on the gunwale. Users should not sit or stand on the gunwale:	5.7.4 - 5.7.6	[Yes / NA ?]	
	 Key 1 sign W001 "General warning" from ISO 7010 2 supplementary text to read "Do not sit on gunwale"			
82	Bilge water should be kept to a minimum.	5.7.4	[Yes / NA ?]	
83	Stability is reduced by any weight added above the main deck.	5.7.4	[Yes / NA ?]	
84	In rough weather, hatches, lockers and doorways should be closed to minimize the risk of flooding.	5.7.4	[Yes / NA ?]	
85	Stability may be reduced when towing or lifting heavy weights using a davit or boom.	5.7.4	[Yes / NA ?]	
86	Air tanks shall not be punctured including warning label on the boat "Do not puncture air tank/container/bag".	5.7.4	[Yes / NA ?]	
87	Breaking waves are a serious stability hazard.	5.7.4	[Yes / NA ?]	
88	Any change in the disposition of the masses aboard (for example, the addition of a fishing tower, a radar, a stowing mast, change of engine, etc.) may significantly affect the stability, trim and performance of the craft.	5.7.4	[Yes / NA ?]	
89	Position and operation of escape hatches of sailing multihulls in the event of inversion.	5.7.6	[Yes / NA ?]	
90	Instructions for the actions to be taken following a grounding of the craft.	5.7.7	[Yes / NA ?]	

compliant: Yes or V

not applicable: NA

follow up on variation report: Rpt or X

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



91	Instructions for propulsion engines, generator sets, etc.: -ensure flow of cooling water; -ensure that ventilation ducts are free; - precautions when refuelling; -prevention of damage to fuel lines; - requirement to keep fixed ventilation openings unobstructed at all times; -avoidance of contact of flammable materials with hot engine parts; -not to store equipment containing petrol in compartments not designed for this purpose.	5.8.2	[Yes / NA ?]	
92	Instructions for gas systems: -operating of appliances; -insection of the system; -gas cylinders shall only be stored in specified housing/lockers; -location of gas housing/lockers; -procedure of changing gas cylinders; -precautions to avoid contact of materials with hot areas; - advise to shut of the gas valve in the event of an LPG leak or fire; - advise to ensure proper ventilation to prevent asphyxiation.	5.8.3	[Yes / NA ?]	
93	Instructions for other fuel-burning systems with relevant informations, if applicable: - operating instructions for appliances; - precautions when refuelling appliances; - instructions for safe storage of fuel containers; - precautions to avoid contact of materials with hot areas or flames; - advise to ensure proper ventilation to prevent asphyxiation.	5.8.4	[Yes / NA ?]	
94	Electrical systems: information and instruction for safe operation as relevant: - operation and position of battery selector switches; - description of switch panel(s); - procedure of changing fuses, type, capacity and identification in diagram; - not to obstruct battery ventilation ducts; - precautions when recharging and disconnecting/reconnecting battery; - precautions when connecting/disconnecting shore supply; - for shore supply: Information about the risk of swimming if craft is connected to the shore power - information required for the safe operation of 3 Phase AC service, if applicable.	5.9	[Yes / NA ?]	
95	WARNING: Do not work on an energized AC system.	5.9	[Yes / NA ?]	
96	Motor craft: information on safe handling as relevant: - avoid sudden manoeuvres at speed; - For comfort and safety, reduce speed in rough seas; - Always use the engine cut off lanyard, if provided.	5.10.1	[Yes / NA ?]	
97	Engine starting: instruction for safe operation is provided.	5.10.2	[Yes / NA ?]	

compliant: Yes or V

not applicable: NA

follow up on variation report: Rpt or X

Checklist_Evaluation_Module B_G en260703

Watercraft manufacturer:	
Watercraft model name:	



98	Emergency steering: Location and operation are indicated.	5.10.3	[Yes / NA ?]	
99	If liferaft stowage area is needed the location is identified.	5.11.2	[Yes / NA ?]	
100	Danger from moving parts of machinery: instructions to avoid moving parts of engine, shafts etc., and if relevant details concerning guards are provided.	5.11.3	[Yes / NA ?]	
101	Ventilation when using combustion device: The information on risks from exhaust gases.	5.11.4	[Yes / NA ?]	
102	Ventilation when using combustion device: Instructions for mitigating CO on petrol-powered craft.	5.11.4	[Yes / NA ?]	
103	Recommendations given about securing loose equipment when underway.	5.11.5	[Yes ?]	
104	Information in regards to respect for environment: - Respect codes of good practise, be aware about local environment laws; - Be aware of international regulations against marine pollution (Marpol) and to respect it; -Instructions not to discharge toilets or holding tanks close to shore or in any prohibited zone, and to use harbour or marina pump-out facilities to empty the holding tank before leaving the harbour.	5.11.6	[Yes ?]	
105	Use of holding tanks with additional information: -note to observe local regulation on discharge; -location of discharge shutoff seacocks and methods of securing these sealed shut.	5.11.7	[Yes / NA ?]	
106	Mass of the trailering condition is provided, if relevant.	5.11.9	[Yes / NA ?]	
107	Instructions how to tune and maintain rigging systems	5.12	[Yes / NA ?]	
108	Any other information relevant for the safe operation of the craft is provided.	6	[Yes / NA ?]	

Comments:
