BMW Motorcycles

Maintenance Schedule for K-Models

☐ K75 ☐ K100 ☐ K1100 ☐ K1

_____ Customer Name _____ Vehicle Identification Number (VIN)	_____ Repair Order Number / Date _____ Mileage In	BMW Inspection 600 miles	BMW Service 4-6,000 miles	BMW Inspection 8-12,000 miles	BMW Annual Service
Check Vehicle History for any outstanding recalls.		☐	☐	☐	☐
Read MOTRONIC fault memory with BMWMoDiTeC. (motorcycles with 4-valve engines only)		☐	☐	☐	☐
Check brake pads and discs for wear, renew as necessary*			☐	☐	
Check front and rear brake fluid levels.		☐	☐	☐	
Check brake system with regard to function, and leaks. Repair as required *		☐	☐	☐	
Change brake fluid once a year with DOT 4 fluid.					☐
Check ABS sensors/pulse wheels for correct gap/contamination Adjust and clean as required *		☐	☐	☐	
Change engine oil when at operating temperature, renew oil filter. (for short distance driving or when outside temperature is below 32 F, every 3 months or 1800 miles.)		☐	☐	☐	☐
Change transmission oil when at operating temperature.		☐		☐	☐
Change oil in rear drive and telescopic fork when at operating temperature.		☐		☐	☐
Clean inductive speed sensor at rear drive.		☐		☐	☐
Check/adjust valve clearances. (every 16,000 mi. for 4 valve engines)		☐ 1)		☐	
Renew the lining of the chain tensioning rail & chain guide every 36,000 miles.*				☐	
Replace spark plugs				☐	
Check hose clamps on fuel & cooling system for leaks; retighten if necessary. Check coolant level & concentration, correct if necessary.		☐		☐	☐
Renew coolant every 2 years.*					☐
Renew fuel filter every 24,000 miles*; if fuel quality is poor every 12,000 miles.				☐	
Drain and clean fuel tank every 2 years*					☐
Renew intake air filter (if riding in dirty/dusty conditions renew every 6,000 miles/check more frequently)				☐	
Lubricate applicable splines every year* (input shaft, paralever, driveshaft) Motorcycles produced from 1990 onward, lubricate every 40,000 miles.)					☐
Check play in steering, wheel and swingarm bearings, renew if necessary. (replace wheel and swing arm bearings every 25,000 miles*)			☐	☐	
Check clutch clearance, adjust if necessary. Grease upper & lower clutch cable nipples.		☐	☐	☐	
Check throttle cable & choke cable freeplay; adjust if necessary. (in severe operating conditions, grease the throttle twistgrip every 18,000 miles.)		☐		☐	
Check battery acid level, top up with water if necessary. Clean & grease battery posts.			☐	☐	☐

* invoiced as a seperate item
1) K75 models only

⇩ **Continue on page 2** ⇩

BMW Motorcycles

Maintenance Schedule for K-Models

☐ **K75** ☐ **K100** ☐ **K1100** ☐ **K1**

_____
Vehicle Identification Number (VIN)

	BMW Inspection 600 miles	BMW Service 6,000 miles	BMW Inspection 12,000 miles	BMW Annual Service
Check operation of sidestand switch (angle); or retracting sidestand linkage (K75's)	☐	☐	☐	
Apply silicone spray to guide rods of adjustable windshield (only K1100LT, K75RT)			☐	☐
Check torque at the bolts and nuts: • engine to frame • suspension strut mounts • side & center stand pivot • rear wheel studs • front axle studs, clamp bolts, brake caliper mounting bolts	☐		☐	
Adjust tire pressure to specification: Front_____psi. Rear_____psi.	☐	☐	☐	☐
Final Inspection with Safety / Operating check: • Condition of tires and wheels • Lights, horn, and signal system • Telltale and warning lights • Clutch and gear shift • Steering, hand & footbrake, ABS • Instruments (including optional accessories, radio, etc.) • Check & adjust engine idle speed • Check and adjust CO content of exhuast (models with closed loop catclyic con verters • Test ride, visual quality check	☐	☐	☐	☐

* invoiced as a separate item

1) K75 models only

⇩ **Maintenance Complete, Sign and Record Mileage Below** ⇩

_____ _____ _____

Technician Signature Date Mileage Out