ROLAND TR8 - PATTERN EDITOR

Name :

DATE :
TEMPO :

STORE IN TR8

PTN SELECT	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
KIT DRUM	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16

INST	1	2	3	4	5	6	7	8
BD	808 BD	909 BD	808 BD Long Decay	707 BD1/2	727 H/L Bongo	909 AttackBD	---	---
SD	808 SD	909 SD	707 SD1/2	727 Mute/ Open H Conga	909 AttackSD	---	---	---
LT	808 LT	909 LT	808 L Conga	707 LT	727 L Conga	707 BD1	707 BD2	808 NoiseTom L
MT	808 MT	909 MT	808 M Conga	707 MT	727 H Timbale	727 L Bongo	727 Open H Conga	808 NoiseTom M
HT	808 HT	909 HT	808 H Conga	707 HT	727 L Timbale	727 H Bongo	727 Mute H Conga	808 NoiseTom H
RS	808 RS	909 RS	808 Claves	707 RS/ Cowbell	727 H/L Agogo	---	---	---
HC	808 HC	909 HC	808 Maracas	707 HC/ Tambourine	727 Cabasa/ Maracas	808 FingerSnap	808 NoiseClap	---
CH	808 CH	909 CH	707 CH	727 ShortWhistle	---	---	---	---
OH	808 OH	909 OH	707 OH	727 LongWhistle	---	---	---	---
CC	808 CC	909 CC	707 CC	727 Quijada	727 ShortWhistle	---	---	---
RC	808 Cowbell	909 RC	707 RC	727 StarChime	727 LongWhistle	808 FingerSnap	808 NoiseClap	707 Tambourine

Right-side columns: SELECT | ACCENT | REVERB | DELAY | External In | Gain | Pan

ACCENT — Level ◯

REVERB — Level ◯ Time ◯ Gate ◯

Delay — Level ◯ Time ◯ Feed back ◯

EXTERNAL IN — Level ◯ Side chain ◯

BD		SD		LT	MT	HT	RS	HC	CH	OH	CC	BC	SCATTER
Tune	Attack	Tune	Snappy	Tune	Tune	Tune	Tune	Tune	Tune	Tune	Tune	Tune	
◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	1 . ◯ . 10
Comp	Decay	Comp	Decay	Decay	Decay	Decay	Decay	Decay	Decay	Decay	Decay	Decay	Shuffle . Fine
◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯	◯ ◯

VOL (0/10)															

PATTERN A	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
BD																
SD																
LT																
MT																
HT																
RS																
HC																
CH																
OH																
CC																
BC																
Accent																
Reverb																
Delay																

PATTERN B	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
BD																
SD																
LT																
MT																
HT																
RS																
HC																
CH																
OH																
CC																
BC																
Accent																
Reverb																
Delay																

Gain :
DRUM SELECT [KIT]. [INST] + [TEMPO] : (0 – 200) Default = 100

Pan :
DRUM SELECT [INST]. [INST] + [TEMPO] : L64–0–R63

REVERB : on/off
DRUM SELECT [KIT]
[REVERB] + instrument PAD

DELAY : on/off
DRUM SELECT [KIT]
[DELAY] + Instrument PAD

Random Pattern:
[PTN SELECT] + SCATTER [ON]. Save with [TR REC]

Copy Pattern :
[PTN SELECT]
[PTN SELECT] + pad you want to copy
Select destination PAD for the pattern

Delete Pattern :
[PTN SELECT]
[CLEAR] + select pad = DELETE

Locking Pattern :
[PTN SELECT]
Select th pattern you want to lock
[PTN SELECT] + [TEMPO] Knob

Copying a kit :
DRUM SELECT [KIT].
SELECT the PAD you want to copy
[KIT] + [TEMPO] to modify
Press the blinking [PAD] to cpoy

Select pattern A or B while playing
[TR REC] + [A] or [B]

A. BERNARD - 2016-11-12