

[illegible]

		(1) 平日			(2) 土曜			(3) 日曜			(4) 特殊日1			(5) 特殊日2			(6) 特殊日3			(7) 特殊日4			
パ タ ン 切 替	切替 番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	
		1	6	00	2	6	00	2	6	00	2												
		2	7	00	3	7	00	3	7	00	3												
		3	9	00	1	9	00	1	9	00	1												
		4	16	00	2	16	00	2	16	00	2												
		5	17	00	3	17	00	3	17	00	3												
		6	18	00	1	18	00	1	18	00	1												
		7																					
		8																					
		9																					
	A																						
動 作 切 替	閃光 系統	23:00～6:00			23:00～6:00			23:00～6:00															
系 統 動 作 定 数	同期点				1ステップ始まり																		
	追従幅				+15%・-5%																		
	追従階梯秒数配分				均等																		
	主現示追従階梯				1ステップ																		
	従現示追従階梯				6ステップ																		
	時刻修正				○(GPS)																		
連 動 子 機 機 能 定 数	DC方式								分 周 期 連 動 機 能 定 数		実行しきい値												
	AC方式										連動パターン												
	同期階梯1(B/Y1)																						
	同期階梯2(A/Y2)																						
	周期監視時間																						
	共通オフセット1																						
	共通オフセット2																						
	連動親機																						
交通弱者感应定数																							
感应階梯								ステップ															
補正階梯								ステップ															
倍率指定 (10～19)								×0.1倍															
弱者用保証青時間(0～99)								秒															
ギ ャ ッ プ 感 応 定 数	単位1								単位2														
	短縮		延長		単位青		単位青		短縮		延長		単位青		単位青								
	Ts		Te		上り0.1秒		下り0.1秒		Ts		Te		上り0.1秒		下り0.1秒								
	P1								P1														
	P2								P2														
	P3								P3														
	P4								P4														
	P5								P5														
	P6								P6														
	P7								P7														
	P8								P8														
	P9								P9														
PA								PA															
感应階梯								感应階梯															
リ コ ー ル 定 数	感应階梯				ステップ																		
	補正階梯				ステップ																		
	感知器指定		押ボタン				車両																
	押ボタン受付禁止階梯								開始				終了										
車両リコール受付禁止階梯								開始															