

		(1)平日			(2)土曜			(3)日曜			(4)特殊日1			(5)特殊日2			(6)特殊日3			(7)特殊日4			
パターン切替	切替番号	時	分	ハタシ番号	時	分	ハタシ番号	時	分	ハタシ番号	時	分	ハタシ番号	時	分	ハタシ番号	時	分	ハタシ番号	時	分	ハタシ番号	
	1	0	0	1	0	0	1	0	0	1													
	2	6	0	2	6	0	2	7	0	2													
	3	7	0	4	7	0	4	10	0	4													
	4	9	0	4	9	0	4	19	0	3													
	5	17	0	5	17	0	5	21	0	1													
	6	19	0	3	19	0	3																
	7	21	0	1	21	0	1																
	8																						
	9																						
A																							
動作切替	リコール1	8:30～07:00			8:30～07:00			8:30～07:00															
	系統	00:00～00:00			00:00～00:00			00:00～00:00															
系統動作定数	同期点				1ステップ頭																		
	追従幅				-5%～+20%																		
	追従階梯秒数配分				スプリット配分																		
	主現示追従階梯				1																		
	従現示追従階梯				7																		
	時刻修正				電波時計●																		
連動子機能定数	DC方式								分周期連動機能定数	実行しきい値													
	AC方式									連動パターン													
	同期階梯1(B/Y1)																						
	同期階梯1(A/Y2)																						
	周期監視時間																						
	共通オフセット1																						
	共通オフセット2																						
連動親機																							
交通弱者感応定数																							
感応階梯						ステップ																	
補正階梯						ステップ																	
倍率指定 (10～19)						×0.1倍																	
弱者用保証青時間 (0～99)						秒																	
ギャップ感応定数	単位1					単位2																	
		短縮	延長	単位青	単位青		延長	短縮	単位青	単位青													
		Ts	Te	上り0.1秒	下り0.1秒		Te	Ts	下り0.1秒	上り0.1秒													
	P1					P1																	
	P2					P2																	
	P3					P3																	
	P4					P4																	
	P5					P5																	
	P6					P6																	
	P7					P7																	
	P8					P8																	
	P9					P9																	
PA					PA																		
感応階梯					感応階梯																		
リコール定数	感応階梯		1		ステップ																		
	補正階梯				ステップ																		
	感知器指定		押ボタン		PB1		車両																
	押ボタン受付禁止階梯						開始		7		終了		7										
	車両リコール受付禁止階梯						開始				終了												
特殊日(プロ多)																							
平主体	西暦	月	日	平日(1) 土曜(2) 休日(3) 毎年(55)						規制番号		05-0043											
										名称		桑田渡船入口											