

パ タ ン 切 替		(1) 平日		(2) 土曜		(3) 日曜		(4)特殊日1		(5)特殊日2		(6)特殊日3		(7)特殊日4		
	切替 番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号
	1	6	00	1	6	00	1	6	00	1						
	2	7	00	3	7	00	3	7	00	2						
	3	9	00	2	9	00	2	19	00	1						
	4	16	00	3	16	00	3									
	5	19	00	2	19	00	2									
	6	20	00	1	20	00	1									
	7															
	8															
9																
A																
動 作 切 替	連動子機	00:00～00:00		00:00～00:00		00:00～00:00										
系 統 動 作 定 数	同期点															
	追従幅															
	追従階梯秒数配分															
	主現示追従階梯															
	従現示追従階梯															
	時刻修正															
連 動 子 機 能 定 数	DC方式				-											
	AC方式				○											
	同期階梯1(B/Y1)				1ステップ											
	同期階梯2(A/Y2)				-											
	周期監視時間				255秒											
	共通オフセット1				個別オフセット											
	共通オフセット2				-											
連動親機				三篠町2丁目5番(01-0258)												
交通弱者感応定数																
感応階梯																
補正階梯																
倍率指定 (10～19)																
弱者用保証青時間(0～99)																
ギ ャ ッ プ 感 応 定 数	単位1				単位2											
	短縮		延長		単位青		単位青		短縮		延長		単位青		単位青	
	Ts		Te		上り0.1秒		下り0.1秒		Ts		Te		上り0.1秒		下り0.1秒	
	P1								P1							
	P2								P2							
	P3								P3							
	P4								P4							
	P5								P5							
	P6								P6							
	P7								P7							
	P8								P8							
	P9								P9							
	PA								PA							
感応階梯																
リ コ ー ル 定 数	感応階梯				ステップ											
	補正階梯				ステップ											
	感知器指定		押ボタン				車両									
									開始				終了			
											開始				終了	
特殊日(プロ多)																
平日(1)																
土曜(2)																
休日(3)																
毎年(55)																
規制番号																
名称																
01-1128																
三篠公園(北)																
設定変更履歴																
年月日																
変更内容																
2015年12月4日																
制御機更新																

備考
地点感応制御機の場合左記の
ギャップ感応定数表の内容は
下記の通りです。

短縮 Ts → ありません。
延長 Te → 限度青です。
単位青 上り → 単位青です。
単位青 下り → ありません。
単位青秒数は0.5秒単位です。