

[illegible]

		(1) 平日			(2) 土曜			(3) 日曜			(4) 特殊日1			(5) 特殊日2			(6) 特殊日3			(7) 特殊日4			
パ タ ン 切 替	切替 番号	時	分	ハタン 番号	時	分	ハタン 番号	時	分	ハタン 番号	時	分	ハタン 番号	時	分	ハタン 番号	時	分	ハタン 番号	時	分	ハタン 番号	
		1	6	30	1	6	30	1	6	30	1												
		2	7	00	4	7	00	4	7	00	4												
		3	9	00	2	9	00	2	9	00	2												
		4	12	00	1	12	00	1	12	00	1												
		5	17	00	3	17	00	3	17	00	3												
		6	19	00	1	19	00	1	19	00	1												
		7																					
		8																					
		9																					
	A																						
動 作 切 替	系統	00:00～00:00			00:00～00:00			00:00～00:00															
系 統 動 作 定 数	同期点				1ステップ始め																		
	追従幅																						
	追従階梯秒数配分																						
	主現示追従階梯				1ステップ																		
	従現示追従階梯																						
	時刻修正				●																		
運 動 子 機 能 定 数	DC方式								分 周 期 連 動 機 能 定 数	実行しきい値													
	AC方式									連動パターン													
	同期階梯1(B/Y1)																						
	同期階梯2(A/Y2)																						
	周期監視時間																						
	共通オフセット1																						
	共通オフセット2																						
	運動親機																						
交通弱者感応定数																							
感応階梯				ステップ																			
補正階梯				ステップ																			
倍率指定 (10～19)				×0.1倍																			
弱者用保証青時間(0～99)				秒																			
ギ ャ ッ プ 感 応 定 数	単位1					単位2																	
		初期青		単位青A	単位青B		初期青		単位青A	単位青B													
		秒		秒	秒		秒		秒	秒													
	P1					P1																	
	P2					P2																	
	P3					P3																	
	P4					P4																	
	P5					P5																	
	P6					P6																	
	P7					P7																	
	P8					P8																	
	P9					P9																	
PA					PA																		
感応階梯		補正階梯				感応階梯		補正階梯															
リ コ ー ル 定 数	感応階梯		ステップ																				
	補正階梯		ステップ																				
	感知器指定		押ボタン				車両																
	押ボタン受付禁止階梯						開始				終了												
	車両リコール受付禁止階梯						開始				終了												
期間(Aプロ多)																							
S	曜日	月	日	日種																			