

[illegible]

パターン切替		(1) 平日		(2) 土曜		(3) 日曜		(4)特殊日1		(5)特殊日2		(6)特殊日3		(7)特殊日4		
	切替番号	時	分	ハタ番号	時	分	ハタ番号	時	分	ハタ番号	時	分	ハタ番号	時	分	ハタ番号
	1	6	00	1	6	00	1	6	00	1						
	2	7	00	7	7	00	7	8	00	2						
	3	9	00	5	9	00	5	10	00	4						
	4	11	00	4	11	00	4	11	00	5						
	5	16	00	5	16	00	5	16	00	6						
	6	17	00	7	17	00	7	19	00	3						
	7	19	00	4	19	00	4	21	0	1						
	8	21	0	1	21	0	1									
9																
A																
動作切替	系統	00:00～00:00			00:00～00:00			00:00～00:00								
	閃光	21:00～6:00			21:00～6:00			21:00～6:00								
系統動作定数	同期点				1ステップ始まり											
	追従幅				+15%・-5%											
	追従階梯秒数配分				均等											
	主現示追従階梯				1ステップ											
	従現示追従階梯				6ステップ											
	時刻修正				○(GPS)											
連動子機能定数	DC方式								分 周 期 連 動 機 能 定 数		実行しきい値					
	AC方式										連動パターン					
	同期階梯1(B/Y1)															
	同期階梯2(A/Y2)															
	周期監視時間															
	共通オフセット1															
	共通オフセット2															
	連動親機															
交通弱者感応定数																
感応階梯								ステップ								
補正階梯								ステップ								
倍率指定 (10～19)								×0.1倍								
弱者用保証青時間(0～99)								秒								
ギャップ感応定数	単位1								単位2							
		短縮	延長	単位青	単位青		短縮	延長	単位青	単位青		短縮	延長	単位青	単位青	
		Ts	Te	上り0.1秒	下り0.1秒		Ts	Te	上り0.1秒	下り0.1秒		Ts	Te	上り0.1秒	下り0.1秒	
	P1					P1					P1					
	P2					P2					P2					
	P3					P3					P3					
	P4					P4					P4					
	P5					P5					P5					
	P6					P6					P6					
	P7					P7					P7					
	P8					P8					P8					
	P9					P9					P9					
	PA					PA					PA					
	感応階梯								感応階梯							
リコール定数	感応階梯		ステップ													
	補正階梯		ステップ													
	感知器指定		押ボタン				車両									
	押ボタン受付禁止階梯								開始				終了			
	車両リコール受付禁止階梯								開始				終了			
特殊日(プロ多)																
平土休	西暦	月	日													
				平日(1) 土曜(2) 休日(3) 毎年(55)												