

	切替番号	(1)平日			(2)土曜			(3)日曜			(4)特殊日1			(5)特殊日2			(6)特殊日3			(7)特殊日4		
		時	分	パタ 番号	時	分	パタ 番号	時	分	パタ 番号	時	分	パタ 番号	時	分	パタ 番号	時	分	パタ 番号	時	分	パタ 番号
パ タ ン 切 替	1	0	0	1	0	0	1	0	0	1												
	2	6	0	2	6	0	2	7	0	2												
	3	7	20	5	7	20	5	8	30	3												
	4	9	0	4	9	0	4	10	0	5												
	5	16	30	5	16	30	5	19	0	3												
	6	19	0	3	19	0	3	21	0	1												
	7	21	0	1	21	0	1															
	8																					
	9																					
	A																					
動 作 切 替	閃光	22:00~06:00			22:00~06:00			22:00~06:00														
	系統	00:00~00:00			00:00~00:00			00:00~00:00														
系 統 動 作 定 数	同期点						1ステップ頭															
	追従幅						-5%~+20%															
	追従階梯秒数配分						スプリット配分															
	主現示追従階梯						1															
	従現示追従階梯						6															
	時刻修正						電波時計●															
運 動 子 機 能 定 数	DC方式												分 周 期 連 動 機 能 定 数	実行しきい値								
	AC方式													連動パターン								
	同期階梯1(B/Y1)																					
	同期階梯1(A/Y2)																					
	周期監視時間																					
	共通オフセット1																					
	共通オフセット2																					
	運動親機																					
交通弱者感応定数																						
感応階梯						ステップ																
補正階梯						ステップ																
倍率指定 (10~19)						×0.1倍																
弱者用保証青時間(0~99)						秒																
ギ ャ ッ プ 感 応 定 数	単位1					単位2																
		短縮	延長	単位青	単位青		延長	短縮	単位青	単位青												
		Ts	Te	上り0.1秒	下り0.1秒		Te	Ts	下り0.1秒	上り0.1秒												
	P1					P1																
	P2					P2																
	P3					P3																
	P4					P4																
	P5					P5																
	P6					P6																
	P7					P7																
	P8					P8																
	P9					P9																
	PA					PA																
	感応階梯					感応階梯																
リ コ ー ル 定 数	感応階梯		ステップ																			
	補正階梯		ステップ																			
	感知器指定		押ボタン		車両																	
	押ボタン受付禁止階梯					開始		終了														
	車両リコール受付禁止階梯					開始		終了														
特殊日(プロ多)																						
平土休	西暦	月	日	平日(1) 土曜(2) 休日(3) 毎年(55)																		
設定変更履歴																						
年月日				変更内容																		
2012年2月23日				制御機更新																		

規制番号	05-0067
名称	松岡団地入口