

[illegible]

The flowchart illustrates the route from the station to the destination. It starts with a vertical line representing the main road. A horizontal line branches off to the right, labeled '東福山駅' (Higashifukuyama Station). From the station, a curved arrow points right and then down, leading to a horizontal line labeled '10.5m 歩灯2灯' (10.5m, 2 pedestrian lights). This line continues to the right, labeled '至 引野団地' (To Inno-danchi). A vertical line branches off to the left from the main road, labeled '至 鋼管町' (To Kōkan-chō). A horizontal line branches off to the right from the main road, labeled '至 引野団地' (To Inno-danchi). A vertical line branches off to the left from the main road, labeled '至 鋼管町' (To Kōkan-chō).

[illegible]

		(1) 平日			(2) 土曜			(3) 日曜			(4) 特殊日1			(5) 特殊日2			(6) 特殊日3			(7) 特殊日4			
パ タ ン 切 替	切替 番号	時	分	パタン 番号	時	分	パタン 番号	時	分	パタン 番号	時	分	パタン 番号	時	分	パタン 番号	時	分	パタン 番号	時	分	パタン 番号	
		1	6	00	5	6	00	5	7	00	1												
		2	7	00	7	7	00	7	8	00	2												
		3	7	30	A	9	00	5	10	00	3												
		4	8	30	7	10	00	2	16	00	4												
		5	9	00	5	16	00	6	19	00	2												
		6	10	00	2	19	00	2	20	00	1												
		7	16	00	6	20	00	1															
		8	17	00	8																		
		9	19	00	2																		
	A	20	00	1																			
動 作 切 替	系統	00:00～00:00			00:00～00:00			00:00～00:00															
	閃光	22:00～06:00			22:00～06:00			22:00～06:00															
系 統 動 作 定 数	同期点				1ステップ始め																		
	追従幅				-5%/+20%																		
	追従階梯秒数配分				スプリット比配分																		
	主現示追従階梯				1																		
	従現示追従階梯				6																		
	時刻修正				●																		
運 動 子 機 能 定 数	DC方式								分 周 期 運 動 機 能 定 数	実行しきい値													
	AC方式									連動パターン													
	同期階梯1(B/Y1)																						
	同期階梯2(A/Y2)																						
	周期監視時間																						
	共通オフセット1																						
	共通オフセット2																						
連動親機																							
交通弱者感応定数																							
感応階梯										ステップ													
補正階梯										ステップ													
倍率指定 (10～19)										×0.1倍													
弱者用保証青時間 (0～99)										秒													
ギ ャ ッ プ 感 応 定 数	単位1								単位2														
		短縮	延長	単位青	単位青		短縮	延長	単位青	単位青		短縮	延長	単位青	単位青								
		Ts	Te	上り0.1秒	下り0.1秒		Ts	Te	上り0.1秒	下り0.1秒		Ts	Te	上り0.1秒	下り0.1秒								
	P1					P1					P1												
	P2					P2					P2												
	P3					P3					P3												
	P4					P4					P4												
	P5					P5					P5												
	P6					P6					P6												
	P7					P7					P7												
	P8					P8					P8												
	P9					P9					P9												
	PA					PA					PA												
	感応階梯								感応階梯														
補正階梯								補正階梯															
感知器指定								感知器指定															
リ コ ー ル 定 数	感応階梯				ステップ																		
	補正階梯				ステップ																		
	感知器指定				押ボタン				車両														
	押ボタン受付禁止階梯								開始				終了										
車両リコール受付禁止階梯								開始				終了											
曜日固定祝祭日テーブル																							
	月	週	曜日																				
1	1	2	1																				
2	7	3	1																				
3	9	3	1																				
4	10	2	1																				
設定変更履歴																							
年月日				変更内容																			
2004年11月12日				三色運用開始時刻変更【現在】22:00～7:00→【変更】22:00～6:00																			
2013年11月13日				制御機更新																			

規制番号	07-0159
名 称	旭ヶ丘南口

備 考

地点感応制御機の場合左記のギャップ感応定数表の内容は下記の通りです。

短縮 Ts → ありません。

延長 Te → 限度青です。

単位青 上り → 単位青です。

単位青 下り → ありません。

単位青秒数は 0.5秒単位です。

名称はこのように変更してください。