

パ タ ン 切 替		(1) 平日		(2) 土曜		(3) 日曜		(4)特殊日1		(5)特殊日2		(6)特殊日3		(7)特殊日4		
	切替 番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号	時	分	ハタ ン番号
	1	6	00	1	6	00	1	6	00	1						
	2	7	00	2	7	00	2	8	00	2						
	3	18	00	1	18	00	1	18	00	1						
	4															
	5															
	6															
	7															
	8															
9																
A																
動 作 切 替	リコール	00:00～00:00		00:00～00:00		00:00～00:00										
系 統 動 作 定 数	同期点															
	追従幅															
	追従階梯秒数配分															
	主現示追従階梯															
	従現示追従階梯															
	時刻修正				○(GPS)											
	連動子機機能定数															
	DC方式															
	AC方式															
	同期階梯1(B/Y1)															
同期階梯2(A/Y2)																
分 周 期 連 動 機 能 定 数	周期監視時間															
	共通オフセット1															
	共通オフセット2															
	連動親機															
	実行しきい値															
	連動パターン															
交通弱者感応定数																
感応階梯																
補正階梯																
倍率指定 (10～19)																
弱者用保証青時間(0～99)																
秒																
ギ ャ ッ プ 感 応 定 数	単位1								単位2							
	短縮		延長		単位青		単位青		短縮		延長		単位青		単位青	
	Ts		Te		上り0.1秒		下り0.1秒		Ts		Te		上り0.1秒		下り0.1秒	
	P1								P1							
	P2								P2							
	P3								P3							
	P4								P4							
	P5								P5							
	P6								P6							
	P7								P7							
P8								P8								
P9								P9								
PA								PA								
感応階梯								感応階梯								
リ コ ー ル 定 数	感応階梯		1		ステップ											
	補正階梯				ステップ											
	感知器指定		押ボタン		PB1		車両		D1							
	押ボタン受付禁止階梯								開始		6		終了		6	
	車両リコール受付禁止階梯								開始		6		終了		8	
	特殊日(プロ多)															
	平日(1)															
	土曜(2)															
	休日(3)															
	毎年(55)															
設定変更履歴																
年月日		変更内容														
2014年3月30日		制御機新設														

備考
地点感応制御機の場合左記の
ギャップ感応定数表の内容は
下記の通りです。

短縮 Ts → ありません。
延長 Te → 限度青です。
単位青 上り → 単位青です。
単位青 下り → ありません。
単位青秒数は0.5秒単位です。

規制番号	09-0108
名称	吉舎インター入口