

Intelligent Function Module
Start I/O:0000 QD77MS4 Simple Motion Module
Parameter

09-07-2026

Item	Axis #1	Axis #2	Axis #3
Basic parameters 1	Set according to the machine and applicable motor when system is		
Pr.1:Unit setting	0:mm	0:mm	0:mm
Pr.2:Number of pulses per rotation	4194304 pulse	4194304 pulse	4194304 pulse
Pr.3:Movement amount per rotation	2500.0 μm	4000.0 μm	4000.0 μm
Pr.4:Unit magnification	1:x1 Times	1:x1 Times	1:x1 Times
Pr.7:Bias speed at start	0.00 mm/min	0.00 mm/min	0.00 mm/min
Basic parameters 2	Set according to the machine and applicable motor when system is		
Pr.8:Speed limit value	20000.00 mm/min	10000.00 mm/min	10000.00 mm/min
Pr.9:Acceleration time 0	1000 ms	1000 ms	1000 ms
Pr.10:Deceleration time 0	1000 ms	1000 ms	1000 ms
Detailed parameters 1	Set according to the system configuration when the system is sta		
Pr.11:Backlash compensation amount	0.0 μm	0.0 μm	0.0 μm
Pr.12:Software stroke limit upper limit value	214748364.7 μm	214748364.7 μm	214748364.7 μm
Pr.13:Software stroke limit lower limit value	-214748364.8 μm	-214748364.8 μm	-214748364.8 μm
Pr.14:Software stroke limit selection	0:Apply Software Stroke Limit on Feed Current Value	0:Apply Software Stroke Limit on Feed Current Value	0:Apply Software Stroke Limit on Feed Current Value
Pr.15:Software stroke limit valid/invalid setting	0:Valid	0:Valid	0:Valid
Pr.16:Command in-position width	10.0 μm	10.0 μm	10.0 μm
Pr.17:Torque limit setting value	300 %	300 %	300 %
Pr.18:M-code ON signal output timing	0:WITH Mode	0:WITH Mode	0:WITH Mode
Pr.19:Speed switching mode	0:Standard Speed Switching Mode	0:Standard Speed Switching Mode	0:Standard Speed Switching Mode
Pr.20:Interpolation speed designation method	0:Vector Speed	0:Vector Speed	0:Vector Speed
Pr.21:Feed current value during speed control	0:Not Update of Feed Current Value	0:Not Update of Feed Current Value	0:Not Update of Feed Current Value
Pr.22:Input signal logic selection : Lower limit	0:Negative Logic	0:Negative Logic	0:Negative Logic
Pr.22:Input signal logic selection : Upper limit	0:Negative Logic	0:Negative Logic	0:Negative Logic
Pr.22:Input signal logic selection : Stop signal	0:Negative Logic	0:Negative Logic	0:Negative Logic
Pr.22:Input signal logic selection : External command/switching signal	0:Negative Logic	0:Negative Logic	0:Negative Logic
Pr.22:Input signal logic selection : Proximity dog signal	0:Negative Logic	0:Negative Logic	0:Negative Logic
Pr.22:Input signal logic selection : Manual pulse generator input	0:Negative Logic		
Pr.80:External input signal selection	2:Buffer Memory of QD77MS	2:Buffer Memory of QD77MS	2:Buffer Memory of QD77MS
Pr.24:Manual pulse generator/Incremental Sync. ENC input selection	0:A-phase/B-phase Mode (4 Multiply)		
Pr.81:Speed-position function selection	0:Speed-position Switching Control (INC Mode)	0:Speed-position Switching Control (INC Mode)	0:Speed-position Switching Control (INC Mode)
Pr.82:Forced stop valid/invalid selectio	1:Invalid		

Intelligent Function Module
Start I/O:0000 QD77MS4 Simple Motion Module
Parameter

09-07-2026

Item	Axis #1	Axis #2	Axis #3
Detailed parameters 2	Set according to the system configuration when the system is sta		
Pr.25:Acceleration time 1	1000 ms	1000 ms	1000 ms
Pr.26:Acceleration time 2	1000 ms	1000 ms	1000 ms
Pr.27:Acceleration time 3	1000 ms	1000 ms	1000 ms
Pr.28:Deceleration time 1	1000 ms	1000 ms	1000 ms
Pr.29:Deceleration time 2	1000 ms	1000 ms	1000 ms
Pr.30:Deceleration time 3	1000 ms	1000 ms	1000 ms
Pr.31:JOG speed limit value	10000.00 mm/min	5000.00 mm/min	5000.00 mm/min
Pr.32:JOG operation acceleration time selection	0:1000	0:1000	0:1000
Pr.33:JOG operation deceleration time selection	0:1000	0:1000	0:1000
Pr.34:Acceleration/deceleration process selection	0:Trapezoidal Acceleration/Deceleration Process	0:Trapezoidal Acceleration/Deceleration Process	0:Trapezoidal Acceleration/Deceleration Process
Pr.35:S-curve ratio	100 %	100 %	100 %
Pr.36:Rapid stop deceleration time	1000 ms	1000 ms	1000 ms
Pr.37:Stop group 1 rapid stop selection	0:Normal Deceleration Stop	0:Normal Deceleration Stop	0:Normal Deceleration Stop
Pr.38:Stop group 2 rapid stop selection	0:Normal Deceleration Stop	0:Normal Deceleration Stop	0:Normal Deceleration Stop
Pr.39:Stop group 3 rapid stop selection	0:Normal Deceleration Stop	0:Normal Deceleration Stop	0:Normal Deceleration Stop
Pr.40:Positioning complete signal output time	300 ms	300 ms	300 ms
Pr.41:Allowable circular interpolation error width	10.0 μ m	10.0 μ m	10.0 μ m
Pr.42:External command function selection	0:External Positioning Start	0:External Positioning Start	0:External Positioning Start
Pr.83:Speed control 10x multiplier setting for degree axis	0:Invalid	0:Invalid	0:Invalid
Pr.84:Restart allowable range when servo OFF to ON	0 pulse	0 pulse	0 pulse
Pr.89:Manual pulse generator/Incremental Sync. ENC input type selection	1:Voltage Output/Open Collector Type		
Pr.90:Operation setting for SPD-TRQ Cont. mode : Torque initial value selection	0:Command Torque	0:Command Torque	0:Command Torque
Pr.90:Operation setting for SPD-TRQ Cont. mode : Speed initial value selection	0:Command Speed	0:Command Speed	0:Command Speed
Pr.90:Operation setting for SPD-TRQ Cont. mode : Condition selection at mode switching	0:Switching Conditions Valid at Mode Switching	0:Switching Conditions Valid at Mode Switching	0:Switching Conditions Valid at Mode Switching
HPR basic parameters	Set the values required for carrying out HPR control (Valid when t		
Pr.43:HPR method	5:Count Method (2)	5:Count Method (2)	5:Count Method (2)
Pr.44:HPR direction	1:Reverse Direction (Address Decrease Direction)	1:Reverse Direction (Address Decrease Direction)	1:Reverse Direction (Address Decrease Direction)
Pr.45:HP address	0.0 μ m	0.0 μ m	0.0 μ m
Pr.46:HPR speed	1000.00 mm/min	1000.00 mm/min	1000.00 mm/min

Intelligent Function Module
Start I/O:0000 QD77MS4 Simple Motion Module
Parameter

09-07-2026

Item	Axis #1	Axis #2	Axis #3
Pr.47:Creep speed	500.00 mm/min	500.00 mm/min	500.00 mm/min
Pr.48:HPR retry	0:Do Not Retry HPR with Limit Switch	0:Do Not Retry HPR with Limit Switch	0:Do Not Retry HPR with Limit Switch
[-] HPR detailed parameters	Set the values required for carrying out HPR control (Valid when t		
Pr.50:Setting for the movement amount after proximity dog ON	250.0 μm	1000.0 μm	1000.0 μm
Pr.51:HPR acceleration time selection	0:1000	0:1000	0:1000
Pr.52:HPR deceleration time selection	0:1000	0:1000	0:1000
Pr.53:HP shift amount	0.0 μm	0.0 μm	0.0 μm
Pr.54:HPR torque limit value	300 %	300 %	300 %
Pr.55:Operation setting for incompleteness of HPR	0:Positioning Control is Not Executed	0:Positioning Control is Not Executed	0:Positioning Control is Not Executed
Pr.56:Speed designation during HP shi	0:HPR Speed	0:HPR Speed	0:HPR Speed
Pr.57:Dwell time during HPR retry	0 ms	0 ms	0 ms
Pr.86:Pulse conversion unit : HPR request setting	0:Turn HPR Request ON at Servo OFF	0:Turn HPR Request ON at Servo OFF	0:Turn HPR Request ON at Servo OFF
Pr.87:Pulse conversion unit : Waiting time after clear signal output	0 ms	0 ms	0 ms
[-] Expansion parameters	Set according to the system configuration when the system is sta		
Pr.91:Optional data monitor : Data type setting 1	0:No Setting	0:No Setting	0:No Setting
Pr.92:Optional data monitor : Data type setting 2	0:No Setting	0:No Setting	0:No Setting
Pr.93:Optional data monitor : Data type setting 3	0:No Setting	0:No Setting	0:No Setting
Pr.94:Optional data monitor : Data type setting 4	0:No Setting	0:No Setting	0:No Setting
Pr.96:Operation cycle setting	0:0.88ms		
Pr.97:SSCNET Setting	1:SSCNET III/H		
Pr.114:External command signal compensation valid/invalid setting	0:Invalid		
Pr.135:Position command error check threshold	0 (Default Value)	0 (Default Value)	0 (Default Value)
Pr.136:Deviation counter error check threshold	0 (Default Value)	0 (Default Value)	0 (Default Value)