Launch Control XL 3 — Rumble Lab (lab/stems)

Seven rumble candidates for the continuum, all on A. Pull up the reference kick (column 8), then one rumble at a time; solo with button 1.

Column 8, button 1 chooses the 16ths of every beat the tonal rumbles (1-5) play on: 3+4, 2+4, 3 or 4. The noises (6, 7) breathe on their own.

The status box at the bottom right shows every value with units.

Knob Fader Button unused

Mode 16 — Rumble Lab

	1 Reverb rumble (008)	2 Dry sine hits	3 Driven cloud	4 Delay rumble	5 Rolling saw	6 Noise pump (house)	7 Sea (ambient)	8 Reference + pattern
Row 1	CC 13 **Brightness** 150 Hz–1.8 kHz low-pass: warm rumble ↔ more of the kick's body.	CC 14 **Length** 50–300 ms: short = a tight bounce, long = almost a bassline.	CC 15 **Drive** 0–0.9: from warm to gritty.	CC 16 **Feedback** 0.2–0.75: how many echoes roll after each hit.	CC 17 **Brightness** 100 Hz–1.2 kHz low-pass.	CC 18 **Pump** 0–1: how deep the noise ducks under the kick.	CC 19 **Wave length** short swells ↔ long, slow waves.	CC 20 —
Row 2	CC 21 **Reverb** 0.4–1: short ↔ a long dark cloud (the reverb is the sound).	CC 22 **Tone** 0–1: a triangle on top, audible on small speakers.	CC 23 **Brightness** 100 Hz–1 kHz low-pass after the drive.	CC 24 **Brightness** 120 Hz–1.2 kHz low-pass.	CC 25 **Envelope** 0–4: the filter snaps open on every hit (a “dow”).	CC 26 **Brightness** 1–12 kHz low-pass.	CC 27 **Brightness** 300 Hz–6 kHz low-pass: deep roar ↔ hissing surf.	CC 28 —
Row 3	CC 29 **Length** 0.15–0.6 s per hit.	CC 30 **Punch** 0–12 semitones pitch drop per hit.	CC 31 **Reverb** 0.3–1.	CC 32 **Echo time** a 16th ↔ a dotted 8th.	CC 33 **Length** 60–300 ms.	CC 34 **Low cut** 200 Hz–3 kHz high-pass: thin hiss ↔ full noise.	CC 35 **Space** 0–1 reverb.	CC 36 —
Fader Level	CC 5 **Level** 008's rumble: a sine kick on A1 + a little 909, low-passed into a big reverb.	CC 6 **Level** short sine hits on A1, no reverb: the tightest rumble.	CC 7 **Level** the reverb rumble, driven: a dark, grainy cloud (Berlin techno).	CC 8 **Level** one hit per beat (the first chosen 16th) that echoes on: rolls by itself.	CC 9 **Level** a saw on A1 through a filter: the rolling bass-rumble of techno.	CC 10 **Level** 010's atmo: noise that swells after every kick, like a sidechain.	CC 11 **Level** 007's sea: brown-noise waves rolling in, each with its own length.	CC 12 **Reference kick** a dry 909 on every beat, so you hear the rumble between the kicks.
Buttons 1	CC 37 **Solo** only this rumble; press again = all.	CC 38 **Solo** only this rumble; press again = all.	CC 39 **Solo** only this rumble; press again = all.	CC 40 **Solo** only this rumble; press again = all.	CC 41 **Solo** only this rumble; press again = all.	CC 42 **Solo** only this noise; press again = all.	CC 43 **Solo** only the sea; press again = all.	CC 44 **16ths** 3+4 → 2+4 → 3 → 4 (tonal rumbles 1-5).
Buttons 2	CC 45 **16th echo** on: the hits echo in 16ths (more rolling).	CC 46 **Octave** on: one octave up (A2).	CC 47 **Crush** on: bit reduction, rougher still.	CC 48 **Stereo** on: the hits move left and right.	CC 49 **Resonance** on: a resonant filter, close to acid.	CC 50 **Off-beat breath** on: the swell peaks on the off-beat instead.	CC 51 **Wind** on: whistling gusts through a wandering band on top.	CC 52 **Tempo** 120 → 128 → 140 BPM.

Guide

What a rumble is

A low sound between the kicks, on the same pitch, so kick and rumble feel like one long, rolling instrument. In techno it is often the kick's own reverb, low-passed; in house a noise that swells after every kick (like a sidechain); in ambient the sea.

Which 16ths

3+4 = the rolling standard (008). 2+4 = more motion, almost a gallop. 3 = only the off-beat 16th, sparse and bouncy. 4 = only the last 16th, pulls into the next kick.

What to listen for

Does it still sound like one low end with the kick and the bass, or like a second, muddy layer? Low-pass low and short = tight; more reverb = a dark cloud. Check at the volume you play at: rumble below the kick.