Launch Control XL 3 — House Keys Lab 12 (lab/keys, round 12 for 009: organic feel)

Touch is fixed on every column: brighter accent before gaps (25 %) and, in the overlays, the second rhythm 45 % softer. Each column adds one organic ingredient; shift + the column's fader = how much (0 = none: then all columns sound alike, the comparison). Start: half (column 7: 25 %).

1 touch sway, same in every bar. 2 touch sway, new every bar. 3 broken chord (notes from the bottom, a few ms apart). 4 length sway (some hits shorter, some longer). 5 breathing voicing (lowest note sometimes out, a note on top sometimes in). 6 slow breath (touch rises and falls over 8 bars). 7 accent strength on the fader. 8 all together (1 + 3 + 4 + 6).

Sound: hold any column's button 2 and turn its knobs: 1 = piano → Rhodes, 2 = B3 → M1, 3 = vibraphone → marimba. In Mode 2: faders 1-4 = grand, Rhodes, organ, vibraphone layers; knob 3 above each changes its character; faders 6 and 7 = drums and bass.

Knob Fader Button unused

Mode 16 — Rhythms

	1 Touch sway, same	2 Touch sway, new	3 Broken chord	4 Length sway	5 Breathing voicing	6 Slow breath	7 Accent strength	8 All together
Row 1 Brightness	CC 13 **Brightness** dull ↔ bright (lpf 250 Hz – 12 kHz, a little resonance): the filter sweep; brighter also plays a little harder (±2 dB, a softer attack at the dark end).	CC 14 **Brightness** as 1 Touch sway, same	CC 15 **Brightness** as 1 Touch sway, same	CC 16 **Brightness** as 1 Touch sway, same	CC 17 **Brightness** as 1 Touch sway, same	CC 18 **Brightness** as 1 Touch sway, same	CC 19 **Brightness** as 1 Touch sway, same	CC 20 **Brightness** as 1 Touch sway, same
Row 2 Space	CC 21 **Space** 0 = dry; a 1/8 echo is there from the first turn (full at half), from about a third on the room joins (full at the top).	CC 22 **Space** as 1 Touch sway, same	CC 23 **Space** as 1 Touch sway, same	CC 24 **Space** as 1 Touch sway, same	CC 25 **Space** as 1 Touch sway, same	CC 26 **Space** as 1 Touch sway, same	CC 27 **Space** as 1 Touch sway, same	CC 28 **Space** as 1 Touch sway, same
Row 3 Length	CC 29 **Length** 0 = short stab ↔ hits ring four times longer.	CC 30 **Length** as 1 Touch sway, same	CC 31 **Length** as 1 Touch sway, same	CC 32 **Length** as 1 Touch sway, same	CC 33 **Length** as 1 Touch sway, same	CC 34 **Length** as 1 Touch sway, same	CC 35 **Length** as 1 Touch sway, same	CC 36 **Length** as 1 Touch sway, same
Fader Level	CC 5 **Level** touch sway: each hit a little harder or softer (up to ±4 dB), the same in every bar.	CC 6 **Level** touch sway, new in every bar.	CC 7 **Level** broken chord: the notes from the bottom up, up to 12 ms apart.	CC 8 **Level** length sway: some hits shorter, some longer (up to ×½ … ×2), the same in every bar.	CC 9 **Level** breathing voicing: lowest note sometimes out, the next chord tone on top sometimes in (fixed).	CC 10 **Level** slow breath: the touch rises and falls over 8 bars (up to ±3 dB).	CC 11 **Level** accent strength: the shift fader is the accent itself (0 = all equal, 25 % = default).	CC 12 **Level** all together: touch sway (same), broken chord, length sway, slow breath.
Button 1 Change	CC 37 **Change** 8 patterns: chain → shifted chain → pairs → 3-3-2 → Kerri syncope → Kerri riff → chain + shifted chain → chain + pairs.	CC 38 **Change** as 1 Touch sway, same	CC 39 **Change** as 1 Touch sway, same	CC 40 **Change** as 1 Touch sway, same	CC 41 **Change** as 1 Touch sway, same	CC 42 **Change** as 1 Touch sway, same	CC 43 **Change** as 1 Touch sway, same	CC 44 **Change** as 1 Touch sway, same
Button 2 Shift	CC 45 **Shift** press = on / off: the 3 knobs mix the sound (piano → Rhodes, B3 → M1, vibraphone → marimba); the fader = how much of the column's organic ingredient (0 = none).	CC 46 **Shift** as 1 Touch sway, same	CC 47 **Shift** as 1 Touch sway, same	CC 48 **Shift** as 1 Touch sway, same	CC 49 **Shift** as 1 Touch sway, same	CC 50 **Shift** as 1 Touch sway, same	CC 51 **Shift** as 1 Touch sway, same	CC 52 **Shift** as 1 Touch sway, same

Mode 2 — Sound + global

	1 Grand	2 Rhodes	3 Organ	4 Vibraphone	5	6 Drums	7 Bass	8
Row 1	CC 61 —	CC 62 —	CC 63 —	CC 64 —	CC 65 —	CC 66 **Swing** 50 % straight ↔ 70 %; 55–58 % = house.	CC 67 —	CC 68 —
Row 2	CC 69 —	CC 70 —	CC 71 —	CC 72 —	CC 73 —	CC 74 —	CC 75 —	CC 76 —
Row 3	CC 77 **M1** 0 = plain grand ↔ the 90s house piano (detuned, e-piano octave, a little grit).	CC 78 **Phaser** 0 = plain ↔ slow, deep phaser swirl.	CC 79 **M1** 0 = B3 ↔ M1, blended at equal loudness.	CC 80 **Marimba** 0 = vibraphone ↔ woody marimba, blended at equal loudness.	CC 81 —	CC 82 —	CC 83 —	CC 84 —
Fader Level	CC 53 **Grand** layer level: dry grand piano.	CC 54 **Rhodes** layer level: warm electric piano.	CC 55 **Organ** layer level: B3 and M1 organ.	CC 56 **Vibraphone** layer level: soft, jazzy mallets.	CC 57 —	CC 58 **Drums** 909 kick, off-beat hat, clap, shaker.	CC 59 **Bass** off-beat bass on the chord root.	CC 60 —
Buttons 1	CC 85 —	CC 86 —	CC 87 —	CC 88 —	CC 89 —	CC 90 —	CC 91 —	CC 92 —
Buttons 2	CC 93 —	CC 94 —	CC 95 —	CC 96 —	CC 97 —	CC 98 **Drums out** keys and bass alone while held.	CC 99 —	CC 100 —

Guide

What to listen for

Does it sound played rather than programmed, without losing the groove? Does the loop still feel like the same loop (house lives on repetition)? Which ingredient makes the biggest difference at the smallest fader position? Note per column: keep / drop, and the fader position you like. The ones you keep become one organic fader.

Why off the kick

Stab rhythms that avoid the kick and sit on the off-16ths pull against the beat; hits on the kick double it and sound like a band. Two hits and 3-3-2 do start on the one: that is their weight.

Harmony

One chord only: Am9 in Kerri Chandler's shape (the 7th at the bottom, the 9 instead of the root). Chord changes have their own board: house-harmony-lab.