Launch Control XL 3 — FX Lab 1 (lab/fx, round 1 for 009: transitions (column 6) and texture (column 7))

Fill + crash every 8 bars, filter downer and high-pass to the drop on everything (held), dub siren and build (held), vinyl crackle (synthetic or real).

Mode 2: fader 6 = drums (knob 1 = swing, button 2 = drums out), fader 7 = bass, fader 8 = keys of 009; column 5 button 1 = harmony.

Knob | Fader | Button | unused

Mode 16 — Candidates

	1 Fill + crash	2 Filter downer	3 High-pass drop	4 Dub siren	5 Build	6 Vinyl	7	8
Row 1 Brightness	CC 13 **Brightness** dull ↔ bright.	CC 14 —	CC 15 —	CC 16 **Brightness** dark ↔ bright siren.	CC 17 **Brightness** dull ↔ bright.	CC 18 **Brightness** dull ↔ bright crackle.	CC 19 —	CC 20 —
Row 2 Space	CC 21 **Space** dry ↔ echo and room.	CC 22 —	CC 23 —	CC 24 **Space** more echo and room.	CC 25 **Space** dry ↔ echo and room.	CC 26 **Space** dry ↔ room.	CC 27 —	CC 28 —
Row 3 Character	CC 29 **Length** crash and toms shorter ↔ longer.	CC 30 **Wobble** LFO on the falling cutoff: none ↔ deep, in quarter notes.	CC 31 **Top** how high the high-pass climbs: 300 Hz ↔ 3 kHz.	CC 32 **Rise** each note rises a little ↔ an octave.	CC 33 **Length** shorter ↔ longer hits.	CC 34 **Density** few clicks ↔ many.	CC 35 —	CC 36 —
Fader Level	CC 5 **Level** toms and crash.	CC 6 **Depth** how far the low-pass falls (0 = off, 1 = down to ~250 Hz).	CC 7 **Depth** 0 = off, 1 = the full climb.	CC 8 **Level** dub siren.	CC 9 **Level** build.	CC 10 **Level** vinyl texture (keep it low).	CC 11 —	CC 12 —
Button 1 Change	CC 37 **Change** every 8 bars → every 4 bars → crash only, next bar.	CC 38 **Change** falls over 1 → 2 → 4 bars, next bar.	CC 39 **Change** climbs over 1 → 2 → 4 bars, next bar.	CC 40 **Change** quarter notes → 8ths → half notes, next bar.	CC 41 **Change** snare ramp → noise riser → both, next bar.	CC 42 **Change** synthetic crackle → real record → both, next bar.	CC 43 —	CC 44 —
Button 2 Moment	CC 45 **Fill now** a tom fill in every bar while held.	CC 46 **Downer** held: the low-pass falls on everything; released = open.	CC 47 **To the drop** held: the high-pass climbs; release = the drop.	CC 48 **Siren** sounds while held.	CC 49 **Build** grows over 2 bars while held.	CC 50 **Echo throw** held: long dotted-8th echo.	CC 51 —	CC 52 —

Mode 2 — Context

	1	2	3	4	5 Harmony	6 Drums	7 Bass	8 Keys
Row 1	CC 61 —	CC 62 —	CC 63 —	CC 64 —	CC 65 —	CC 66 **Swing** 50 % straight ↔ 70 %; 55–58 % = house.	CC 67 —	CC 68 —
Row 2	CC 69 —	CC 70 —	CC 71 —	CC 72 —	CC 73 —	CC 74 —	CC 75 —	CC 76 —
Row 3	CC 77 —	CC 78 —	CC 79 —	CC 80 —	CC 81 —	CC 82 —	CC 83 —	CC 84 —
Fader Level	CC 53 —	CC 54 —	CC 55 —	CC 56 —	CC 57 —	CC 58 **Drums** 909 kick, off-beat hat, clap, shaker.	CC 59 **Bass** off-beat bass on the chord root.	CC 60 **Keys** the keys of 009 (Steinway + Rhodes, chain rhythm), to hear the answers.
Buttons 1	CC 85 —	CC 86 —	CC 87 —	CC 88 —	CC 89 **Harmony** Ein Akkord ↔ Wechsel, at the next 4-bar phrase.	CC 90 —	CC 91 —	CC 92 —
Buttons 2	CC 93 —	CC 94 —	CC 95 —	CC 96 —	CC 97 —	CC 98 **Drums out** FX, keys and bass alone while held.	CC 99 —	CC 100 —

Guide

What to listen for

Which moves sound like deep house and not like EDM? Try 2 and 3 with drums and keys up: they act on everything.

Playing

Hold button 2 on columns 2–5 for the move; columns 2 and 3: the fader = how deep the filter goes.