

CON L3 BOTTLE CODER		240HR PREVENTIVE MAINTENANCE	
Asset Activity:	CON L3 Bottle Coder 240hr PM	Work Order #:	WO-FINAL-001
Machine ID:	BOTTLECODER-L3	Actual Start Date:	_____
Interval:	240 Operating Hours	Actual End Date:	_____
Team Member(s):	Ahmed Khan	Machine Hours:	_____
Generated:	07 May 2026 19:10 UTC	Comments:	_____

RUNNING TASKS					
TASK #	AREA	ACTION	DESCRIPTION	INITIAL	DONE ■
30	BOTTLE CODER	CHECK	CHECK BOTTLE IS PRINTING CORRECT MESSAGE FORMAT: XXDDMMYY HHMM â€” SAMPLE MINIMUM 5 CONSECUTIVE BOTTLES â€” COMPARE AGAINST CURRENT BATCH SPECIFICATION BEFORE POWERING DOWN FOR SERVICE		■
40	BOTTLE CODER	VERIFY	VERIFY CORRECT PLANT LINE NUMBER FORMAT IS PRINTED ON EACH BOTTLE â€” CONFIRM LINE NUMBER MATCHES PRODUCTION SCHEDULE â€” PHOTOGRAPH SAMPLE FOR RECORD		■
50	BOTTLE CODER	VERIFY	VERIFY BEST BY DATE FORMAT: DDMMYYYYY â€” COMPARE WITH CURRENT BATCH RECORDS AND PRODUCTION ORDER â€” ESCALATE ANY DISCREPANCY BEFORE PROCEEDING WITH PM		■

STOPPED TASKS					
TASK #	AREA	ACTION	DESCRIPTION	INITIAL	DONE ■
10	SAFETY	LOCKOUT	LOCK OUT AND TAG OUT THE LASER CODER MACHINE â€” APPLY LOTO DEVICE TO CODER MAIN POWER DISCONNECT â€” VERIFY MACHINE IS FULLY POWERED DOWN BEFORE PROCEEDING		■
20	SAFETY	CONFIRM	RE-CHECK ALL EMERGENCY STOP SWITCHES AND CONTROLS ARE CORRECTLY POSITIONED, OPERATIONAL AND ACCESSIBLE â€” DOCUMENT E-STOP LOCATIONS IN PM RECORD		■
60	SAFETY	LOCKOUT	ENTER PASSWORD DLI ON CODER CONTROL PANEL TO ACCESS MAINTENANCE MODE â€” CONFIRM MAINTENANCE MODE IS ACTIVE ON DISPLAY BEFORE PROCEEDING		■
70	SAFETY	LOCKOUT	DISABLE HEAD A ON CODER CONTROL PANEL â€” NAVIGATE TO HEAD CONTROL MENU â€” SELECT HEAD A â€” SELECT DISABLE â€” CONFIRM HEAD A SHOWS DISABLED STATUS ON DISPLAY		■
80	SAFETY	LOCKOUT	TURN DC POWER KEY SWITCH TO THE OFF POSITION â€” REMOVE KEY AND RETAIN IN SAFE LOCATION â€” VERIFY CONTROL PANEL SCREEN HAS GONE DARK		■
90	SAFETY	LOCKOUT	DEPRESS RED POWER BUTTON TO FULLY POWER DOWN CODER ELECTRONICS â€” VERIFY ALL STATUS LIGHTS ON CONTROL PANEL ARE EXTINGUISHED		■
100	SAFETY	LOCKOUT	DEPRESS EMERGENCY STOP BUTTON AND VERIFY MACHINE IS COMPLETELY POWERED DOWN â€” APPLY LOTO HASP AND PERSONAL DANGER TAG â€” VERIFY ZERO ENERGY BEFORE OPENING ANY PANEL		■
110	BOTTLE CODER	CHECK	INSPECT ALL EXTERNAL CODER CABLES FOR DAMAGE, FRAYING, CUTS OR SIGNS OF HEAT DAMAGE â€” PAY ATTENTION TO CABLE ENTRY POINTS AND AREAS SUBJECT TO MOVEMENT OR VIBRATION		■
120	BOTTLE CODER	CHECK	OPEN REAR ACCESS DOOR â€” INSPECT ALL INTERNAL CABLE CONNECTIONS AND CIRCUIT BOARD CONNECTORS â€” VERIFY NONE ARE LOOSE, CORRODED OR DAMAGED â€” RESEAT ANY LOOSE CONNECTORS		■
130	BOTTLE CODER	CHECK	CHECK AIR LINE SUPPLY TO LASER HEAD â€” VERIFY PRESSURE IS CORRECT AND WITHIN SPECIFICATION â€” CHECK LINE FOR MOISTURE, KINKS OR RESTRICTIONS â€” DRAIN AIR FILTER IF MOISTURE IS PRESENT		■
140	BOTTLE CODER	CHECK	INSPECT LASER HEAD HOUSING FOR CRACKS, IMPACT DAMAGE OR SIGNS OF OVERHEATING â€” CHECK MOUNTING BRACKETS ARE SECURE â€” VERIFY LASER APERTURE WINDOW IS CLEAN AND UNDAMAGED		■

TASK #	AREA	ACTION	DESCRIPTION	INITIAL	DONE ☐
150	CLEAN	CLEAN	CLEAN EXTERIOR OF LASER CODER CABINET AND LASER HEAD HOUSING WITH LINT-FREE CLOTH â€” REMOVE ALL DUST, PRODUCT RESIDUE AND DEBRIS â€” DO NOT USE SOLVENT OR WATER ON ELECTRICAL COMPONENTS		☐
170	FUME EXTR ACTOR	CHECK	CHECK FUME EXTRACTOR OPERATION SCREEN FOR ACTIVE FAULT CODES AND FILTER STATUS INDICATORS â€” RECORD ANY ACTIVE ALARMS IN PM RECORD BEFORE PROCEEDING WITH FILTER INSPECTION		☐
180	FUME EXTR ACTOR	CHECK	CHECK VACUUM LEVEL AT EXTRACTION HOSE NOZZLE USING VACUUM GAUGE â€” VERIFY ADEQUATE SUCTION IS PRESENT â€” RECORD READING IN PM LOG â€” LOW SUCTION INDICATES FILTER BLOCKAGE		☐
250	SAFETY	CONFIRM	REMOVE ALL LOTO DEVICES FROM LASER CODER â€” RESTORE MAIN POWER â€” REINSERT DC POWER KEY AND TURN TO ON POSITION â€” POWER UP CODER USING NORMAL START PROCEDURE		☐
260	SAFETY	CONFIRM	RE-CHECK ALL EMERGENCY STOP SWITCHES AND CONTROLS BEFORE RETURNING CODER TO SERVICE â€” VERIFY EVERY E-STOP IS FUNCTIONAL AND CLEARLY ACCESSIBLE â€” TEST E-STOP TRIP		☐
270	GENERAL	CONFIRM	FOLLOW ALL GMP PROCEDURES FOR RETURN TO SERVICE â€” VERIFY PRINT QUALITY MEETS SPECIFICATION ON FIRST 10 BOTTLES AFTER RESTART â€” CONFIRM CORRECT MESSAGE, DATE AND LINE NUMBER BEFORE AUTHORISING PRODUCTION		☐
280	GENERAL	CONFIRM	COMPLETE AND SIGN PM RECORD â€” RECORD ALL FILTER PART NUMBERS AND QUANTITIES USED IN PARTS LOG â€” SUPERVISOR TO COUNTERSIGN â€” FILE COMPLETED RECORD IN MAINTENANCE HISTORY		☐

POWERED OFF TASKS					
TASK #	AREA	ACTION	DESCRIPTION	INITIAL	DONE ☐
160	FUME EXTR ACTOR	LOCKOUT	LOCK OUT AND TAG OUT THE FUME EXTRACTOR SEPARATELY â€” APPLY LOTO DEVICE TO FUME EXTRACTOR MAIN POWER ISOLATOR â€” NOTE: LASER FUMES ARE HAZARDOUS â€” NEVER BYPASS FUME EXTRACTOR LOTO		☐
190	FUME EXTR ACTOR	LOCKOUT	TURN OFF FUME EXTRACTOR (DPX) USING OPERATING SWITCH â€” WAIT FOR COMPLETE MOTOR AND FAN STOP (MINIMUM 2 MINUTES) BEFORE OPENING FILTER COMPARTMENT â€” NEVER OPEN UNDER POWER		☐
200	FUME EXTR ACTOR	CHECK	CHECK BOX FILTER ELEMENTS â€” INSPECT FOR SATURATION, CLOGGING OR PHYSICAL DAMAGE â€” REPLACE FILTERS IF DIRTY, DAMAGED OR BEYOND SERVICE LIFE â€” DISPOSE PER HAZARDOUS WASTE PROCEDURE [PART: L011378]		☐
210	FUME EXTR ACTOR	CHECK	CHECK BAG FILTER ELEMENTS â€” INSPECT FOR SATURATION, CLOGGING OR PHYSICAL DAMAGE â€” REPLACE FILTERS IF DIRTY, DAMAGED OR BEYOND SERVICE LIFE â€” DISPOSE PER HAZARDOUS WASTE PROCEDURE [PART: L011362]		☐
220	FUME EXTR ACTOR	CHECK	CHECK VACUUM EXTRACTION HOSE FOR KINKS, CRACKS, HOLES OR LOOSE CONNECTIONS AT BOTH THE CODER HEAD END AND THE EXTRACTOR END â€” REPLACE HOSE IF DAMAGED		☐
230	FUME EXTR ACTOR	CHECK	CHECK FUME EXTRACTOR CABINET HOUSING FOR DAMAGE, LOOSE PANELS, CORROSION OR SIGNS OF HEAT DAMAGE â€” VERIFY ALL VENTILATION OPENINGS ARE UNOBSTRUCTED		☐
240	SAFETY	CONFIRM	RESTORE FUME EXTRACTOR POWER â€” REMOVE ALL LOTO DEVICES FROM FUME EXTRACTOR ONLY â€” RESTART EXTRACTOR AND VERIFY NORMAL OPERATION BEFORE PROCEEDING TO RESTORE CODER POWER		☐

Technician Name:		Supervisor Approval:		Date:	
------------------	-------------	----------------------	-------------	-------	-------------

PARTS / CONSUMABLES REQUIRED						
PART NUMBER	DESCRIPTION	UOM	REQ QTY	ISSUED QTY	PICK LOCATION	MECHANIC INITIAL
L011378	BOX Filter Elements — Fume Extractor	EA				
L011362	BAG Filter Elements — Fume Extractor	EA				

**** END OF REPORT ****

GENERAL — PRIOR TO RETURNING TO SERVICE FOLLOW ALL GMP PROCEDURES

- Remove all LOTO (Lockout/Tagout) devices before returning to service
- Re-check all E-STOP (Emergency Stop) and control switches
- This document must be signed and retained as a maintenance record

Doc-ID: 4a53eba106adae1f | WO: WO-FINAL-001 | Generated: 2026-05-07 19:10 UTC | PM Automation System v1.0