

SCHNEIDER ELEVATOR SERVICE REPORT (SESR)

Date of Preventive Maintenance Service		Equipment Type	
Project Name		Project Number	
Address / Location		Rated Load Capacity / Speed	
Mode of Service Schedule	Monthly ☐	Quarterly ☐	No. of Floors / Openings

SPECIFICATIONS OF TASKS PER AREA	INSPECTION REPORT STATUS / REMARKS		
I. MACHINE ROOM	GOOD CONDITION	NEED TO REPAIR	NEED TO REPLACED
1) Inspect MOTOR running condition, noise, and excessive vibration			
2) Inspect and Measured Wire Rope operational diameter			
3) Check feedback rotary encoder against unnecessary vibration			
4) Inspect main drive secondary pulleys, bearings, and oil rings			
5) Inspect Braking System (Brake Coil, Pads, & linings)			
6) Inspect and Test Governor Safety if normally functioning			
7) Check-up Traction Machine's Oil Gauge (use only Approved oil)			
8) Inspect and Re-tight Machine room bed/ base Bolts and Nuts			
9) Maintain Cleanliness of Machine Room			
II. CONTROL PANEL			
1) Inspect Electrical & Electronic Components (transformer, magnetic contactor, breakers, main board, inverter, etc)			
2) Check Ventilation fan if functional (temp. must be less than 45degree)			
3) Inspect for loose wires, bolts, nuts, terminals fittings			
4) Check and Test Emergency communication system (intercom, alarm indicator, AVR, ELD, etc)			
5) Check if functional additional features such as: Remote Monitoring Device (Computer), CCTV system, Recessed LED Screen, Elevator voice announcer, etc) IF AVAILABLE			
III. HOISTWAY SHAFT COMPONENTS			
1) Ensure alignment, lubricate, and calibrate Door mechanisms, rollers, guide shoes, counterweights, interlocks, cables, safety switches, and related components			
2) Run and Test adjustments of leveling in all Landing Floors (leveling error must not exceed 5mm)			
3) Ensure Entrance sill to its allowable clearances			
4) Inspect and ensure Wire rope degree of tightness and tensions			

5) Check and test compensating chain against vibration while the Elevator Unit is in motion			
6) Check and test; Top & Bottom limit and Terminal switches if functional			
7) Inspect Hoist way wiring cable tray/raceway holders and fixtures			
IV. ELEVATOR CAR (TOP & INSIDE)	GOOD CONDITION	REPAIRED	REPLACED
1) Check and monitor leveling sensors response if acceptable			
2) Inspect and test monitor car door system, door motor, drives and other connected parameters			
3) Check and test landing Gong, overload alarms, and emergency stop button if all functional			
4) Check and test curtain sensors if acceptable on-time			
5) Cleanliness of Car Top			
V. ELEVATOR PIT			
1) Check and monitor spring buffer switch emergency stop switch, and governor switch if all activated			
2) Cleaning of Pit			
VI. OTHERS			
1) Observe Elevator running parameters, acceleration, deceleration, and high-speed running condition if normally functioning			
2) Observe Elevator Door opening, and closing delay if acceptable			
3) Observe Hall, Car button, and Digital indicators if all functional			
4) Check and Test Safety & Emergency Switch if activated (By-pass is not allowed)			

MOTOR PARAMETERS READING

VOLTAGE READING				

Check and confirmed by contractor supervisor/technician:

Name and Signature

Date

Check and confirmed by Owner/Client:

Name and Signature

Date