1 glow plugs relay	27 5V	53 throttle pos	79 <mark>nc</mark>
2 <mark>nc</mark>	28 <mark>nc</mark>	54 <mark>nc</mark>	80 glow plugs lamp
3 (sck)	29 <mark>nc                                   </mark>	55 +12V / ATT	81 <mark>nc</mark>
4 (sda)	30 <mark>nc</mark>	56 <mark>nc</mark>	82 <mark>nc</mark>
5 (a0)	31 turbo pressure	57 oil temp	83 3.3V
6 (cpu reset)	32 H window button	58 coolant temp	84 <mark>nc</mark>
7 (cs)	33 <mark>nc</mark>	59 <mark>nc</mark>	85 <mark>nc</mark>
8 (3.3v)	34 misc 1	60 <mark>nc</mark>	86 <mark>nc</mark>
9 <mark>nc</mark>	35 EGR	61 <mark>nc</mark>	87 <mark>nc</mark>
10 <mark>nc</mark>	36 <mark>nc</mark>	62 <mark>nc</mark>	88 <mark>nc</mark>
11 nc	37 <mark>nc</mark>	63 air temp	89 <mark>nc</mark>
12 heater hi	38 <mark>nc</mark>	64 <mark>nc</mark>	90
13 heater lo	39 DPF start	65 <mark>nc</mark>	91
14 EGT	40 <mark>nc</mark>	66 <mark>Fulel pos</mark>	92 +12V / ignition
15	41 misc 2	67 <mark>nc</mark>	93 <mark>nc</mark>
16	42 turbo solenoid	68 FAN	94 <mark>nc</mark>
17 heated window	43 <mark>nc</mark>	69 idle solenoid	95 <mark>nc</mark>
18	44 <mark>nc</mark>	70 DPF lamp	96
19 heated window	45 <mark>nc</mark>	71 +12V / ignition	97 +12V / ignition
20 <mark>nc</mark>	46	72 <mark>nc</mark>	98 <mark>nc</mark>
21 hall sign	47 <mark>nc</mark>	73 <mark>nc</mark>	99 <mark>nc</mark>
22 hall gnd	48 <mark>nc</mark>	74 <mark>nc</mark>	100
23 <mark>nc</mark>	49 SDA	75 <mark>nc</mark>	101 nc
24 nc	50 SCL	76 gnd	102 nc
25 gnd	51 gnd	77 gnd	103 gnd
26 <mark>nc</mark>	52 <mark>nc</mark>	78 <mark>nc</mark>	104 <mark>nc</mark>