


T-01 Completed-jamb measurement worksheet

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square


Record width and height at top/middle/bottom; jamb thickness, projection, plumb, square, twist, floor, undercut, handing, swing, stop, strike, adjacent trim, baseboard, wall flatness.



Reference edge / story-stick baseline; half-inch ticks

T-02 Master story stick

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Top datum; rail shoulders at 4, 17.5, 21.5, 35.5, 42.5, 52, 56, 67, and 79 inches.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-03 Rail-location story stick

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Transfer shoulders and opening identifiers from the approved master only.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-04 Domino joint centerlines

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Fence 17.5 mm; show-face reference; each joint's first centerline tight.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-05 Wide-rail multiple-tenon layout

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Lock rail centers 1.125, 3.5, 5.875 inches. Bottom rail centers 1.125, 4.0, 7.5, 10.875 inches.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-06 Muntin joint layout

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

6 mm cutter; 20 mm plunge; centers 0.9375 and 2.0625 inches; first tight, second medium.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-07 Domino setup register

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Record cutter, plunge, width, fence, face, edge, test identifier, dry-fit result, and approval.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-08 Domino test-piece worksheet

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Accept hand-pressure seating, closed shoulder, flush faces, intact groove web, and no breakout.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-09 Hinge layout

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Transfer actual 3-1/2-inch brass leaves or existing completed-jamb gains. Verify leaf thickness and screw pilots.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-10 Lock verification worksheet

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square


Record actual backset, body, faceplate, spindle, key/privacy, strike, and screw dimensions.



Reference edge / story-stick baseline; half-inch ticks

T-11 Strike transfer guide

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Transfer from the hanging latch; do not locate from nominal dimensions.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-12 Glue-up clamp map

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Bottom subassembly first; rehearse open time; measure diagonals before final pressure.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-13 Moulding measurement worksheet

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Record casing, backband, reveal, projection, cap/plinth evidence, baseboard, wall, corners, and field-fit lengths.




Reference edge / story-stick baseline; half-inch ticks

Reference face: SHOW FACE | Reference edge: TOP/LEFT | Verify orientation before cutting.

T-14 Final inspection record

DC-1916-001 | Rev. A | Print at 100% / Actual Size



1 inch calibration square

Record reveals, undercut, swing, latch, stop contact, hardware, finish, panel freedom, and date.



Reference edge / story-stick baseline; half-inch ticks