Preventative Maintenance Procedures

Acuity Series Engines

HD2504
Advance

Customer Name: _____

Acuity S/N: _____

Visually inspect for signs of leaking ink at these locations:

1. ☐ Tubing connections at the ink reservoir
2. ☐ Tubing connections at the degassing filters
3. ☐ Tubing connections at the ink bay ink filters
4. ☐ Tubing connections at the ink filter check valves (if modification # 9 is not installed)
5. ☐ Tubing connections at the ink bag couplers
6. ☐ Seals on the ink pumps
7. ☐ Ensure that none of the ink tubes are kinked or pinched.

Visually inspect for signs of leaking coolant at these locations:

1. ☐ Tubing connections in the carriage assembly
2. ☐ Tubing connections at the coolant reservoir assembly
3. ☐ Coolant pump seals
4. ☐ Check for coolant tube chaffing in the IGUS track – refer to Information Bulletin 1071
5. ☐ Flush the coolant system – refer to Information Bulletin 1087
6. ☐ Refill and check the coolant level

Physically check for signs of leaking in the ink vacuum system.

1. ☐ Disable the vacuum pump (unplug connector J325 on the system control pcb)
2. ☐ Record the vacuum change over a 10 minute time period
3. ☐ If the amount is greater than 1 inch of H20 in the ink status window, look for a leak in the system.
4. ☐ Check the ink vacuum system calibration – refer to the Technical Service Manual

Visually inspect the degassing modules

1. ☐ Replace the degassing module(s) if ink can be seen in the .2 micron filter

Visually inspect the UV power cable in the IGUS track

1. ☐ Refer to Information Bulletin 1048

Physically inspect the table vacuum system

1. ☐ Use media to cover all of the table vacuum holes. Close the vacuum bleed valve to achieve maximum vacuum pressure.
2. ☐ Record the vacuum pressure from the table vacuum pressure gauge
3. ☐ If the value reads less than 20 inches / Hg, replace the outer edge foam tape under the table overlay

4. ☐ Use media to cover any individual, custom vacuum zones. Close the vacuum bleed valve to achieve maximum vacuum pressure. Individually check each custom vacuum zone by opening and closing the correct vacuum valve handle
5. ☐ If the value reads less than 20 inches / Hg, replace the inner edge foam tape under the table overlay.
6. ☐ Refer to Information Bulletin 1067A for the correct tape part number
7. ☐ Use loctite to tighten any loose vacuum valve handles

Visually inspect the roll media option media drive couplers

1. ☐ Replace the media drive couplers if cracking or chipping is present

Replace the following .2 micron filters

1. ☐ Purge valves on the carriage assembly
2. ☐ Degassing modules
3. ☐ Purge pump

Clean the following components

1. ☐ Gantry encoder scale
2. ☐ Carriage encoder scale
3. ☐ Carriage bearing rail
4. ☐ Gantry bearing rail
5. ☐ UV lamp housing filters
6. ☐ UV lamp housing quartz glass
7. ☐ AC power enclosure air filters
8. ☐ UV power supply enclosure air filter
9. ☐ Perform the entire daily, weekly and monthly maintenance procedures

Lubricate the following components

1. ☐ Gantry bearing rail (the rail only, not the bearing blocks)
2. ☐ Carriage bearings and rail
3. ☐ Refer to Information Bulletin 1044B

Check and verify the following alignments and adjustments

1. ☐ Carriage height and level
2. ☐ Carriage angle
3. ☐ Print head gantry direction
4. ☐ Bidirectional
5. ☐ Roll media option height and level

6. ☐ Roll media option gimbal bar level

Bleed the ink bay ink filters

1. ☐ Refer to Information Bulletin 1041

Update the operating system firmware

1. ☐ Obtain the latest version from www.oce-dgs.com

Record the following values

2. ☐ Print engine serial number
3. ☐ Roll media option serial number
4. ☐ Firmware version
5. ☐ Date of annual maintenance
6. ☐ Number of manual purges performed (SDS 5-0-09)
7. ☐ Liters of cyan ink used (SDS 5-0-01)
8. ☐ Liters of magenta ink used (SDS 5-0-02)
9. ☐ Liters of yellow ink used (SDS 5-0-03)
10. ☐ Liters of black ink used (SDS 5-0-04)
11. ☐ Liters of white ink used (SDS 5-0-05)
12. ☐ Ink bay ink filter replacement date for cyan (SDS 2-08-01)
13. ☐ Ink bay ink filter replacement date for magenta (SDS 2-08-02)
14. ☐ Ink bay ink filter replacement date for yellow (SDS 2-08-03)
15. ☐ Ink bay ink filter replacement date for black (SDS 2-08-04)
16. ☐ Ink bay ink filter replacement date for white (SDS 2-08-05)
17. ☐ If unsure of these dates ask the customer. If the customer is unsure, ask them to make an estimate the update the SDS system
18. ☐ Square meters printed in flatbed mode (SDS 21-0-07)
19. ☐ Square meters printed in roll mode (SDS 21-0-08)
20. ☐ Total length of roll prints (SDS 21-0-04)
21. ☐ Number of prints made in production mode (SDS 21-0-12)
22. ☐ Number of prints made in quality mode (SDS 21-0-11)
23. ☐ Number of prints made in quality matte mode (SDS 21-0-16)
24. ☐ Number of prints made in quality density mode (SDS 21-0-)
25. ☐ Number of prints made in fine art mode (SDS 21-0-10)
26. ☐ Right UV lamp install date
27. ☐ Right UV lamp hours of operation (SDS 1-8-01)

28. ☐ Right UV lamp number of times lit (SDS 1-8-03)
29. ☐ Left UV lamp install date
30. ☐ Left UV lamp hours of operation (SDS 1-8-02)
31. ☐ Left UV lamp number of times lit (SDS1-8-04)
32. ☐ Number of times the unit has been powered on (SDS 21-0-14)
33. ☐ Number of operation hours for the table vacuum (SDS 12-8-01)
34. ☐ Number of operation hours for the print engine (SDS 21-0-15)

Ship Print Quality Verification

1. ☐ Output the ship print and compare it to the ship print that came from the factory

Ensure that the customer has electronic and hard copies of the MSDS sheets for the following consumables:

1. ☐ UV ink
2. ☐ UV flush
3. ☐ Coolant
4. ☐ Adhesion promoters

Technical Response Center

1. ☐ Ensure that the customer knows the 800 359 3854 number
2. ☐ Ensure that the customer knows how navigate the phone prompts for either hardware or software support
3. ☐ Ensure that the customer knows what information to have ready when they initiate a service call

Fujifilm Professional Services

1. ☐ Ensure that the customer is aware of this group and the service that they provide
2. ☐ Ensure that the customer knows how to contact this group to request their services

Oce Support Web Site

1. ☐ Ensure that the customer knows how to access the customer support page
2. ☐ Ensure that the customer knows how to download application bulletins

Notes: