FUJIFILM

Preventative Maintenance Procedures

Javelin Series Engines

Non - GLV

8000, 8000II
8100
8300E, 8300S
8600, 8600HS, 8600E, 8600S, 8600R, 8600Z
6600E, 6600S

GLV

8800I, 8800II, 8800E, 8800S, 8800Z

SAL/MAL

Customer Name: _____

Javelin S/N: _____

Javelin F/W Rev: _____

SAL S/N: _____

MAL S/N: _____

Check the **User Maintenance Error Log.** Note recurring errors and during PM inspect those areas.

1. ☐ Clean the **Plate Input and Exit guides and Rollers** on Path Unit. Clean **Plate Insert Section.**
2. ☐ Clean the **Input and Output Nip Roller** assemblies. Check if Teflon Tape is worn. Teflon Tape can be removed when running LH-PJ.
3. ☐ Clean the **Green Plate Loading Belts.**
4. ☐ Clean and Inspect **Punch Section**. Clean **guides** around punches. Clean **punch dust chute.** If needed, **punches can be cleaned**. Use "**Punch for Cleaning**" function in User Maintenance and Oiled paper to remove aluminum dust.
5. ☐ Check the **springs** on the **Unloading Guide** mounted under punch unit. If broken, replace.
6. ☐ Inspect the **Leading Clamps**. Look for any dislodged rubber. Check/Clean the **Registration Pins** for any abnormality. Check the Operation of the **Hooks**. Make sure they open/close properly with operation of lead clamp. Ensure they do not interfere with plate loading.
7. ☐ Check the **Tail Clamps.** Put the clamps on drum using service mode. Remove and inspect rubber condition. Clean. Check to see if any **springs** are missing or broken.
8. ☐ Clean **Drum.** On some models, you may have to clean **vacuum holes** with long paper clip.
9. ☐ Clean the Drum **Squeegee Roller and Cleaning Roller.**
10. ☐ Check/Clean the **Drum Balance Weights and Groove**. DO NOT add grease.
11. ☐ Clean the **Calibration Sensor.** Also clean the **Recording Head Lens**.
12. ☐ Check the **Recording Head filter element**. Rotate a ¼ turn. Replace if necessary.
13. ☐ Check the **M41 RH compressor**. If it is an older style, you can change **carbon blades** on a yearly basis. If older style one is not functioning, replace with new style Piston Type compressor. Check compressor **filter elements**. Clean or replace.
14. ☐ Clean the **Air Filter** on intake side of machine.
15. ☐ **Wipe down/Vacuum** inside of Javelin where dust or punch debris have built up. Watch for punch chads that have fallen where they should not be.
16. ☐ Run **Laser Calibration.** Check for weak diodes.
17. ☐ Check **Consumable Timers**. Warn customer if something is about to expire. **Reset** timers were applicable.
18. ☐ Confirm **Exposure Settings.**

19. ☐ Check **Focus** for all resolutions customer is using. Check **Zoom** and **Vertical 1x1**

20. ☐ Run **Zero Tint** and **50% tint** on LHPJ. Check Image Quality.

21. ☐ **Update firmware** as needed. Verify customer has a back-up of machine data. If not, then **back-up all data.**

GLV

1. ☐ Record **LD Status** on record sheet provided in Screen class. (Also in Manual)

2. ☐ Check **GLV on/off graphs** and laser power measure.

3. ☐ Review the above numbers. The **Recording Head lens** can be cleaned if numbers need improvement. Clean the outside of this lens. The lens can also be removed and the inside can be cleaned. Care must be used when removing lens. It is sealed tightly and getting it to turn at first will be a bit tricky.

4. ☐ Re-check **LD status, GLV on/off and laser power measure** and confirm numbers are OK.

Chiller

GLV Javelins have a chiller that requires maintenance.

1. ☐ The **Original style** chiller runs **Distilled Water**. This must be drained on a yearly basis and flushed with special cleaning fluid. Once done, reset counter.

2. ☐ **Newer Style Chillers** use the **Blue fluid**. Add/ Replace as necessary. Once changed, reset counter in Service\Init Data\Consumable Timer. Make sure chiller is off when resetting.

3. ☐ Clean **Air Filter** on Chiller. Reset Consumable Timer.

Single Auto Loader

1. ☐ Clean/Lube the **Guide Rails** of Paper Pad and Plate Pad assemblies. Use white Lithium grease, sparingly.

2. ☐ Check/Clean the **Suction Pads** of Paper Pad and Plate Pad assemblies. Replace if necessary.

3. ☐ Clean the **Brown drive rollers**. Clean the **Green cleaning roller**.

4. ☐ Clean the **Transport path** and rollers.

5. ☐ Inspect the **silencer filter** and replace if necessary.

Multi Auto Loader

1. ☐ Use **Cassette Exchange** and operate each cassette.

2. ☐ Make sure **MAL doors** open properly and support each cassette. Check cassette bearings are properly rolling out onto door frames.

3. ☐ **Clean/vacuum** cassettes. Confirm **plate side guide position.**

See the following page for a list of commonly used PM Parts

Notes:

Common PM Parts for Javelin Series

RH Filter Element	70584840-00
RH Compressor Filter Element (In)	100046946V00
RH Compressor Filter Element (Out)	100046505V00
Unloading Guide Springs	70584776-00
Suction Cups Paper Pad	100034127V00
Suction Cups Plate Pad (Main)	100008058V00
Suction Cups Plate Pad (Sub)	100018300V00
Main suction cup has a wider top.	
SAL Filters	70584911-00
SAL Silencers	435545000
Blue Chiller Fluid	100075295V10 (ships ground only)
Chiller Maintenance Kit (Old Style)	DSG10421
Tail Clamp Spring Set	100050325V02

PM Kit Contents

Filter	70516584-02
Compressor Filter	AF10-M5-2

GLV

M41 Turbo Fan Filter	100235812V00