Acuity Install Checklist

- ☐ Check condition of shock & tilt indicators (notify management if indicators are tripped)
- ☐ Remove printer and all accessories from crate (See Crate / Uncrate Procedure in the manual)
- ☐ Place the printer in the final location.
- ☐ Remove packing wrapped around gantry securing the IGUS track to the beam.
- ☐ Remove the foam packing under the Gantry.
- ☐ Remove carriage cover and manually raise the carriage.
- ☐ Remove both red gantry shipping blocks (see Gantry Lock-Down in the manual)
- ☐ Remove the red carriage shipping plate.
- ☐ Move Gantry to the Park position.
- ☐ Move the Carriage to the center of the Gantry.
- ☐ Remove the carriage face packing.
- ☐ Move carriage to the “Park” position.
- ☐ Remove the protective paper from the tabletop.
- ☐ Lower the feet and level the printer (see printer leveling).
- ☐ Place the vacuum box under the printer’s table.
- ☐ Install hose between vacuum box and printer.
- ☐ Reconnect the Tubing between the Vacuum Accumulator "T" and the vacuum sensor.
- ☐ Install the power cables between the vacuum box and printer.
- ☐ Connect the vacuum foot switch to the printer.
- ☐ Mount the monitor on podium.
- ☐ Connect all cables between podium and printer.
- ☐ Install coolant into reservoir.
- ☐ Install ink bags.
- ☐ Power up printer and allow all reservoirs to fill.
- ☐ Enable ink heater.
- ☐ Load paper on table, turn on vacuum, and verify printer level.
- ☐ When ink temp is greater than 40 deg C, perform 3 purges then suction print heads.
- ☐ Run a nozzle print to ensure all nozzles are firing.
- ☐ Confirm Head Height, Carriage Angular Adjustment, Gantry Alignment Adjustment
- ☐ Print the Exercise print 2 or 3 times (available in the special print tab.)
- ☐ Print the ship print to verify print quality is within specification. Save the final version for future reference
- ☐ Back-up the printer registry using SDS 21-6-04. (See Exporting the Registry in TSM)
- ☐ Install ColorGATE or Onyx RIP on computer
- ☐ Configure RIP for Acuity printer
- ☐ From the workflow through the RIP, print the test document *Digital Standard Test File.pdf* with no color management. **Verify print quality over the entire print bed.** (This document is available at the Fuji FTP site in the wide format folder.)
- ☐ Using the Operator training syllabus and the User manuals, teach the operator the machine operations and operator daily/weekly and shutdown maintenance

Technician signature

Customer name / ASTEA Call Number

Fax (630-259-7399) or email this form to you Service Coordinator.