RMO Installation Checklist:

- ☐ Check condition of shock & tilt indicators (notify management if indicators are tripped)
- ☐ Arizona 250 GT Printer Installed
- ☐ Turn off Ink Temp.
- ☐ Remove the RMO crate top, back, and both end covers, leaving the RMO unit on its pallet with the front crate panel attached to the pallet.
- ☐ Remove the RMO side outside covers & Gimbal Covers.
- ☐ Retract RMO leveling and angular adjustment screws.
- ☐ Loosen platen, capstan, and Gimbal mounting screws.
- ☐ Roll the unit in between the gantry beams so it is oriented to the flatbed printer.
- ☐ Adjust the 4 leveling screws until there are 20 threads (1"/25mm) showing above the bracket.
- ☐ Gently lower the RMO unit onto the table support arms.
- ☐ Place the box of media (shipped with the unit) behind dancer.
- ☐ Attach dial indicator to the carriage.
- ☐ Zero Dial gauge to the table 8 vacuum holes back from the Park Side (push down on overlay)
- ☐ Perform RMO Platen Angular Adjustment.
- ☐ Perform RMO Platen Height & Level Adjustment.
- ☐ Perform RMO Gimbal Level Check.
- ☐ Perform RMO Gimbal Level Adjustment
- ☐ Install edge sensor (only after modification bulletin is released)
- ☐ Install interlock cable to bulkhead plate.
- ☐ Install bulkhead plate
- ☐ Install all cabling to printer (dual foot pedal, interlock cable, and RMO data cable)
- ☐ Ensure latest version of printer software is installed.
- ☐ Update SDS parameters
- ☐ Adjust Capstan Brake
- ☐ Adjust Capstan Encoder Sensor
- ☐ Adjust RMO Media Edge Sensor Offset
- ☐ Verify the table level and re-level as necessary.
- ☐ Backup and Export the Registry
- ☐ Cover all topics listed in the Operator training manual with customer.

Technician signature

Customer name / ASTEA Call Number

Fax (630-259-7399) or email this form to you Service Coordinator.

Rev 11/15/2010