Preventative Maintenance Procedures

Violet Saber Series Engines

V/V*x* Manual Load, V/V*x* Semi-Auto Load, V/V*x* Auto Load
V6 Manual Load, V6 Semi-Auto Load, V6 Auto Load
V6e Manual Load, V6e Semi-Auto Load
V8 Manual Load, V8 Semi-Auto Load, V8 Auto Load

Customer Name: _____

Saber S/N: _____

Saber F/W Rev: _____

Review error log (diags/log/display_errors). Note errors happening frequently and during PM you can check this area for abnormalities. After checking errors, reset them.

1. ☐ Clean the **External Optics.** External optics are all optical parts outside of the Optics Base. M1 mirror, M2 mirror, LPD assembly, L6 mirror, Spinner Mirror, and FPD filter lens.
2. ☐ On a yearly basis, clean the **Internal Optics.** These are optical parts inside the Optics base Box. Dust will build up on all mirrors and lenses that are mounted horizontally. Clean these. Clean ND filter wheel. Check for excessive looseness. Loose ND wheel will cause dot variation.
3. ☐ Clean the **RFI box intake grill**. If excessively dirty, you may have to clean the RFI intake fan inside the RFI Box. Excessive dirt may build up on SSB if not cleaned.
4. ☐ Inspect/Clean **Input and Output Roller sections**. Look for belts that have fallen off rollers.
5. ☐ Clean the **Liner Scale and Drive Rail**. Check the **Drive Rail Wiper** and replace if necessary.
6. ☐ Inspect the **Push Bar Pads**. Push bar pads should be removed and tightened to push bar spring. Replacement is recommended on a yearly basis. Push bar pads are easily removed by removing Operator side Push Bar roller plate. This allows you to slightly lift push bar and get pads out. When refitting push bar, make sure it is aligned to Drum Scribes.
7. ☐ Re-Align the **Traverse Ball Cage** and Carriage.
8. ☐ Clean the **Drum.**
9. ☐ Inspect **Vacuum Filter Vanes and Filter.** It has been proven in the field that these vanes last a long time. Inspect on machines that have been running for more than 2 years or are very high volume.
10. ☐ **Punch check.** If punch has run for more than 35,000, than you want to perform FFEI TIS # 13795-00. This may be best done on a separate service call. As a simple check, you can remove the Punch Arm from the Punch Motor and operate by hand. If excessive stress is felt than further punch maintenance may be needed.
11. ☐ With covers back on, run the **MMI Calibration**. Make note of ND numbers before running for comparison.
12. ☐ Run **Focus check** to confirm spinner has not been unseated.
13. ☐ Check **PAT** for filter expiration warnings. Replace or confirm filters are on site.
14. ☐ In service mode, **Load a Plate**. Watch for proper drum loading operation. Check **drum blow**, **plate push** and **drum conformance**. Watch plate punching and centering, if applicable.
15. ☐ Wipe out/Vacuum all **Drum end Caps** and Saber Interior.
16. ☐ Run a **Persistent Image.** Check image quality using the 50% tint.

PTM

1. ☐ Remove **Feed Head.** Clean all feed head rollers and inspect for any paper stuck. Check feed head sensors for any damage from plate feeding.
2. ☐ Clean all **PTM guides** and remove paper dust.
3. ☐ Clean/ Inspect **Retard Pad**. If worn, retard pad can be rotated 180 degrees. Replace if necessary.
4. ☐ Check operation of **Diverter.** Make sure when in down position, it is low enough for proper plate feed.
5. ☐ Load plate. Check for **proper plate and paper feed**

Autoloader

1. ☐ **Cassette**s can be cleaned of paper/plate debris.
2. ☐ Check **plate side guides** for proper position. Over time during plate loading, these guides can move. If excessive **1750** errors on punch machines or **240** errors on non-punch machines, then plates may not be entering drum centered.

See the following page for a list of commonly used PM Parts

Notes:

Common PM Parts for Saber Series

Vacuum Vanes	0722522486
Retard Pad	7A005940
Pat Filter Kit	FSK550

PM Kit Contents

Wiper	7553530
Push Bar Pads	7A06027
Push Bar Spring	7A06449
Vacuum Filter	90950500