

DB11_HMI_out [DB11]

DB11_HMI_out Eigenschaften

Allgemein

Name	DB11_HMI_out	Nummer	11	Typ	DB	Sprache	DB
Nummerierung	Manuell						

Information

Titel		Autor		Kommentar		Familie	
Version	0.1	Anwenderdefinierte ID					

Name	Datentyp	Startwert	Remanenz	Erreichbar aus HMI/OPC UA/Web API	Schreibbar aus HMI/OPC UA/Web API	Sichtbar in HMI Engineering	Einstellwert	Überwachung	Kommentar
▼ Static									
▼ general	Struct		False	True	True	True	False		
speed	Real	0.0	False	True	True	True	False		actual speed [m/min]
calPower	Int	0	False	True	True	True	False		calculated power [%]
NIRwidth	Int	0	False	True	True	True	False		actual NIR width [mm]
NIRno	Int	0	False	True	True	True	False		number of active emitter
Watchdog	Bool	false	False	True	True	True	False		1Hz blink
▼ zone	Array[1..48] of Bool		False	True	True	True	False		emitter zone [on-off]
zone[1]	Bool	false	False	True	True	True	False		emitter zone [on-off]
zone[2]	Bool	false	False	True	True	True	False		emitter zone [on-off]
zone[3]	Bool	false	False	True	True	True	False		emitter zone [on-off]
zone[4]	Bool	false	False	True	True	True	False		emitter zone [on-off]
zone[5]	Bool	false	False	True	True	True	False		emitter zone [on-off]
zone[6]	Bool	false	False	True	True	True	False		emitter zone [on-off]

Totally Integrated Automation Portal										
Name	Datentyp	Startwert	Remanenz	Erreichbar aus HMI/OPC UA/Web API	Schreibbar aus HMI/OPC UA/Web API	Sichtbar in HMI Engineering	Einstellwert	Überwachung	Kommentar	
zone[34]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[35]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[36]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[37]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[38]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[39]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[40]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[41]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[42]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[43]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[44]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[45]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[46]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[47]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
zone[48]	Bool	false	False	True	True	True	False		emitter zone [on-off]	
▼ module	Array[1..2] of "moduleData"		False	True	True	True	False			
▼ module[1]	"moduleData"		False	True	True	True	False			
NIRstatus	Int	0	False	True	True	True	False		NIR Status: 0=off, 1=startup, 2=ready, 3=standby, 4=process, 5=shutdown	
error	Bool	false	False	True	True	True	False		error heater off	
message	Bool	false	False	True	True	True	False		at least one message	
closed	Bool	false	False	True	True	True	False		module closed in docking station	
SuppAirRunning	Bool	false	False	True	True	True	False		support air blower running	
ExhAirRunning	Bool	false	False	True	True	True	False		exhaust air blower running	
EmFailNo	USInt	0	False	True	True	True	False		number of defect emitter	
airPressIn	Real	0.0	False	True	True	True	False		air pressure support air [Pa]	
airPressOut	Real	0.0	False	True	True	True	False		air pressure exhaust air [Pa]	

Totally Integrated Automation Portal										
Name	Datentyp	Startwert	Remanenz	Erreichbar aus HMI/OPC UA/Web API	Schreibbar aus HMI/OPC UA/Web API	Sichtbar in HMI Engineering	Einstellwert	Überwachung	Kommentar	
airFilter	Int	0	False	True	True	True	False		air pressure filter monitoring [Pa]	
actSpeedIn	Int	0	False	True	True	True	False		actual speed support air [0..100%]	
actSpeedOut	Int	0	False	True	True	True	False		actual speed exhaust air [0..100%]	
actPower	Int	0	False	True	True	True	False		actual NIR power [%]	
spare	Int	0	False	True	True	True	False			
spare_1	Int	0	False	True	True	True	False			
spare_2	Int	0	False	True	True	True	False			
spare_3	Int	0	False	True	True	True	False			
spare_4	Int	0	False	True	True	True	False			
spare_5	Int	0	False	True	True	True	False			
▼ module[2]	"moduleData"		False	True	True	True	False			
NIRstatus	Int	0	False	True	True	True	False		NIR Status: 0=off, 1=startup, 2=ready, 3=standby, 4=process, 5=shutdown	
error	Bool	false	False	True	True	True	False		error heater off	
message	Bool	false	False	True	True	True	False		at least one message	
closed	Bool	false	False	True	True	True	False		module closed in docking station	
SuppAirRunning	Bool	false	False	True	True	True	False		support air blower running	
ExhAirRunning	Bool	false	False	True	True	True	False		exhaust air blower running	
EmFailNo	USInt	0	False	True	True	True	False		number of defect emitter	
airPressIn	Real	0.0	False	True	True	True	False		air pressure support air [Pa]	
airPressOut	Real	0.0	False	True	True	True	False		air pressure exhaust air [Pa]	
airFilter	Int	0	False	True	True	True	False		air pressure filter monitoring [Pa]	
actSpeedIn	Int	0	False	True	True	True	False		actual speed support air [0..100%]	
actSpeedOut	Int	0	False	True	True	True	False		actual speed exhaust air [0..100%]	
actPower	Int	0	False	True	True	True	False		actual NIR power [%]	
spare	Int	0	False	True	True	True	False			
spare_1	Int	0	False	True	True	True	False			

Name	Datentyp	Startwert	Remanenz	Erreichbar aus HMI/OPC UA/Web API	Schreibbar aus HMI/OPC UA/Web API	Sichtbar in HMI Engineering	Einstellwert	Überwachung	Kommentar
spare_2	Int	0	False	True	True	True	False		
spare_3	Int	0	False	True	True	True	False		
spare_4	Int	0	False	True	True	True	False		
spare_5	Int	0	False	True	True	True	False		
Software	Int	1	False	True	True	True	False		software version
Hardware	Int	1	False	True	True	True	False		hardware version
interface	Int	1	False	True	True	True	False		interface (OPC-UA)
HMI	Int	1	False	True	True	True	False		HMI version