

CHF



737-300/400/500 TASK CARDS

AIRLINE CARD NO		TITLE STANDBY POWER SYSTEM			BOEING CARD NO. 24-054-00-01								
DATE	TASK OPERATIONAL				RELATED CARD								
TAIL NUMBER	WORK AREA CONTRL CABIN	VERSION 1.1	THRESHOLD 24 HR	REPEAT 24 HR	APPLICABILITY AIRPLANE ALL ENGINE ALL								
STATION	SKILL ELEC	NOTE											
		ACCESS 1103			ZONE 101 102 202								
Operationally check standby power system. INTERVAL NOTE: 24 Elapsed clock-hours A. References <table><thead><tr><th>Reference</th><th>Title</th></tr></thead><tbody><tr><td>AMM 24-22-00 P/B 201</td><td>MANUAL CONTROL - MAINTENANCE PRACTICES (APPLY POWER)</td></tr><tr><td>AMM 49-11-00 P/B 201</td><td>APU POWER PLANT - MAINTENANCE PRACTICES</td></tr><tr><td>AMM 49-21-00 P/B 201</td><td>APU ENGINE - MAINTENANCE PRACTICES</td></tr></tbody></table>						Reference	Title	AMM 24-22-00 P/B 201	MANUAL CONTROL - MAINTENANCE PRACTICES (APPLY POWER)	AMM 49-11-00 P/B 201	APU POWER PLANT - MAINTENANCE PRACTICES	AMM 49-21-00 P/B 201	APU ENGINE - MAINTENANCE PRACTICES
Reference	Title												
AMM 24-22-00 P/B 201	MANUAL CONTROL - MAINTENANCE PRACTICES (APPLY POWER)												
AMM 49-11-00 P/B 201	APU POWER PLANT - MAINTENANCE PRACTICES												
AMM 49-21-00 P/B 201	APU ENGINE - MAINTENANCE PRACTICES												
EFFECTIVITY CHF ALL		SOURCE MRB	STANDBY POWER SYSTEM D6-38278-3C1 24-054-00-01										

CHF



737-300/400/500 TASK CARDS

DATE	TAIL NUMBER	STATION	AIRLINE CARD NO.	BOEING CARD NO. 24-054-00-01	MECH	INSP				
TASK 24-54-00-715-002										
1. Standby Power System - Operational Test										
A. General										
(1) This test uses the GROUND SENSING test switch to put the airplane in the air mode. This makes sure the battery will automatically supply power to the standby buses if the ac buses have no power.										
(2) To get accurate results from this test, the ac generation system (Ref 24-21-00) and the dc generation system (Ref 24-31-00) must operate correctly.										
B. Procedure										
SUBTASK 24-54-00-010-002										
(1) Open this access panel:										
<table><thead><tr><th>Number</th><th>Name/Location</th></tr></thead><tbody><tr><td>1103</td><td>Forward Access Door</td></tr></tbody></table>					Number	Name/Location	1103	Forward Access Door		
Number	Name/Location									
1103	Forward Access Door									
SUBTASK 24-54-00-865-003										
(2) Make sure that the circuit breakers for the dc and standby power systems are closed:										
CHF 001										
(a) The circuit breakers on the J9 panel										
CHF ALL										
(b) The circuit breakers on the P6-4 panel										
(c) The circuit breakers on the P6-5 panel										
(d) The circuit breakers on the P6-6 panel.										
SUBTASK 24-54-00-865-004										
(3) Supply external or APU generator power (AMM PAGEBLOCK 24-22-00/201).										
CHF 001										
SUBTASK 24-54-00-715-005										
(4) Do the Operational Test:										
(a) Turn the dc meters switch on the P5-13 panel to TR3.										
1) Make sure that the dc voltmeter shows 26 ± 4 volts.										
(b) Set the POSITION light switch on the P5 overhead panel to the ON BATT or STEADY position.										
<u>NOTE:</u> The POSITION light switch is located on the lower right of the P5 panel.										
(c) Make sure that the dc ammeter indication increases approximately 5 amperes.										
(d) Push the POSITION switch to the OFF position.										
(e) Make sure that the dc ammeter indication decreases approximately 5 amperes (returns to its original value).										
(f) Turn the dc meters switch to BAT BUS.										
1) Make sure that the dc voltmeter shows approximately the same voltage as for the TR3 position (± 0.5 volt).										
EFFECTIVITY CHF ALL		SOURCE MRB	STANDBY POWER SYSTEM							
			D6-38278-3C1 24-054-00-01							

CHF



737-300/400/500 TASK CARDS

DATE	TAIL NUMBER	STATION	AIRLINE CARD NO.	BOEING CARD NO. 24-054-00-01	
CHF 001 (Continued) (g) Push the STANDBY POWER switch to OFF. 1) Make sure that the STANDBY POWER OFF light comes on. 2) Turn the ac meters switch on the P5-13 panel to STBY PWR. a) Make sure that the ac voltmeter shows no voltage. 3) Turn the dc meters switch to STBY PWR. a) Make sure that the dc voltmeter shows 0-5 volts. (h) Push the STANDBY POWER switch to AUTO. 1) Make sure these indications occur: a) The STANDBY PWR OFF light goes off b) The dc voltmeter shows 26 ± 4 volts c) The ac voltmeter shows 115 ± 5 volts d) The frequency meter shows 400 ± 5 Hz (i) Push the GRD PWR switch or the APU GEN No. 1 and No. 2 switches to OFF. 1) Make sure that the STANDBY PWR OFF light comes on. 2) Turn the dc meters switch to these positions and look for the correct voltages on the dc voltmeter: a) TR3 - 0 volts b) BAT - 24 ± 4 volts c) BAT BUS - approximately the same as for the BAT position (± 0.5 volts) d) STBY PWR - 0 volts 3) Turn the AC meters switch to INV. 4) Make sure that the ac voltmeter shows no voltage. (j) Open the forward access door near the nose landing gear. <u>WARNING:</u> MAKE SURE THAT PERSONS AND EQUIPMENT ARE CLEAR OF THE LEADING EDGE SLATS BEFORE YOU PUT THE AIRPLANE IN THE AIR MODE. THE LEADING EDGE SLATS CAN EXTEND AUTOMATICALLY WHEN YOU PUT THE AIRPLANE IN THE AIR MODE. THIS CAN CAUSE INJURY TO PERSONS AND DAMAGE TO EQUIPMENT. (k) Push and hold the GROUND SENSING test switch on the front panel of the E11 landing gear logic shelf. 1) Make sure these indications occur: a) The STANDBY PWR OFF light goes off. b) The dc voltmeter shows 24 ± 4 volts c) The ac voltmeter shows 115 ± 5 volts d) The frequency meter shows 400 ± 5 Hz (l) Release the GROUND SENSING test switch.				MECH	INSP
EFFECTIVITY CHF ALL	SOURCE MRB	STANDBY POWER SYSTEM D6-38278-3C1 24-054-00-01			

CHF



737-300/400/500 TASK CARDS

DATE	TAIL NUMBER	STATION	AIRLINE CARD NO.	BOEING CARD NO. 24-054-00-01	
CHF 001 (Continued) (m) Close the forward access door. (n) Push the STANDBY POWER switch to BAT. 1) Make sure that the STANDBY PWR OFF light goes off. 2) Make sure that the dc voltmeter shows 24 ± 4 volts. (o) Put the STANDBY POWER switch to OFF. 1) Make sure the STANDBY PWR OFF light is ON. CAUTION: MAKE SURE TO SHUTDOWN THE APU BEFORE YOU SET THE BAT SWITCH TO THE OFF POSITION. DAMAGE TO EQUIPMENT CAN OCCUR. (p) If the APU is used as the power source, Shut down the APU (AMM PAGEBLOCK 49-11-00/201). (q) Put the BAT switch to OFF. 1) Make sure electrical power is removed from the airplane. a) Make sure the STANDBY PWR OFF light is OFF. (r) Put the STANDBY POWER switch to BAT. <u>NOTE:</u> For airplanes with digital P5-13 Electrical Meter, Battery and Galley Power Module P/Ns 69-37321-65/80/81, the required voltages will not be displayed. For these airplanes, make sure the DC BUS PWR ON STBY and AC BUS PWR ON STBY lights on the M238 Annunciator Module located in the P6 panel are ON. 1) Make sure the STANDBY PWR OFF light is OFF. 2) Make sure the DC voltmeter shows 24 +/- 4 volts. 3) Make sure the AC voltmeter shows 115 +/- 5 volts. (s) Put the STANDBY POWER switch to OFF. 1) Make sure the STANDBY PWR OFF light remains OFF. a) Make sure electrical power is removed from the airplane. (t) Put the BAT switch to ON. 1) Make sure the STANDBY PWR OFF light is ON. CHF 002-999 SUBTASK 24-54-00-710-001 (5) AIRPLANES WITH ENERGIZED STANDBY POWER SYSTEM IN THE AIR; Do the Operational Test: (a) Turn the dc meters switch on the P5-13 panel to TR3. 1) Make sure that the dc voltmeter shows 26 ± 4 volts. (b) Push the POSITION switch on the P5 overhead panel to the ON BAT position. <u>NOTE:</u> The POSITION switch is located on the lower right of the P5 panel.				MECH	INSP
EFFECTIVITY CHF ALL	SOURCE MRB	STANDBY POWER SYSTEM D6-38278-3C1 24-054-00-01			

CHF



737-300/400/500 TASK CARDS

DATE	TAIL NUMBER	STATION	AIRLINE CARD NO.	BOEING CARD NO. 24-054-00-01	
CHF 002-999 (Continued) 1) Make sure that the dc ammeter indication increases approximately 5 amperes. (c) Push the POSITION switch to the OFF position. 1) Make sure that the dc ammeter indication decreases approximately 5 amperes (returns to its original value). (d) Turn the dc meters switch to BAT BUS. 1) Make sure that the dc voltmeter shows approximately the same voltage as for the TR3 position (± 0.5 volt). (e) Push the STANDBY POWER switch to OFF. 1) Make sure that the STANDBY POWER OFF light comes on. 2) Turn the ac meters switch on the P5-13 panel to STBY PWR. a) Make sure that the ac voltmeter shows no voltage. 3) Turn the dc meters switch to STBY PWR. a) Make sure that the dc voltmeter shows 0 volts. (f) Push the STANDBY POWER switch to AUTO. 1) Make sure these indications occur: a) The STANDBY PWR OFF light goes off b) The dc voltmeter shows 26 ± 4 volts c) The ac voltmeter shows 115 ± 5 volts d) The frequency meter shows 400 ± 5 Hz (g) Push the GRD PWR switch or the APU GEN No. 1 and No. 2 switches to OFF. 1) Make sure that the STANDBY PWR OFF light comes on. 2) Turn the dc meters switch to these positions and look for the correct voltages on the dc voltmeter: a) TR3 - 0 volts b) BAT - 24 ± 4 volts c) BAT BUS - approximately the same as for the BAT position (± 0.5 volts) d) STBY PWR - 0 volts 3) If the INVERTER VOLTS circuit breaker is installed, turn the AC meters switch to the INV position. a) Make sure that the ac voltmeter shows no voltage. <u>WARNING:</u> MAKE SURE THAT PERSONS AND EQUIPMENT ARE CLEAR OF THE LEADING EDGE SLATS BEFORE YOU PUT THE AIRPLANE IN THE AIR MODE. THE LEADING EDGE SLATS CAN EXTEND AUTOMATICALLY WHEN YOU PUT THE AIRPLANE IN THE AIR MODE. THIS CAN CAUSE INJURY TO PERSONS AND DAMAGE TO EQUIPMENT. (h) Pull CB C18 AIR/GND at P6-3 panel. 1) Make sure these indications occur:				MECH	INSP
EFFECTIVITY CHF ALL	SOURCE MRB	STANDBY POWER SYSTEM D6-38278-3C1 24-054-00-01			

CHF

CHF



737-300/400/500 TASK CARDS

DATE	TAIL NUMBER	STATION	AIRLINE CARD NO.	BOEING CARD NO. 24-054-00-01	
CHF 002-999 (Continued)				MECH	INSP
a) The STANDBY PWR OFF light goes off. b) The dc voltmeter shows 24 ± 4 volts c) The ac voltmeter shows 115 ± 5 volts d) The frequency meter shows 400 ± 5 Hz (i) Push CB C18 AIR/GND at P6-3 panel back. 1) Make sure that the STANDBY POWER OFF light comes on. (j) Push the STANDBY POWER switch to BAT. 1) Make sure that the STANDBY PWR OFF light goes off. 2) Make sure that the dc voltmeter shows 24 ± 4 volts. (k) Put the STANDBY POWER switch to OFF. 1) Make sure the STANDBY PWR OFF light is ON. (l) If the APU is used as the power source, shut down the APU (AMM PAGEBLOCK 49-21-00/201). (m) Put the BAT switch to OFF. 1) Make sure electrical power is removed from the airplane. a) Make sure the STANDBY PWR OFF light is OFF. (n) Put the STANDBY POWER switch to BAT. 1) Make sure the STANDBY PWR OFF light is OFF. 2) Make sure the DC voltmeter shows 24 ± 4 volts. 3) Make sure the AC voltmeter shows 115 ± 5 volts. (o) Put the STANDBY POWER switch to OFF. 1) Make sure the STANDBY PWR OFF light remains OFF. a) Make sure electrical power is removed from the airplane. (p) Put the BAT switch to ON. 1) Make sure the STANDBY PWR OFF light is ON. CHF ALL C. Put the System Back to its Usual Condition SUBTASK 24-54-00-865-006 (1) Push the STANDBY POWER switch to AUTO. SUBTASK 24-54-00-865-007 (2) Push the GRD PWR switch or the APU GEN No. 1 and No. 2 switches to ON. SUBTASK 24-54-00-765-008 (3) Make sure that the battery is fully charged. SUBTASK 24-54-00-865-010 (4) Turn the dc meters switch to TR1.					
EFFECTIVITY CHF ALL		SOURCE MRB	STANDBY POWER SYSTEM		
			D6-38278-3C1 24-054-00-01		

CHF



737-300/400/500 TASK CARDS

DATE	TAIL NUMBER	STATION	AIRLINE CARD NO.	BOEING CARD NO. 24-054-00-01					
SUBTASK 24-54-00-865-011 (5) Remove electrical power if it is not necessary (AMM PAGEBLOCK 24-22-00/201). SUBTASK 24-54-00-410-002 (6) Close this access panel: <table><thead><tr><th><u>Number</u></th><th><u>Name/Location</u></th></tr></thead><tbody><tr><td>1103</td><td>Forward Access Door</td></tr></tbody></table> ————— END OF TASK —————				<u>Number</u>	<u>Name/Location</u>	1103	Forward Access Door	MECH	INSP
				<u>Number</u>	<u>Name/Location</u>				
1103	Forward Access Door								
EFFECTIVITY CHF ALL				SOURCE MRB	STANDBY POWER SYSTEM D6-38278-3C1 24-054-00-01				