Vertuo Next

Price

Standard Next Model

The Standard versions have plastic cup support and available in different colours.

Price = 229.00
Bundle Price with Milk Frother = 299.00
=> Milk Frother: Aeroccino 3

Premium Next Model

The Premium versions have metal cup support.

Price = 249.00
Bundle Price with Milk Frother = 319.00
=> Milk Frother: Aerocinno 3

Deluxe Next Model

The Deluxe versions have a metal cup support and coffee outlet ring. The machine head is also chromed.

Price = 279.00
Bundle Price with Milk Frother = 349.00
=> Milk Frother: Aeroccino 3

Cup Sizes

Espresso	Double Espresso	Gran Lungo	Long Coffee	Alto	Carafe
40 ml Espresso	80 ml Double Espresso	150 ml Gran Lungo	230 ml Long Coffee	355 ml (Alto)	535 ml (Carafe)

There is the possibility of buying one of our Aeroccino Milk Frother alongside the Vertuo machine in order to create the ultimate milk frothing experience. Using a Milk Frother in conjunction with the coffee machine, the following beverages can also be made: Cappuccino, Latte Macchiato, and Hot Foam.

Specifications

- Dimensions (W x D x H): 14.2 x 42.9 x 31.4 cm
- Weight: 4 kg
- Warranty: 1 year
- Removable Water Tank: 1.1 L
- Connected Machines — Ensures software updates
- Heat-Up Time: 15 - 20 sec
- Capsule Container Capacity: 6 - 10 capsules

Premise

Vertuo Next takes the full range of Nespresso coffee styles even further. Choose your favourite among six different cup sizes, from espresso to coffee in carafe. The machine reads the barcode integrated in each capsule to offer you it's hidden treasures at the touch of a button: the aromas, the flavours and most importantly, the crema.

Vertuo Next has many different design options for you, with its multiple colours and chromed accents on Premium and Deluxe versions.

Reprogram Cup Size

The programming is specific to each capsule size. Cup sizes can be preprogrammed from 0.7 oz/20 ml to 17 oz/500 ml. To do this, insert the capsule for which you wish to reprogram the volume, push and hold the button until desired volume is reached. Water volume level is then stored for the capsule size used for the programming.

Factory Reset Instructions

1. Open the machine head and let the used capsule be ejected.
2. Close the head.
3. Leave the handle in "UNLOCKED" position.
4. Push the button 5 times within 3 seconds.
5. The button blinks 5 times orange and then changes to steady white.

First TIme Use Procedure

Be aware of the following.
- CAUTION: First read the important safeguards to avoid risks of fatal electrical shock and fire.
- NOTE: For the best experience, please pair your machine and accept automatic software updates.
- CAUTION: Please ensure ground continuity when plugging the machine in the power outlet.

1. Rinse and clean the water tank and the lid before filling it only with fresh drinking water. Put the water tank in place and make sure it's properly attached.
2. Rinse and clean the water tank and the lid before filling it only with fresh drinking water. Put the water tank in place and make sure it's properly attached.
3. Ensure the capsule container and the cup support (if necessary for the selected cup size) are in place. For your safety, operate the machine only with cup and capsule container in position.
4. Plug in the power cord.
5. For an optimized heating time, close and lock the machine to turn the machine ON. If the machine is already closed and locked, turn the machine ON by pressing the button. NOTE: to close the machine, push down the machine's head and turn the handle left to the lock symbol while maintaining pressure.
6. Light will blink while the machine is heating up. Steady light indicates the machine is ready.
7. Place a container of at least 34 fl oz. / 1 L under the coffee outlet. Make sure no capsule is inserted during the cleaning.
8. Make sure that the machine is still locked. Press the button 3 times within 2 seconds to start cleaning and let the cleaning procedure complete automatically. It will take less than 2 minutes before start of the flow.
9. This operation may take up to 7 minutes. The procedure can be stopped at any time by pushing the button. Once the cleaning is finished, a steady light will appear on the machine. In case you want to resume the cleaning process, push the button again. When interrupting the cleaning procedure, the machine may not stop immediately. Never open the machine during the cleaning procedure.

Descaling

See User Manual or Tutorial video for detailed procedure. You can also use the Nespresso app if your machine is paired. Thanks to the step-by-step procedure, descaling your machine is super easy.

The descaling frequency depends on the machine usage and the water hardness, which varies based on how often coffee is consumed in the household and the water of that particular location. The general rule is every 300 cups of coffee. The most reliable way to ensure that the machine is ready to descale is through the "descaling alert" or by checking the status through the App.

Descaling Alert: The light on the button would be steady white followed by 3x orange blinking and steady white again.

FAQS

- CENTRIFUSION technology is used to gently and fully brew a Carafe, Alto, Mug, Gran Lungo, Double Espresso or Espresso.
- The cable length from the coffee machine to the plug is 75cm.
- The cup support has 2 (or 3) positions, or can be removed to accommodate bigger sizes.
- The machine parts are not dishwasher safe. They can be hand washed with mild soap and water. The external part of the machine can be wiped down with a damp cloth.
- Turn the machine ON by pushing the coffee button or locking/unlocking the lever. Turn the machine OFF by holding the coffee button for 3 seconds.
- In line with our company wide sustainability approach, we seek to minimize the amount of energy required to produce a cup of coffee. Since 2009, all new Nespresso machine ranges

have all been equipped with an energy-saving mode, or an automatic power-off function. The Vertuo Next machine has an auto-off at 2 minutes and an A+ energy rating.
- The Vertuo Next cannot regulate heat. The temperature varies for each blend and cannot be altered. If you would like a warmer coffee, it is recommended to preheat your cup rinsing it in hot water to help maintain the temperature and mix the coffee with the crema once brewed.
- The machine does not require specific cleaning frequency from a hygienic perspective. You may define the best frequency after learning how often you use the machine. A suggestion is to run it after two weeks to observe the cleanliness of the water. You may then decide to increase or decrease the frequency based on your preferences.
- The machine is equipped with a cleaning procedure (see User Manual or tutorial video for detailed procedure). This process takes approximately 5 minutes. The external part of the machine can be wiped down with a damp cloth.
- The classic/original Nespresso capsules cannot be used in the Vertuo machine system. They interact with the systems in different ways. These are two separate lines that will appeal to different types of coffee lovers.

Notes

- The sleek build & design of the Vertuo Next helps if a customer wants to place the machine in more tighter-to-fit spaces in their household.
- The Vertuo Next machine is able to brew Carafe capsules. Carafe capsules are designed for sharing, whereby a single capsule could accommodate 2 to 3 cups of coffee from a single capsule. This is advantageous for larger households, or for customers that regularly have guests over. Officially, only the Vertuo Next machine is able to utilize the Carafe capsules.
- 54% of the machine was created using recycled materials, and thus it is an “Eco-Friendly” machine that matches with Nespresso’s sustainability initiatives.

Helpful Links

Name of Link	URL
Machine Manual	https://www.nespresso.com/shared_res/manuals/vertuo-next/UM_VERTUO_NEXT_Z1_PROD_2019_05_13.pdf
Machine Assistance Vertuo Next	https://www.nespresso.com/ca/en/machine-assistance#!/Vertuo-Next/instructions
YouTube Playlist	https://youtube.com/playlist?list=PLQ2eIUsAVWUyPLLt9Vj2SKNb5JIHJoxe0&feature=shared
Descaling Guide	https://www.nespresso.com/static/us/documents/Vertuo%20Next%20Descaling%20Guide%20FINAL.pdf
Descaling Video	https://youtu.be/QlpirrGK6uU?feature=shared
Factory Reset Instructions	https://www.mymorningespresso.com/how-to-reset-nespresso-machine/#3-vertuo-next

Colour Variations

Standard Next Model

Machine Name	Machine Photo
Vertuo Next - Matte Black	

Vertuo Next

Machine Name	Machine Photo
Vertuo Next - Dark Grey	

Vertuo Next

Machine Name	Machine Photo
Vertuo Next - White	

Premium Next Model

Vertuo Next

Machine Name	Machine Photo
Vertuo Next Premium - Rose Gold	

Vertuo Next

Machine Name	Machine Photo
Vertuo Next Premium - Classic Black	

Deluxe Next Model

Vertuo Next

Machine Link	Machine Photo
Vertuo Next Deluxe - Pure Chrome	