

CHINA SOUTHERN AIRLINES
中国南方航空公司A/C Type
机型

C919

Registration No.
飞机注册号Maint. Station
维修站Work Order No.
工作指令号Workorder Date
工作指令日期Print Date
打印日期

Job Card No. 工卡号

C193405001001-1

Rev. Date 版本日期

2025-11-25 R1

Skill 工种

AVIONICS INSP(RII)
电子必检

Maint. Cat 维修等级

C(RII)

Work Area 工作区域

COCKPIT
驾驶舱

Est. Man-hours 计划工时

4.00 hrs

Station 站位

N/A

Stringer 桁条

N/A

Related Job Card 相关工卡

N/A

JC Seq. No.
顺序号Start Date
开始日期Completion Date
完成日期Act. Man-hours
实际工时

Reference Documents 维修实施依据文件及版次

AMM C919-A-34-46-00-02A-340A-A 2025-11-25

MRS Item No. MRS号

34-05-011

Access Panel 接近盖板

821A

Written/Revised By 编写/修订

丁立彬

2025-12-12

Reviewed By 审核

王书荣

2026-01-06

Approved By 批准

陈世华

2026-01-06

Zone 区域

127 128 130 210 220

JC Title
工卡标题FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM)
功能检查 - 应答机 (RVSM)Mech
机械员CHK/INSP
互检/必检

Special Maintenance Requirement/特殊要求: ALI

Tools & Equipment 工具和设备:

SN 序号	P/N(RF) 件号(参考)	QTY 数量	DESIGNATION 名称	REMARK 备注
1	TR-220	1	Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment ISS测试设备测距仪	- Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A
2	TC-201	1	Antenna Coupler 天线耦合器	- Remark/备注: For TC-201, TC-201A and TC-201B are available. Opt: ZDC-02 - Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A
3	QJSPQ-C9	1	Kit, Adapter - Air Data System Test 大气数据系统测试套装转 接头	- Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A

Aircraft Effectivity 飞机适用范围:

ALL

Page 页码

1 of 26

Job Card 工卡号:		C193405001001-1				
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)				Mech 机械员	CHK/INSP 互检/必检
4	AGE19021	1	RAT stow lock pins RAT收上锁定销	- Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A		
5	No Specific/无特殊要求	As Req/按需	Lock - Circuit Breaker 跳开关锁定夹	- Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A		
6	6341C02-A	1	Tool - Ground Anti heating, Air Data probe 大气数据探头地面防加温工具	- Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A		
7	No Specific/无特殊要求	1	Test Set - Test, Air Data System 大气数据系统测试设备	- Remark/备注: Parameter requirements/参数要求: 1. Height range: -2000 ft~39800ft; 2. Height accuracy range: 15 ft~80 ft; 3. Airspeed range: Maximum 350 kts; 4. Airspeed accuracy range: $\pm 1 \sim \pm 5$ kts; 5. Operating temperature: -10~50 °C; REC P/N推荐件号: Model 6300; ADTS505; ADTS552F; ADSE743; MPS45. - Eff/适用性: ALL - From/来源: C919-A-34-46-00-02A-340A-A		
Parts & Material 部件和航材:						
	Not Required 不需要					
Work Content 工作内容:						
INSPECTION ITEM: ATC TRANSPONDER 检查项目: ATC应答机						
DESCRIPTION: FUNCTIONAL CHECK OF ATC TRANSPONDER (RVSM). 描述: 对应答机进行功能检查(RVSM)。						
ALL						
TASK C919-A-34-46-00-02A-340A-A						
Integrated surveillance system (ATC transponder)-Functional test 综合监视系统(ATC应答机)-功能测试						
Aircraft Effectivity 飞机适用范围: ALL					Page 页码 2 of 26	

Job Card 工卡号:	C193405001001-1		
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
WARNING: PUT SAFETY DEVICES AND WARNING NOTICES NEAR THE RAT DOOR. 警告: OTHERWISE, ACCIDENTAL DEPLOYMENT OF THE RAT CAN CAUSE INJURY TO PERSONNEL. 在RAT舱门附近放置安全装置和警告牌。否则, RAT意外放出可能会造成人员受伤。 1. Procedures 主程序 A. Job Set-Up 工作准备 (1) Remove the protective covers of pitot probe, static port, pitot-static probe, Total Air Temperature (TAT) sensor and the Angle of Attack (AOA) sensor. 拆下皮托管、静压口、全静压管、TAT总温探头和AOA迎角传感器的保护套。 (2) Disconnect the electrical connectors of three Air Data Heating Controller (ADHC) s. 脱开三个ADHC大气数据加热控制器的电插头。 (3) Connect the Tool - Ground Anti heating, Air Data probe(6341C02-A) to the electrical connectors of three ADHC s and set all the switches of the Tool - Ground Anti heating, Air Data probe(6341C02-A) to ON. 将大气数据探头地面防加温工具 (6341C02-A) 连接到三个ADHC的电插头上, 并将大气数据探头地面防加温工具 (6341C02-A) 的所有电门设置为ON。 (4) Make sure that the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) is fully charged and operates normally by doing the built-in test. 通过执行自检, 确保ISS测试设备测距仪 (TR-220) 充满电并正常工作。 (5) Make sure that the directional antenna of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) and the (TSA) are in a line within visual range. 确保ISS测试设备测距仪 (TR-220) 的定向天线和TSA交通监视天线在目视范围内成一条直线。 (6) Make sure that the unwanted materials, especially metal obstacle are removed from the work area. Otherwise, test result may be affected by multi-path effect. 确保从工作区域清除多余的材料, 尤其是金属障碍物。否则, 测试结果可能会受到多路径效应的影响。 (7) Open the Fwd E/E compartment back door 821A . Refer to Fwd E/E equipment compartment back door-Open from outside for access procedure,MPP C919-A-52-43-00-00A-540B-A . 打开前E/E舱后门821A。参考前E/E舱后门 - 从外部打开接近程序, MPP C919-A-52-43-00-00A-540B-A (8) Energize the aircraft electrical circuits. Refer to Energize the aircraft electrical circuits (Task Selection)-Energize electrical network,MPP C919-A-24-00-00-00A-761A-A . 给飞机电网通电。 参考给飞机电网通电(任务选择) - 飞机通电, MPP C919-A-24-00-00-00A-761A-A。			XXXXX
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 3 of 26

Job Card 工卡号: C193405001001-1																																																																																											
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检																																																																																								
(9) Open, safety/lock and tag this(these) circuit breaker(s): 拔出、保险/锁定并挂标签以下跳开关: Circuit breaker: 跳开关: <table><tr><th>PANEL 面板</th><th>CB name 跳开关名称</th><th>CB number 跳开关编号</th><th>Type 类型</th></tr><tr><td>RICBP</td><td>D-ISS-PU</td><td>R-ICBP-B-15</td><td>TCB</td></tr><tr><td>EDP</td><td>EDP-EMPC-A-LRM</td><td>EDP-A-2</td><td>TCB</td></tr><tr><td>EDP</td><td>RIGHT-PITOT-STATIC</td><td>EDP-G-1</td><td>TCB</td></tr><tr><td>EDP</td><td>AOA-LEFT1</td><td>EDP-G-2</td><td>TCB</td></tr><tr><td>EDP</td><td>LEFT-PITOT-STATIC</td><td>EDP-H-1</td><td>TCB</td></tr><tr><td>LDP</td><td>EDP-EMPC-C-LRM</td><td>LDP-Q-2</td><td>TCB</td></tr><tr><td>RDP</td><td>EDP-EMPC-B-LRM</td><td>RDP-K-3</td><td>TCB</td></tr><tr><td>CBIC</td><td>OET1</td><td>RPDU11-8-6</td><td>SSPC</td></tr><tr><td>CBIC</td><td>LEFT-STATIC1</td><td>RPDU21-3-7</td><td>SSPC</td></tr><tr><td>CBIC</td><td>RIGHT-STATIC1</td><td>RPDU21-4-5</td><td>SSPC</td></tr><tr><td>CBIC</td><td>LEFT-PITOT-PROBE</td><td>RPDU21-7-5</td><td>SSPC</td></tr><tr><td>CBIC</td><td>RIGHT-PITOT-PROBE</td><td>RPDU22-7-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TAT-RIGHT</td><td>RPDU22-8-3</td><td>SSPC</td></tr><tr><td>CBIC</td><td>AOA-RIGHT1</td><td>RPDU23-8-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TAT-LEFT</td><td>RPDU23-8-3</td><td>SSPC</td></tr><tr><td>CBIC</td><td>LEFT-STATIC3</td><td>RPDU24-3-3</td><td>SSPC</td></tr><tr><td>CBIC</td><td>AOA-LEFT2</td><td>RPDU24-7-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>RIGHT-STATIC3</td><td>RPDU26-3-2</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TSA-RELAYS-POWER</td><td>RPDU26-4-10</td><td>SSPC</td></tr><tr><td>CBIC</td><td>ISS-PU</td><td>RPDU26-7-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>AOA-RIGHT2</td><td>RPDU26-7-3</td><td>SSPC</td></tr></table> CAUTION: WHEN THE ADHCS IS POWER OFF, THE SENSORS WILL BE HEATED AUTOMATICALLY. IN ORDER TO PREVENT THE EQUIPMENT FROM BEING BURNT OUT, THE CIRCUIT BREAKERS OF THE ADHCS SHOULD BE OPENED AT LAST DURING THE OPERATION OF OPENING CIRCUIT BREAKERS. 注意: 当ADHC断电时, 传感器将自动加温。为了防止设备被烧坏, 在断开		PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型	RICBP	D-ISS-PU	R-ICBP-B-15	TCB	EDP	EDP-EMPC-A-LRM	EDP-A-2	TCB	EDP	RIGHT-PITOT-STATIC	EDP-G-1	TCB	EDP	AOA-LEFT1	EDP-G-2	TCB	EDP	LEFT-PITOT-STATIC	EDP-H-1	TCB	LDP	EDP-EMPC-C-LRM	LDP-Q-2	TCB	RDP	EDP-EMPC-B-LRM	RDP-K-3	TCB	CBIC	OET1	RPDU11-8-6	SSPC	CBIC	LEFT-STATIC1	RPDU21-3-7	SSPC	CBIC	RIGHT-STATIC1	RPDU21-4-5	SSPC	CBIC	LEFT-PITOT-PROBE	RPDU21-7-5	SSPC	CBIC	RIGHT-PITOT-PROBE	RPDU22-7-1	SSPC	CBIC	TAT-RIGHT	RPDU22-8-3	SSPC	CBIC	AOA-RIGHT1	RPDU23-8-1	SSPC	CBIC	TAT-LEFT	RPDU23-8-3	SSPC	CBIC	LEFT-STATIC3	RPDU24-3-3	SSPC	CBIC	AOA-LEFT2	RPDU24-7-1	SSPC	CBIC	RIGHT-STATIC3	RPDU26-3-2	SSPC	CBIC	TSA-RELAYS-POWER	RPDU26-4-10	SSPC	CBIC	ISS-PU	RPDU26-7-1	SSPC	CBIC	AOA-RIGHT2	RPDU26-7-3	SSPC		
PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型																																																																																								
RICBP	D-ISS-PU	R-ICBP-B-15	TCB																																																																																								
EDP	EDP-EMPC-A-LRM	EDP-A-2	TCB																																																																																								
EDP	RIGHT-PITOT-STATIC	EDP-G-1	TCB																																																																																								
EDP	AOA-LEFT1	EDP-G-2	TCB																																																																																								
EDP	LEFT-PITOT-STATIC	EDP-H-1	TCB																																																																																								
LDP	EDP-EMPC-C-LRM	LDP-Q-2	TCB																																																																																								
RDP	EDP-EMPC-B-LRM	RDP-K-3	TCB																																																																																								
CBIC	OET1	RPDU11-8-6	SSPC																																																																																								
CBIC	LEFT-STATIC1	RPDU21-3-7	SSPC																																																																																								
CBIC	RIGHT-STATIC1	RPDU21-4-5	SSPC																																																																																								
CBIC	LEFT-PITOT-PROBE	RPDU21-7-5	SSPC																																																																																								
CBIC	RIGHT-PITOT-PROBE	RPDU22-7-1	SSPC																																																																																								
CBIC	TAT-RIGHT	RPDU22-8-3	SSPC																																																																																								
CBIC	AOA-RIGHT1	RPDU23-8-1	SSPC																																																																																								
CBIC	TAT-LEFT	RPDU23-8-3	SSPC																																																																																								
CBIC	LEFT-STATIC3	RPDU24-3-3	SSPC																																																																																								
CBIC	AOA-LEFT2	RPDU24-7-1	SSPC																																																																																								
CBIC	RIGHT-STATIC3	RPDU26-3-2	SSPC																																																																																								
CBIC	TSA-RELAYS-POWER	RPDU26-4-10	SSPC																																																																																								
CBIC	ISS-PU	RPDU26-7-1	SSPC																																																																																								
CBIC	AOA-RIGHT2	RPDU26-7-3	SSPC																																																																																								
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 4 of 26																																																																																									

Job Card 工卡号: C193405001001-1																			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检																
跳开关的操作过程中，应最后断开ADHC的跳开关。 (10) Open, safety/lock and tag this(these) circuit breaker(s): 拔出、保险/锁定并挂标签以下跳开关: Circuit breaker: 跳开关: <table><tr><td>PANEL 面板</td><td>CB name 跳开关名称</td><td>CB number 跳开关编号</td><td>Type 类型</td></tr><tr><td>EDP</td><td>ADHC2</td><td>EDP-B-4</td><td>TCB</td></tr><tr><td>CBIC</td><td>ADHC1</td><td>RPDU25-3-11</td><td>SSPC</td></tr><tr><td>CBIC</td><td>ADHC3</td><td>RPDU26-4-9</td><td>SSPC</td></tr></table> (11) Make sure that this(these) circuit breaker(s) is(are) closed: 确保以下跳开关闭合: - BATT INTLK at the front panel of the PCM1, in the fwd E/E compartment. 前E/E舱中，PCM1前面板上的BATT INTLK。 - BATT INTLK at the front panel of the PCM2, in the fwd E/E compartment. 前E/E舱中，PCM2前面板上的BATT INTLK。 - BATT INTLK at the front panel of the PCM3, in the mid E/E compartment. 中E/E舱中，PCM3前面板上的BATT INTLK。 - BATT INTLK at the front panel of the PCM4, in the mid E/E compartment. 中E/E舱中，PCM4前面板上的BATT INTLK。 - ACE at the front panel of the PCM1, in the fwd E/E compartment. 前E/E舱中，PCM1前面板上的ACE。 - ACE at the front panel of the PCM2, in the fwd E/E compartment. 前E/E舱中，PCM2前面板上的ACE。 - ACE at the front panel of the PCM3, in the mid E/E compartment. 中E/E舱中，PCM3前面板上的ACE。 - ACE at the front panel of the PCM4, in the mid E/E compartment. 中E/E舱中，PCM4前面板上的ACE。 - FCM at the front panel of the PCM1, in the fwd E/E compartment. 前E/E舱中，PCM1前面板上的FCM。 - FCM at the front panel of the PCM2, in the fwd E/E compartment. 前E/E舱中，PCM2前面板上的FCM。 - FCM at the front panel of the PCM3, in the mid E/E compartment. 中E/E舱中，PCM3前面板上的FCM。 WARNING: MAKE SURE THAT PERSONS AND EQUIPMENT ARE FAR AWAY FROM THE PATH OF THE RAT DEPLOYMENT AND RAT COMPARTMENT DOOR OPENING. BECAUSE FAST DEPLOYMENT OF THE RAT AND OPENING OF THE RAT COMPARTMENT DOOR CAN CAUSE INJURY TO PERSONS AND DAMAGE TO EQUIPMENT. 警告:		PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型	EDP	ADHC2	EDP-B-4	TCB	CBIC	ADHC1	RPDU25-3-11	SSPC	CBIC	ADHC3	RPDU26-4-9	SSPC		
PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型																
EDP	ADHC2	EDP-B-4	TCB																
CBIC	ADHC1	RPDU25-3-11	SSPC																
CBIC	ADHC3	RPDU26-4-9	SSPC																
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 5 of 26																	

Job Card 工卡号: C193405001001-1																																	
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检																														
确保人员和设备远离RAT放出和RAT舱门打开的路径，因为RAT的快速放出和RAT舱门的打开会造成人员受伤和设备损坏。 (12) Instal the RAT stow lock pins(AGE19021) . Refer to RAT stow lock pin-Installation,MPP C919-A-24-23-00-00A-720A-A . 安装RAT收上锁定销(AGE19021)。参考RAT收上锁定销 - 安装, MPP C919-A-24-23-00-00A-720A-A。 B. Procedure 程序 (1) Do the ISS self-test: 执行ISS自检: NOTE: Two persons are necessary to do the task. One person operates 注: this(these) circuit breaker(s), the other observes the ISS self-test. 需要两人来执行此任务。一人操作跳开关，另一人观察ISS自检。 (a) Remove the tag(s) and/or the safety clip(s) and close/unlock this(these) circuit breaker(s): 拆下标签和/或保险夹并闭合/解锁以下跳开关: Circuit breaker: 跳开关: <table><tr><td>PANEL 面板</td><td>CB name 跳开关名称</td><td>CB number 跳开关编号</td><td>Type 类型</td></tr><tr><td>RICBP</td><td>D-ISS-PU</td><td>R-ICBP-B-15</td><td>TCB</td></tr><tr><td>CBIC</td><td>OET1</td><td>RPDU11-8-6</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TSA-RELAYS-POWER</td><td>RPDU26-4-10</td><td>SSPC</td></tr><tr><td>CBIC</td><td>OET2</td><td>RPDU26-4-15</td><td>SSPC</td></tr><tr><td>CBIC</td><td>ISS-PU</td><td>RPDU26-7-1</td><td>SSPC</td></tr></table> (b) Do these steps: 执行以下步骤: <table><tr><td>ACTION 动作</td><td>RESULT 结果</td></tr><tr><td>1.On the left side of the aft equipment rack in the forward (EE) compartment. 1. 在前EE电子设备舱中的后设备架的左侧。</td><td>On the left ISS computer: 在左ISS计算机上:</td></tr><tr><td>- Check the lights indication on the front panel of left ISS : 检查左ISS前面板上的灯指示:</td><td>- The LRU STATUS light indicates red, then goes off. LRU STATUS灯指示红色，然后熄灭。 - The lights of LRU STATUS,UPPER</td></tr></table>		PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型	RICBP	D-ISS-PU	R-ICBP-B-15	TCB	CBIC	OET1	RPDU11-8-6	SSPC	CBIC	TSA-RELAYS-POWER	RPDU26-4-10	SSPC	CBIC	OET2	RPDU26-4-15	SSPC	CBIC	ISS-PU	RPDU26-7-1	SSPC	ACTION 动作	RESULT 结果	1.On the left side of the aft equipment rack in the forward (EE) compartment. 1. 在前EE电子设备舱中的后设备架的左侧。	On the left ISS computer: 在左ISS计算机上:	- Check the lights indication on the front panel of left ISS : 检查左ISS前面板上的灯指示:	- The LRU STATUS light indicates red, then goes off. LRU STATUS灯指示红色，然后熄灭。 - The lights of LRU STATUS,UPPER		C
PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型																														
RICBP	D-ISS-PU	R-ICBP-B-15	TCB																														
CBIC	OET1	RPDU11-8-6	SSPC																														
CBIC	TSA-RELAYS-POWER	RPDU26-4-10	SSPC																														
CBIC	OET2	RPDU26-4-15	SSPC																														
CBIC	ISS-PU	RPDU26-7-1	SSPC																														
ACTION 动作	RESULT 结果																																
1.On the left side of the aft equipment rack in the forward (EE) compartment. 1. 在前EE电子设备舱中的后设备架的左侧。	On the left ISS computer: 在左ISS计算机上:																																
- Check the lights indication on the front panel of left ISS : 检查左ISS前面板上的灯指示:	- The LRU STATUS light indicates red, then goes off. LRU STATUS灯指示红色，然后熄灭。 - The lights of LRU STATUS,UPPER																																
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 6 of 26																															

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	ANT FAIL and LOWER ANT FAIL indicate red, then go off. LRU STATUS、UPPER ANT FAIL和LOWER ANT FAIL灯指示红色，然后熄灭。 - The LRU STATUS light flashes in green. LRU STATUS灯以绿色闪烁。 - The LRU STATUS light indicates green, then goes off. LRU STATUS灯指示绿色，然后熄灭。 - Make sure there is no bright red light on the panel. 确保面板上没有明亮的红灯。		
	2.On the right side of the aft equipment rack in the forward EE compartment. 2. 在前EE舱后设备架的右侧。	On the right ISS computer: 在右ISS计算机上:	
	- Check the lights indication on the front panel of right ISS : 检查右ISS前面板上的灯指示:	- The ACAS/ATC STATUS light indicates red, then goes off. ACAS/ATC STATUS灯指示红色，然后熄灭。 - The lights of ACAS/ATC STATUS, UPPER ANT FAIL and LOWER ANT FAIL indicate red, then go off. ACAS/ATC STATUS、UPPER ANT FAIL和LOWER ANT FAIL灯指示红色，然后熄灭。 - The ACAS/ATC STATUS light flashes in green. ACAS/ATC STATUS灯以绿色闪烁。 - The ACAS/ATC STATUS light indicates green, then goes off. ACAS/ATC STATUS灯指示绿色，然后熄灭。 - Make sure there is no bright red light on the panel. 确保面板上没有明亮的红灯。	
(2) Connect the Test Set - Test, Air Data System to the pitot probes, pitot-static probes and static ports of the air data system using Kit, Adapter - Air Data System Test(QJSPQ-C9) . 使用大气数据系统测试套装转接头(QJSPQ-C9)将大气数据系统测试设备连接到大气数据系统的皮托管，全静压管和静压孔。			
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 7 of 26

Job Card 工卡号: C193405001001-1											
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检								
(3) Do the leak check of the air data system. Refer to Air Data System-Leak check, MPP C919-A-34-11-00-00A-364A-A . 执行大气数据系统的渗漏检查。参考大气数据系统 - 渗漏检查, MPP C919-A-34-11-00-00A-364A-A。 NOTE: Do not remove the test equipment after leak check. 注: 渗漏检查后不要拆下测试设备。 (4) Make sure that the aircraft is on the ground. 确保飞机在地面。 (5) Do these steps to test the bottom TSA : 执行以下步骤测试下TSA: WARNING: MAKE SURE THAT THE TRANSPONDER IS IN THE STANDBY MODE WHEN YOU SIMULATE ALTITUDE. OTHERWISE YOU CAN ACCIDENTALLY CAUSE TCAS TARGETS. AIR TRAFFIC IN THE AREA WILL CHANGE DIRECTION QUICKLY TO GO AWAY FROM THESE TARGETS. THIS CAN CAUSE INJURIES TO PERSONNEL AND DAMAGE TO EQUIPMENT. 警告: 当模拟高度时, 确保应答机处于备用模式。否则可能会意外导致TCAS目标。该区域的空中交通将快速改变方向以远离这些目标。这可能会造成人员受伤和设备受损。 (a) Set the TR-220: 设置TR-220: <table border="1"> <thead> <tr> <th>ACTION 动作</th> <th>RESULT 结果</th> </tr> </thead> <tbody> <tr> <td>1.Put the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) on the top TSA to shield the antenna. 1. 将天线耦合器(TC-201)或(ZDC-02)放在上TSA上以屏蔽天线。</td> <td></td> </tr> <tr> <td>2.On the Test Set - Test, Air Data System : 2. 在大气数据系统测试设备上:</td> <td>On the Primary Flight Display (PFD) : 在PFD主飞行显示上:</td> </tr> <tr> <td>- Set the altitude to 43000 ft and airspeed to 120 kts. 设置高度为 43000 ft , 空速为 120 kts。 NOTE: The altitude value is recommended and you can set the altitude according to the requirements of air traffic control tower. When you set the altitude, make</td> <td>- The barometric altitude shown is 43000ft. The air speed is 120kts. 气压高度显示43000ft。空速120kts。</td> </tr> </tbody> </table>		ACTION 动作	RESULT 结果	1.Put the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) on the top TSA to shield the antenna. 1. 将天线耦合器(TC-201)或(ZDC-02)放在上TSA上以屏蔽天线。		2.On the Test Set - Test, Air Data System : 2. 在大气数据系统测试设备上:	On the Primary Flight Display (PFD) : 在PFD主飞行显示上:	- Set the altitude to 43000 ft and airspeed to 120 kts. 设置高度为 43000 ft , 空速为 120 kts。 NOTE: The altitude value is recommended and you can set the altitude according to the requirements of air traffic control tower. When you set the altitude, make	- The barometric altitude shown is 43000ft. The air speed is 120kts. 气压高度显示43000ft。空速120kts。		C
ACTION 动作	RESULT 结果										
1.Put the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) on the top TSA to shield the antenna. 1. 将天线耦合器(TC-201)或(ZDC-02)放在上TSA上以屏蔽天线。											
2.On the Test Set - Test, Air Data System : 2. 在大气数据系统测试设备上:	On the Primary Flight Display (PFD) : 在PFD主飞行显示上:										
- Set the altitude to 43000 ft and airspeed to 120 kts. 设置高度为 43000 ft , 空速为 120 kts。 NOTE: The altitude value is recommended and you can set the altitude according to the requirements of air traffic control tower. When you set the altitude, make	- The barometric altitude shown is 43000ft. The air speed is 120kts. 气压高度显示43000ft。空速120kts。										
			C								
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 8 of 26									

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
sure that the STBY for XPDR MODE is green on TRAFFIC page of (TCP) . 高度值是推荐的，可以根据 空中交通管制塔台的要求设 置高度。当设置高度时，确 保(TCP)的TRAFFIC页面上的 XPDR MODE的STBY为绿色。 3.Connect the directional antenna coaxial cable of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) to the ANTENNA SUM&DIFF connector in the front panel of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) . 3. 将综合ISS测试设备测距仪 (TR-220) 的定向天线同轴电缆连接到ISS测试设 备测距仪 (TR-220) 前面板的ANTENNA SUM&DIFF插上。 NOTE: Make sure that the white 注: cable is connected to the SUM end and the yellow cable is connected to the DIFF end. 确保白色电缆连接到SUM端， 黄色电缆连接到DIFF端。 4.Put the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) 20 ft ± 1ft(6.1 m ± 0.305m) away from the left-front screw hole in the heading direction of the bottom TSA base. 4. 将ISS测试设备测距仪 (TR-220) 放在 距离下TSA天线的左前螺孔航向前 20 ft ± 1ft(6.1 m ± 0.305m)处。 NOTE: Heading direction is 注: defined as the angle between the direction and the heading is within 9 ° . 航向方向定义为方向和航向 之间的角度在9°以内。			
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 9 of 26	

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	5.Do these steps on the right TCP : 5. 在右TCP上执行以下步骤:		
	On the right TCP : 在右TCP上:		
	- Push the TFC key on the TCP to enter the TRAFFIC page. 按压TCP上的TFC键进入TRAFFIC页。 - Push the R-LSK-6 to select L for TFC SYS. 按压R-LSK-6以选择TFC SYS的L。 - Push the L-LSK-3 to select XPDR for XPDR MODE. 按压L-LSK-3以选择XPDR的XPDR MODE。		
	- XPDR is shown on the display. 显示屏上显示XPDR。		
	- Input the XPDR CODE: 1234 on the digital keyboard of the TCP . 在TCP的数字键盘上输入XPDR代码: 1234。 - Push the L-LSK-6 to enter XPDR CODE. 按压L-LSK-6以输入XPDR CODE。		
	- 1234 is shown on the display. 1234显示在显示屏上。		
	6.On the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) : 6. 在ISS测试设备测距仪 (TR-220) 上:		
	On the TR-220: 在TR-220上:		
	- Set the TEST SET toggle switch to ON position. 设置TEST SET拨动电门到ON位。		
	- Make sure that the green indication light near the TEST SET toggle switch turns on and the screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows PASS after built-in test. 确保自检后, TEST SET拨动电门附近的绿色指示灯点亮, 并且ISS测试设备测距仪 (TR-220) 的屏幕显示PASS。		
	- Turn the UUT FUNCTION switch on the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) to SETUP position. 将ISS测试设备测距仪 (TR-220) 上的 UUT FUNCTION电门转到SETUP位。 - Set the AUTO/TEST/MANUAL switch to AUTO on the Test Set - Test,		
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 10 of 26

Job Card 工卡号: C193405001001-1											
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检								
Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) to XPDR position. 将ISS测试设备测距仪 (TR-220) 的UUT FUNCTION电门转到XPDR位。 Auto/Manual) is shown. 显示COMM AB和Press A/M(或Press Auto/Manual)。											
(b) Do the transponder functional test: 执行应答机功能测试:											
<table><thead><tr><th>ACTION 动作</th><th>RESULT 结果</th></tr></thead><tbody><tr><td>1.On the TR-220: 1. 在TR-220上:</td><td>On the TR-220: 在TR-220上:</td></tr><tr><td>- Set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the Mode A test. 将AUTO/TEST/MANUAL电门设置到MANUAL位置，以启动模式A测试。</td><td>- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-1 and figure 1-2. ISS测试设备测距仪 (TR-220) 的屏幕交替显示两个结果页面，参考图1-1和图1-2。 NOTE: The display is only for reference. As long as the mode A code (1234) in figure 1-1 is in accordance with the present setting on the aircraft, and the screen shows PASS, the test is passed. 显示仅供参考。只要图1-1中的方式A代码(1234)与飞机上的当前设置一致，并且屏幕显示PASS，则测试通过。</td></tr><tr><td>- Push the IDENT button on the TCP . 按压TCP上的IDENT按钮。</td><td>- Make sure that IDENT shows on the screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) for about 20 s to check the SPI pulse from the XPDR , refer to figure 1-3. 确保ISS测试设备测距仪 (TR-220) 的屏幕上显示IDENT约 20 s ，以检查来自XPDR的SPI脉冲，参考图1-3。</td></tr></tbody></table>		ACTION 动作	RESULT 结果	1.On the TR-220: 1. 在TR-220上:	On the TR-220: 在TR-220上:	- Set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the Mode A test. 将AUTO/TEST/MANUAL电门设置到MANUAL位置，以启动模式A测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-1 and figure 1-2. ISS测试设备测距仪 (TR-220) 的屏幕交替显示两个结果页面，参考图1-1和图1-2。 NOTE: The display is only for reference. As long as the mode A code (1234) in figure 1-1 is in accordance with the present setting on the aircraft, and the screen shows PASS, the test is passed. 显示仅供参考。只要图1-1中的方式A代码(1234)与飞机上的当前设置一致，并且屏幕显示PASS，则测试通过。	- Push the IDENT button on the TCP . 按压TCP上的IDENT按钮。	- Make sure that IDENT shows on the screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) for about 20 s to check the SPI pulse from the XPDR , refer to figure 1-3. 确保ISS测试设备测距仪 (TR-220) 的屏幕上显示IDENT约 20 s ，以检查来自XPDR的SPI脉冲，参考图1-3。		
ACTION 动作	RESULT 结果										
1.On the TR-220: 1. 在TR-220上:	On the TR-220: 在TR-220上:										
- Set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the Mode A test. 将AUTO/TEST/MANUAL电门设置到MANUAL位置，以启动模式A测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-1 and figure 1-2. ISS测试设备测距仪 (TR-220) 的屏幕交替显示两个结果页面，参考图1-1和图1-2。 NOTE: The display is only for reference. As long as the mode A code (1234) in figure 1-1 is in accordance with the present setting on the aircraft, and the screen shows PASS, the test is passed. 显示仅供参考。只要图1-1中的方式A代码(1234)与飞机上的当前设置一致，并且屏幕显示PASS，则测试通过。										
- Push the IDENT button on the TCP . 按压TCP上的IDENT按钮。	- Make sure that IDENT shows on the screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) for about 20 s to check the SPI pulse from the XPDR , refer to figure 1-3. 确保ISS测试设备测距仪 (TR-220) 的屏幕上显示IDENT约 20 s ，以检查来自XPDR的SPI脉冲，参考图1-3。										
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 12 of 26								

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	NOTE: If the result is not the same as the display in figure 1-3, it will not affect the test result. As long as PASS shows on the screen, the test is passed. 如果结果与图1-3中的显示不同, 则不会影响测试结果。只要PASS显示在屏幕上, 测试就通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the Mode C test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位置, 以启动模式C测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-4 and 1-5. ISS测试设备测距仪(TR-220)的屏幕交替显示两个结果页面, 参考图1-4和1-5。 NOTE: The 6520 in figure 1-4 is the mode C code of the undertest equipment, which indicates the altitude is 10000 ft . 图1-4中的6520是被测设备的模式C代码, 指示高度为10000 ft 。 NOTE: Figure 1-4 and figure 1-5 are only for reference. As long as the mode C altitude is in accordance with the altitude on the PFD , and the screen shows PASS, the test is passed. 图1-4和图1-5仅供参考。只要模式C高度与 PFD 上的高度一致, 并且屏幕显示PASS, 则测试通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the Side Lobe Suppression (SLS) test of Mode A. 继续将AUTO/TEST/MANUAL电门设置到	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-6. ISS测试设备测距仪(TR-220)的屏幕显		
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 13 of 26

Job Card 工卡号: C193405001001-1					
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机 (RVSM)	Mech 机械员	CHK/INSP 互检/必检		
MANUAL位，以启动模式A的SLS旁瓣抑制测试。					
示结果页面，参考图1-6。 NOTE: When the two lines in figure 1-6 both show PASS, the test is passed. When P1 is 9 dB bigger than P2, the reply rate of the XPDR is greater than 99%. When P1= P2, the reply rate of the XPDR is less than 1%. 当图1-6中的两行都显示PASS时，测试通过。当P1大于P2 9 dB 时，XPDR的应答率大于99%。当P1=P2时，XPDR的应答率小于1%。					
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the only call test of Mode A. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位置，以启动模式A的仅呼测试。				- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-9. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-9。 NOTE: When PASS shows in figure 1-9, the test is passed. 当PASS显示在图1-9中时，测试通过。	
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the only call test of Mode C. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位，以启动模式C的仅呼测试。				- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-10. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-10。 NOTE: When PASS shows in figure 1-10, the test is passed. 当PASS显示在图1-10中时，测试通过。	
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the SI LOCKOUT test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位，以启动SI LOCKOUT锁定测试。				- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-11. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-11。	
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 14 of 26		

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	NOTE: The value in figure 1-11 is only for reference. As long as PASS shows on the screen, the test is passed. 图1-11中的值仅供参考。只要PASS显示在屏幕上，测试就通过。		
	- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the surveillance ID test of mode S. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位，以启动模式S的监视ID测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-12. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-12。 NOTE: The value in figure 1-12 is only for reference. As long as the mode A code (1234) is in accordance with the present setting on the TCP , the test is passed. 图1-12中的值仅供参考。只要模式A代码(1234)与 TCP 上的当前设置一致，则测试通过。	
	- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the surveillance altitude test of mode S. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位，以启动模式S的监视高度测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-13. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-13。 NOTE: 10000 in figure 1-13 means the surveillance aircraft altitude is 10000 ft and this value is only for reference. As long as the surveillance altitude is in accordance with the altitude on the PFD , the test is passed. 图1-13中的10000表示监视飞机高度为 10000 ft ，该值仅供参考。只要监视高度与 PFD 上的高度一致，测试就通过。	
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 15 of 26

Job Card 工卡号: C193405001001-1				
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)		Mech 机械员	CHK/INSP 互检/必检
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the short range air surveillance test of mode S. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位，以启动模式S的短程空中监视测试。		- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-14 and figure 1-15. ISS测试设备测距仪 (TR-220) 的屏幕交替显示两个结果页面，参见图1-14和图1-15。 NOTE: In figure 1-14 and figure 1-15, 10000 means the aircraft altitude is 10000 ft , 800000 is the hexadecimal aircraft address code and 40000000 is the octal aircraft address code. As long as the address code is in accordance with the present aircraft address code, the test is passed. 在图1-14和图1-15中，10000表示飞机高度为 10000 ft ，800000是十六进制飞机地址代码，40000000是八进制飞机地址代码。只要地址代码与当前飞机地址代码一致，则测试通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the communication ID test of mode S. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位置，以启动模式S的通信ID测试。		- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-16. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-16。 NOTE: 1234 in figure 1-16 is the mode A code of the aircraft and the value is only for reference. As long as the mode A code is in accordance with the present setting on the TCP , the test is passed. 图1-16中的1234是飞机的模式A代码，该值仅供参考。只		
Aircraft Effectivity 飞机适用范围: ALL				Page 页码 16 of 26

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	要模式A代码与 TCP 上的当前设置一致, 则测试通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the communication altitude test of mode S. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位, 以启动模式S的通信高度测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-17. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面, 参考图1-17。 NOTE: 10000 in figure 1-17 means 注: the aircraft altitude is 10000 ft and the value is only for reference. As long as the altitude on the screen is in accordance with the altitude on the PFD , the test is passed. 图1-17中的10000表示飞机高度为 10000 ft , 该值仅供参考。只要屏幕上的高度与 PFD 上的高度一致, 测试就通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the long air surveillance test of mode S. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位, 以启动模式S的远程空中监视测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-18. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面, 参考图1-18。 NOTE: 43000 in figure 1-18 means 注: the aircraft altitude is 43000 ft , 7800CB is the hexadecimal aircraft address code, and the value is only for reference. As long as the aircraft altitude is in accordance with the altitude on the PFD , and the hexadecimal address code is in accordance with the present aircraft address code, the test is passed. 图1-18中的43000表示飞机高		
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 17 of 26

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	度为 43000 ft , 7800CB是十六进制飞机地址代码, 该值仅供参考。只要飞机高度与 PFD 上的高度一致, 并且十六进制地址代码与当前飞机地址代码一致, 则测试通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the undesired reply test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位置, 以启动非预期应答测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-19. ISS测试设备测距仪(TR-220)的屏幕显示结果页面, 参考图1-19。 NOTE: PASS in the figure 1-19 注: means the test is passed. 图1-19中的PASS表示测试通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the squitter test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位, 以启动信号测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-20 and figure 1-21. ISS测试设备测距仪(TR-220)的屏幕交替显示两个结果页面, 参考图1-20和图1-21。 NOTE: As long as PASS shows in 注: figure 1-20, the test is passed. 只要PASS显示在图1-20中, 则测试通过。		
- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the maximum cruise speed test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位, 以启动最大巡航速度测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-22. ISS测试设备测距仪(TR-220)的屏幕显示结果页面, 参考图1-22。 NOTE: Figure 1-22 means that the 注: maximum cruise speed is between 300 kts and 600 kts.		
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 18 of 26

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
		图1-22表示最大巡航速度在300 kts 和 600 kts之间。	
	- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the diversity test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位以启动分集测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-23. ISS测试设备测距仪 (TR-220) 的屏幕显示结果页面，参考图1-23。 NOTE: The value in figure 1-23 is only for reference. As long as PASS shows in figure 1-23, the test is passed. 图1-23中的值仅供参考。只要PASS显示在图1-23中，则测试通过。	
	- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the sensitivity test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位以启动灵敏度测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page after 2 min ~ 4 min , refer to figure 1-24. ISS测试设备测距仪 (TR-220) 的屏幕在2 min ~ 4 min 后显示结果页面，参考图1-24。 NOTE: The display in figure 1-24 is only for reference. As long as PASS shows on the page , the test is passed. 图1-24中的显示仅供参考。只要页面上显示PASS，则测试通过。	
	- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the width/ amplitude test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位置，以启动宽度/振幅测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows two result pages alternately, refer to figure 1-25 and figure 1-26. ISS测试设备测距仪 (TR-220) 的屏幕交替显示两个结果页面，参见图1-25和图1-26。 NOTE: The value in figure 1-25 and	
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 19 of 26

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
	注: figure 1-26 are only for reference. As long as P and PASS shows on the two pages, the test is passed. 图1-25和图1-26中的值仅供参考。只要PASS显示在两个页面上,则测试通过。		
	- Continue to set the AUTO/TEST/MANUAL switch to MANUAL position in order to activate the power/frequency test. 继续将AUTO/TEST/MANUAL电门设置到MANUAL位,以启动功率/频率测试。	- The screen of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) shows result page, refer to figure 1-27. ISS测试设备测距仪(TR-220)的屏幕显示结果页面,参考图1-27。 NOTE: In figure 1-27, 54dBm is the emissive power and 1090MHz is the transmitting frequency. When the emissive power is within 53~55 dBm and the transmitting frequency is within 1089 MHz ~ 1091 MHz , the test is passed. 在图1-27中, 54dBm是发射功率, 1090MHz是发射频率。当发射功率在53~55 dBm范围内且发射频率在 1089 MHz ~ 1091 MHz 范围内时, 测试通过。	
(c) Remove the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) from the top TSA . 从上TSA拆下天线耦合器(TC-201)或(ZDC-02)。			
(6) Do these steps to do the functional test of the top TSA . 执行以下步骤对上TSA进行功能测试。			C
(a) Put the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) on the bottom TSA to shield the antenna. 将天线耦合器(TC-201)或(ZDC-02)放在下TSA上以屏蔽天线。			
(b) Put the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) 20 ft ± 1ft(6.1 m ± 0.305m) away from the left-front screw hole in the heading direction of the top TSA base.. 将ISS测试设备测距仪(TR-220)放在距离上TSA天线的左前螺孔航向前 20 ft ± 1ft(6.1 m ± 0.305m)处。			
(c) Make sure that the directional antenna of the Test Set - Test, Integrated			
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 20 of 26

Job Card 工卡号: C193405001001-1							
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检				
Surveillance System, Distance Measuring Equipment(TR-220) points to the top TSA of the aircraft and there is no obstruction between the two antennas. 确保ISS测试设备测距仪 (TR-220) 的定向天线指向上TSA，并且两个天线之间没有障碍物。 (d) Repeat Step B.(5).(b). . 重复步骤B. (5). (b). 。 (7) Do the transponder functional test of right ISS : 执行右ISS的应答机功能测试: (a) Push the TFC key on the right TCP to enter the TRAFFIC page. 按压右TCP上的TFC键进入TRAFFIC页。 (b) Push the R-LSK-6 to select R for TFC SYS. 按压R-LSK-6以选择TFC SYS的R。 (c) R is highlighted in green on the right TCP. R在右TCP上以绿色高亮显示。 (d) Repeat Step B.(5).(b). . 重复步骤B. (5). (b). 。 (e) Remove the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) from the bottom TSA . 从下TSA上拆下天线耦合器 (TC-201) 或 (ZDC-02) 。 (f) Put the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) on the top TSA to shield the antenna. 将天线耦合器 (TC-201) 或 (ZDC-02) 放在上TSA上以屏蔽天线。 (g) Put the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) 20 ft ± 1ft(6.1 m ± 0.305m) away from the left-front screw hole in the heading direction of the bottom TSA base. 将ISS测试设备测距仪 (TR-220) 放在距离下TSA天线的左前螺孔航向前 20 ft ± 1ft(6.1 m ± 0.305m) 处。 (h) Make sure that the directional antenna of the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) points to the bottom TSA of the aircraft and there is no obstruction between the two antennas. 确保ISS测试设备测距仪 (TR-220) 的定向天线指向下TSA，并且两个天线之间没有障碍物。 (i) Repeat Step B.(5).(b). . 重复步骤B. (5). (b). 。 (8) Open, safety/lock and tag this(these) circuit breaker(s): 拔出、保险/锁定并挂标签以下跳开关: Circuit breaker: 跳开关: <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <tr> <td style="width: 20%; padding: 5px;">PANEL 面板</td> <td style="width: 30%; padding: 5px;">CB name 跳开关名称</td> <td style="width: 20%; padding: 5px;">CB number 跳开关编号</td> <td style="width: 30%; padding: 5px;">Type 类型</td> </tr> </table>		PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型		
PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型				
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 21 of 26					

Job Card 工卡号: C193405001001-1																											
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检																								
<table border="1"> <tr> <td>CBIC</td> <td>OET1</td> <td>RPDU11-8-6</td> <td>SSPC</td> </tr> <tr> <td>CBIC</td> <td>OET2</td> <td>RPDU26-4-15</td> <td>SSPC</td> </tr> </table> (9) Make sure that XPDR L+R FAULT shows on the EICAS page. 确保EICAS页面上显示XPDR L+R FAULT。 (10) Do the restoration test: 执行恢复测试: (a) Slowly decrease the altitude on the Test Set - Test, Air Data System to the local altitude. 将大气数据系统测试设备上的高度缓慢降低到当地高度。 (b) Slowly decrease the airspeed to 0 kts on Test Set - Test, Air Data System . 在大气数据系统测试设备上，将空速缓慢降至0节。 (c) Remove the Test Set - Test, Air Data System and Kit, Adapter - Air Data System Test(QJSPQ-C9) from the air data system. 从大气数据系统上拆下大气数据系统测试设备和大气数据系统测试套装转接头(QJSPQ-C9)。 (d) Disconnect the Tool - Ground Anti heating, Air Data probe(6341C02-A) from the electrical connectors of three ADHC s. 从三个ADHC的电插上脱开大气数据探头地面防加温工具(6341C02-A)。 (e) Connect the electrical connectors of three ADHC s. 连接三个ADHC的电插头。 CAUTION: WHEN THE ADHCS IS POWER OFF, THE SENSORS WILL BE HEATED AUTOMATICALLY. IN ORDER TO PREVENT THE EQUIPMENT FROM BEING BURNT OUT, THE CIRCUIT BREAKERS OF THE ADHCS SHOULD BE CLOSED FIRST DURING THE OPERATION OF CLOSING CIRCUIT BREAKERS. 注意: 当ADHC断电时，传感器将自动加温。为了防止设备被烧坏，在闭合跳开关的操作过程中，应首先闭合ADHC的跳开关。 (f) Remove the tag(s) and/or the safety clip(s) and close/unlock this(these) circuit breaker(s): 拆下标签和/或保险夹并闭合/解锁以下跳开关: Circuit breaker: 跳开关: <table border="1"> <tr> <td>PANEL 面板</td> <td>CB name 跳开关名称</td> <td>CB number 跳开关编号</td> <td>Type 类型</td> </tr> <tr> <td>EDP</td> <td>ADHC2</td> <td>EDP-B-4</td> <td>TCB</td> </tr> <tr> <td>CBIC</td> <td>ADHC1</td> <td>RPDU25-3-11</td> <td>SSPC</td> </tr> <tr> <td>CBIC</td> <td>ADHC3</td> <td>RPDU26-4-9</td> <td>SSPC</td> </tr> </table> (g) Remove the tag(s) and/or the safety clip(s) and close/unlock this(these) circuit breaker(s):		CBIC	OET1	RPDU11-8-6	SSPC	CBIC	OET2	RPDU26-4-15	SSPC	PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型	EDP	ADHC2	EDP-B-4	TCB	CBIC	ADHC1	RPDU25-3-11	SSPC	CBIC	ADHC3	RPDU26-4-9	SSPC		C
CBIC	OET1	RPDU11-8-6	SSPC																								
CBIC	OET2	RPDU26-4-15	SSPC																								
PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型																								
EDP	ADHC2	EDP-B-4	TCB																								
CBIC	ADHC1	RPDU25-3-11	SSPC																								
CBIC	ADHC3	RPDU26-4-9	SSPC																								
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 22 of 26																									

Job Card 工卡号: C193405001001-1																																																																																															
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检																																																																																												
拆下标签和/或保险夹并闭合/解锁以下跳开关: Circuit breaker: 跳开关: <table><tr><td>PANEL 面板</td><td>CB name 跳开关名称</td><td>CB number 跳开关编号</td><td>Type 类型</td></tr><tr><td>RICBP</td><td>D-ISS-PU</td><td>R-ICBP-B-15</td><td>TCB</td></tr><tr><td>EDP</td><td>EDP-EMPC-A-LRM</td><td>EDP-A-2</td><td>TCB</td></tr><tr><td>EDP</td><td>RIGHT-PITOT-STATIC</td><td>EDP-G-1</td><td>TCB</td></tr><tr><td>EDP</td><td>AOA-LEFT1</td><td>EDP-G-2</td><td>TCB</td></tr><tr><td>EDP</td><td>LEFT-PITOT-STATIC</td><td>EDP-H-1</td><td>TCB</td></tr><tr><td>LDP</td><td>EDP-EMPC-C-LRM</td><td>LDP-Q-2</td><td>TCB</td></tr><tr><td>RDP</td><td>EDP-EMPC-B-LRM</td><td>RDP-K-3</td><td>TCB</td></tr><tr><td>CBIC</td><td>OET1</td><td>RPDU11-8-6</td><td>SSPC</td></tr><tr><td>CBIC</td><td>LEFT-STATIC1</td><td>RPDU21-3-7</td><td>SSPC</td></tr><tr><td>CBIC</td><td>RIGHT-STATIC1</td><td>RPDU21-4-5</td><td>SSPC</td></tr><tr><td>CBIC</td><td>LEFT-PITOT-PROBE</td><td>RPDU21-7-5</td><td>SSPC</td></tr><tr><td>CBIC</td><td>RIGHT-PITOT-PROBE</td><td>RPDU22-7-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TAT-RIGHT</td><td>RPDU22-8-3</td><td>SSPC</td></tr><tr><td>CBIC</td><td>AOA-RIGHT1</td><td>RPDU23-8-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TAT-LEFT</td><td>RPDU23-8-3</td><td>SSPC</td></tr><tr><td>CBIC</td><td>LEFT-STATIC3</td><td>RPDU24-3-3</td><td>SSPC</td></tr><tr><td>CBIC</td><td>AOA-LEFT2</td><td>RPDU24-7-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>RIGHT-STATIC3</td><td>RPDU26-3-2</td><td>SSPC</td></tr><tr><td>CBIC</td><td>TSA-RELAYS-POWER</td><td>RPDU26-4-10</td><td>SSPC</td></tr><tr><td>CBIC</td><td>OET2</td><td>RPDU26-4-15</td><td>SSPC</td></tr><tr><td>CBIC</td><td>ISS-PU</td><td>RPDU26-7-1</td><td>SSPC</td></tr><tr><td>CBIC</td><td>AOA-RIGHT2</td><td>RPDU26-7-3</td><td>SSPC</td></tr></table> (h) Do the test for the ADHC 1, 2, 3. Refer to Air data probe heating system-Operational test,MPP C919-A-30-31-00-00A-320A-A . 执行ADHC1, 2, 3的测试。参考大气数据探头加热系统 - 操作测试, MPP C919-A-30-31-00-00A-320A-A。 C. Close-Up 结束		PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型	RICBP	D-ISS-PU	R-ICBP-B-15	TCB	EDP	EDP-EMPC-A-LRM	EDP-A-2	TCB	EDP	RIGHT-PITOT-STATIC	EDP-G-1	TCB	EDP	AOA-LEFT1	EDP-G-2	TCB	EDP	LEFT-PITOT-STATIC	EDP-H-1	TCB	LDP	EDP-EMPC-C-LRM	LDP-Q-2	TCB	RDP	EDP-EMPC-B-LRM	RDP-K-3	TCB	CBIC	OET1	RPDU11-8-6	SSPC	CBIC	LEFT-STATIC1	RPDU21-3-7	SSPC	CBIC	RIGHT-STATIC1	RPDU21-4-5	SSPC	CBIC	LEFT-PITOT-PROBE	RPDU21-7-5	SSPC	CBIC	RIGHT-PITOT-PROBE	RPDU22-7-1	SSPC	CBIC	TAT-RIGHT	RPDU22-8-3	SSPC	CBIC	AOA-RIGHT1	RPDU23-8-1	SSPC	CBIC	TAT-LEFT	RPDU23-8-3	SSPC	CBIC	LEFT-STATIC3	RPDU24-3-3	SSPC	CBIC	AOA-LEFT2	RPDU24-7-1	SSPC	CBIC	RIGHT-STATIC3	RPDU26-3-2	SSPC	CBIC	TSA-RELAYS-POWER	RPDU26-4-10	SSPC	CBIC	OET2	RPDU26-4-15	SSPC	CBIC	ISS-PU	RPDU26-7-1	SSPC	CBIC	AOA-RIGHT2	RPDU26-7-3	SSPC		
PANEL 面板	CB name 跳开关名称	CB number 跳开关编号	Type 类型																																																																																												
RICBP	D-ISS-PU	R-ICBP-B-15	TCB																																																																																												
EDP	EDP-EMPC-A-LRM	EDP-A-2	TCB																																																																																												
EDP	RIGHT-PITOT-STATIC	EDP-G-1	TCB																																																																																												
EDP	AOA-LEFT1	EDP-G-2	TCB																																																																																												
EDP	LEFT-PITOT-STATIC	EDP-H-1	TCB																																																																																												
LDP	EDP-EMPC-C-LRM	LDP-Q-2	TCB																																																																																												
RDP	EDP-EMPC-B-LRM	RDP-K-3	TCB																																																																																												
CBIC	OET1	RPDU11-8-6	SSPC																																																																																												
CBIC	LEFT-STATIC1	RPDU21-3-7	SSPC																																																																																												
CBIC	RIGHT-STATIC1	RPDU21-4-5	SSPC																																																																																												
CBIC	LEFT-PITOT-PROBE	RPDU21-7-5	SSPC																																																																																												
CBIC	RIGHT-PITOT-PROBE	RPDU22-7-1	SSPC																																																																																												
CBIC	TAT-RIGHT	RPDU22-8-3	SSPC																																																																																												
CBIC	AOA-RIGHT1	RPDU23-8-1	SSPC																																																																																												
CBIC	TAT-LEFT	RPDU23-8-3	SSPC																																																																																												
CBIC	LEFT-STATIC3	RPDU24-3-3	SSPC																																																																																												
CBIC	AOA-LEFT2	RPDU24-7-1	SSPC																																																																																												
CBIC	RIGHT-STATIC3	RPDU26-3-2	SSPC																																																																																												
CBIC	TSA-RELAYS-POWER	RPDU26-4-10	SSPC																																																																																												
CBIC	OET2	RPDU26-4-15	SSPC																																																																																												
CBIC	ISS-PU	RPDU26-7-1	SSPC																																																																																												
CBIC	AOA-RIGHT2	RPDU26-7-3	SSPC																																																																																												
Aircraft Effectivity 飞机适用范围: ALL		Page 页码 23 of 26																																																																																													

Job Card 工卡号: C193405001001-1			
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)	Mech 机械员	CHK/INSP 互检/必检
(1) Remove the Antenna Coupler(TC-201) or Antenna Coupler(ZDC-02) from the top TSA . 从上TSA拆下天线耦合器(TC-201) 或 (ZDC-02) 。 (2) Remove the Test Set - Test, Integrated Surveillance System, Distance Measuring Equipment(TR-220) . 拆下ISS测试设备测距仪 (TR-220) 。 (3) Make sure that the work area is clean and clear of tools and other items. 确保工作区域清洁，没有工具和其他物品。 (4) Close the Fwd E/E compartment back door 821A . Refer to Fwd E/E equipment compartment back door-Close from outside after access procedure,MPP C919-A-52-43-00-00A-740B-A . 关闭前E/E舱后门821A。参考前E/E舱后门 - 结束接近后从外部关闭程序, MPP C919-A-52-43-00-00A-740B-A。 (5) Install the protective covers of pitot probe, static port, pitot-static probe, TAT sensor and the AOA sensor. 安装皮托管，静压孔，全静压管，TAT探头和AOA传感器的保护套。 WARNING: MAKE SURE THAT PERSONS AND EQUIPMENT ARE FAR AWAY FROM THE PATH OF THE RAT DEPLOYMENT AND RAT COMPARTMENT DOOR OPENING. BECAUSE FAST DEPLOYMENT OF THE RAT AND OPENING OF THE RAT COMPARTMENT DOOR CAN CAUSE INJURY TO PERSONS AND DAMAGE TO EQUIPMENT. 警告： 确保人员和设备远离RAT放出和RAT舱门打开的路径，因为RAT的快速放出和RAT舱门的打开会造成人员受伤和设备损坏。 (6) After all maintenance work is completed, remove the RAT stow lock pins(AGE19021) . Refer to RAT stow lock pin - Removal, MPP C919-A-24-23-00-00A-520A-A . 所有维护工作完成后，拆下RAT收上锁销（AGE19021）。参考RAT收上锁销-拆卸, MPP C919-A-24-23-00-00A-520A。 (7) De-energize the aircraft electrical circuits. Refer to De-energize the aircraft electrical circuits (Task Selection)-De-energize electrical network,MPP C919-A-24-00-00-00A-561A-A . 断开飞机电路。参考飞机断电(任务选择) - 电网断电, MPP C919-A-24-00-00-00A-561A-A。 (8) Remove all tools, equipment and unwanted materials from the work area. 从工作区域移走所有工具，设备和多余的材料。			
Aircraft Effectivity 飞机适用范围: ALL			Page 页码 24 of 26

M A 1234 100% 0.45-20.35-0.45 PASS	M C Only PASS	Undesrd Rply PASS
1-1	1-10	1-19
M A Rply 3.11us P M A Jitter 25ns P	SI Lockout PASS 18 sec	ACQ: PASS 900 ms ADD: 800000 II:0
1-2	1-11	1-20
M A 1234 IDENT 100% 0.45-20.35-0.45 PASS	M S Surv ID 1234 FS: AIR 100%	EXT: PASS ADD: 40000000 II:0
1-3	1-12	1-21
M C 6520 10000' 100% 0.45-20.35-0.45 PASS	M S Surv Alt 10000' 100%	Max True Spd GT 300 & LE 600kts
1-4	1-13	1-22
M C Rply 3.11us P M C Jitter 25ns P	IND: VT???? 10000' 800000 VS:AIR 100%	Diversity 800000 PASS 29dB Attn
1-5	1-14	1-23
SLS P1>P2 100%PASS P1=P2 0%PASS	IND: VT???? 10000' 40000000 VS:AIR 100%	A:-79.2dB C:-78.5dB Mode S:-74.8dB PASS
1-6	1-15	1-24
M A All Call 800000 100%	M S Comm Id 1234 00000000 100%	Rply Dlay 128.20us P MS Jitter 50ns P
1-7	1-16	1-25
M C All Call 800000 100%	M S Comm Alt 10000' 100%	MS Ampl Var. PASS MS Pulse Width PASS
1-8	1-17	1-26
M A Only PASS	M S Long Air 43000' 7800CB 100%	Power,Frequency 54 dBm 1090.0Mhz
1-9	1-18	1-27

Job Card 工卡号		C193405001001-1					
JC Title 工卡标题	FUNCTIONAL CHECK - ATC TRANSPONDER (RVSM) 功能检查 - 应答机(RVSM)						
N/A DESCRIPTION PAGE FOR AIRCRAFT MAINTENANCE 飞机维护N/A原因说明页							
PAGE NO 工卡页码	ITEM NO 项目号	N/A REASON N/A原因					SIGNATURE 签名
		1	2	3	4	OTHER 其他	
Note/注: 1. Non-applicable Aircraft configuration (with different components installed, or different aircraft line number); 飞机构型不符（所装部件或飞机流水号不符等）; 2. Non-applicable status as specified in the task card, it means the steps unnecessary to be implemented included in the selective items; 与工卡所描述的状态不符，指选择类项目中不必进行的步骤; 3. Different implementation method is chosen; 施工方法选择不同; 4. Non-applicable SB status. SB状态不符。 ***END OF CARD***							
Aircraft Effectivity 飞机适用范围: ALL							Page 页码 26 of 26