

AZAD INDIA MOBILITY LIMITED
Preventive Maintenance Service Checklist
Check Sheet (A) - 20000 KMs

Date of Inspection		Vehicle Reg. No	
Depot		Odometer Reading	

Status mark	(V) OK	(RR)-Repair Recommended	(RI)-Repair Immediately	
-------------	--------	-------------------------	-------------------------	--

Max. Labour Time	Start Time	End Time	Total Time
Minutes			

Sr. No	Check Parameter	Inspection Method	STD Time (Minutes)	Status	Remarks
--------	-----------------	-------------------	--------------------	--------	---------

I. Check Bus Exterior

1	All Lamp Glasses both Front/Side / Rear	Visual			
2	All Flap Door Lock and Shockers, LHS	Visual			
3	Rear Flap Door Lock and Shockers	Visual			
4	All Flap Door Lock and Shockers, RHS	Visual			
5	Function of Hydraulic & Screw Jacks	Functional			
6	Driver Door Window Glass/ Door Locks	Visual			
7	Uneven body level, one side or both the side	Visual			
8	Check the exterior of the vehicle body for paint peeling and cracks	Visual			

II. Lubrication, Coolant, Oil, and Water level checks

9	Centralized Lubrication System, Grease Level, if required top up the grease	Visual			
10	Check all Grease Nipple & Fitting	Visual			
11	Power Steering Reservoir Oil level	Visual			
12	Radiator (Motor System), Coolant level	Visual			
13	Expansion tank (HV Battery System) Coolant Level	Visual			
14	Wiper Reservoir, Water Level	Visual			
15	Check Differential Oil, Level	Repair			
16	Propeller Shaft, Lubricate the grease	Lubrication			
17	Check the level of Compressor oil	Visual			

III. Check Driver Cabin,

18	Driver Seat Adjustment/ Seat Belt	Functional			
19	Co-Driver Seat adjustment / Seat Belt	Functional			
20	Inner View Mirror / Clock Time/ VTS	Functional			

IV. Check After Ignition Key On,

21	Instrument Cluster Warning Symbols & function of all Gauges	Functional			
22	Fault Codes in the Instrument Cluster	Functional			
23	Internal and external lightings	Functional			
24	Check Wiper Motor/ Blade/Arm/Link assembly	Functional			
25	Rear view mirror Position / Function	Functional			
26	Passenger door openings and closing	Functional			
27	Brake Pedal Free Play	Functional			
28	Hand Brake Function	Functional			

29	Suspension Function Check, Kneeling/Normal	Functional			
30	Suspension Function Check, High / Low	Functional			
31	Gear Function Test	Functional			
32	Horn function	Functional			
33	Brake Light and Reverse Light / Warning alarm	Functional			

V. Check Bus Interiors,

34	All Camera Function	Functional			
35	Emergency Alarm/ Panic Switch, Function	Functional			
36	MIC announcement / Speaker	Functional			
37	Charging USB Ports, Passenger seat	Functional			
38	Function of TV and Radio	Functional			
39	Destination Board Mountings & Function	Functional			
40	Passenger Seat Hand Rests	Visual			
41	First Aid box, Fulfilment.	Visual			
42	Roof Emergency Exit (Roof Hatches) both Front & Rear	Visual			
43	Availability of Fire extinguishers and emergency hammers are complete	Visual			

VI. Traction Motor, Radiator

44	No coolant leakage at all parts of the Drive motor and system	Visual			
----	---	--------	--	--	--

VII. Electric Air pump (Air Compressor),

45	Check Oil is 1 / 2 to 2 / 3 of the sight glass port	Visual/Top up			
46	No oil leakage at all parts of the Air pump and the oil seal.	Visual			
47	Clean the air filter with 4 bar compressed air.	Repair			
48	Check Air Compressor Flexible Pipe (Outlet)	Visual			
49	Check Temperature Sensor Condition	Visual			

VIII. Electric Steering Pump, Steering System & Tie-Rod

50	No Oil leakage of all parts of electric steering pump.	Visual			
51	Check Tie rod & Drag rod ball Joints / Dust Cover, Normal clearance $\leq 1.8\text{mm}$	Visual & Functional			
52	Steering rocker Arm, No looseness	Visual			
53	Check and make sure the Left & Right steering Knuckle arm have no crack	Visual			
54	Check and make sure the slotted nuts have no crack.	Visual			
55	Check Oil Level if required top up	Visual			
56	Inspect the Tie rod and confirm that there is no Deformation, Bend and Crack	Visual			
57	Inspect all the Fastening bolts and Nuts, confirm that there is no Deformation, Bend and Crack	Visual			

IX. Transmission shaft (Propeller Shaft),

58	Check Fastening bolts & Nuts, No loose	Functional			
59	Check the universal joint, No Damage/Loose	Visual			

X. Front and Rear axles,

60	Inspect "I" Beam and Confirm that there is no Crack	Visual			
61	Front Hub Cup Cover Gasket, Grease Leak (External)	Visual			
62	Rear Hub, Axle Shaft Gasket grease or Oil leak (External)	Visual			

63	Axle Half shaft bolt, not loose	Functional			
64	Check Differential oil leak	Visual			
65	Check Pinion Oil Leak	Visual			
66	Inspect the Housing and confirm that there is no Deformation, Bend and Crack	Visual			
67	From rear axle, Inspect and confirm that there is no oil leak on the Junction surface between Drive Head and Housing	Visual			
68	Inspect and confirm that, there is no Oil leak on Rear axle Housing Welding line	Visual			
69	Inspect and confirm that, there is no Oil leak on Drain Plug (rear axle)	Visual			
70	Check Diff. Air breather plug should be not lost	Visual			
71	Clean the Diff. Breather Pipe every 10K KMS	Repair			

XI. Brakes & Pneumatic System,

72	Inspect the Operating state of Brake Chamber	Functional			
73	Check the working condition of the Brake adjusting mechanism.	Functional			
74	Brake Clearance Adjustment for all wheels	Functional			
75	Air Pressure building up time	Functional			
76	Check air pressure regulator Cut out and Cut In pressure	Functional			
77	Press Brake, check air Leakage / Pressure drop	Functional			
78	Check Air leakage in pneumatic system	Visual			

XII. LV Battery & Fuse Box,

79	Battery Surface is clean	Visual			
80	Check Battery Terminals/ Top bracket, No loose	Functional			
81	Check battery voltage should be over 27V at IC (after start)	Functional			
82	Apply Petroleum Jelly on Terminals	Repair			
83	Check Front & Rear Fuse box and Relays	Visual			

XIII. Suspension,

84	Check Air Bellows, Leak	Visual			
85	Check Air Bellows, Heights & adjust if required	Visual			

XIV. Tyres

86	All the Tyre condition incl. Spare wheel (Damage/Under Inflation/Stone remove)	Visual			
87	Check Tyre wear	Visual			
88	Check the Torque of Wheel Nuts (No loose)	Repair			

XV. EV Charging Socket,

89	Clean the inner side of the Charging Socket (Contact point) both 1 & 2.	Clean			
----	---	-------	--	--	--

XVI. Air Condition,

90	Return Grill Air Filter	Clean			
91	Evaporator Air Filter	Clean			
92	Condenser Coil	Clean			
93	Check the Control Panel for its normal Operation	Functional			
94	Check abnormal noisy from the A/C system	Functional			
95	Check A/C System for adequate cooling	Functional			
96	Operation of Condenser Fan	Visual			
97	Operation of Evaporator Blower	Visual			
98	Check for any abnormal noisy from Compressor	Visual			

99	Check the refrigerant amount by Sight Glass	Visual			
100	Check the pipe joints for oil stain, it signs of Oil / Gas leakage	Visual			
101	Check all the pipeline is reliably secured	Visual			
102	Check Compressor Mountings	Visual			
103	Inspect all Electric Component mountings	Visual			

Inspected by - Employ. Name		Supervisor Name	
Signature		Signature	

Sr. No	Comments & Remarks if any