

Sentera RTK PPK Module Checkout	
Performed By:	
Date:	
Module Serial Number:	
Module Radio Net ID	
Sensor Serial Number:	
Checkout Type (circle one):	Module / Sensor
RMA Number:	
System Setup - Indoors	Check / Fill In / Circle
Sensor Setup	
List sensor type (circle one)	6X / 6XT / 6XTP / 65R
Verify intended aircraft (circle one)	IF800 / IF1200
Verify sensor has Gen II or greater markings <i>sensor will not work with the RTK PPK hardware without Gen II upgrades</i>	
Verify sensor configuration <i>sensor must have Aircraft-Sentera GNSS config applied</i>	
Aircraft Setup	
Install sensor onto aircraft	
Install module onto aircraft	
Connect coax cable to module and aircraft <i>IF800: MCX to MCX cable and aircraft pass through</i> <i>IF1200: MCX to SMA with rail mounted bracket</i>	
Install 900Mhz antenna to aircraft	
Connect module to sensor via USB-C to USB-C cable	
Secure cable with cable clips	
Aircraft Hand Controller Setup	
Power on handcontroller	

Connect controller to hotspot / internet	
Open IGC	
Open the NTRIP menu <i>(Located top center, T Icon with ({}))</i>	
Enter NTRIP credentials	
Select mountpoint	
Verify connection to NTRIP network	
Disconnect from NTRIP network & power off	
Choose Base Station OR Laptop NTRIP Setup	
Emlid Base Station	
Power on	
Connect to base station WiFi	
Verify base station output is set to USB OTG 115200	
Connect ground radio to Emlid using USB-C to USB-C cable	
Verify the ground radio has green scrolling LEDs <i>(if RTK-PPK module is powered on the LEDs will be solid green on ground radio)</i>	
Power down	
Laptop NTRIP <i>(Not needed if Emlid Base Station above is completed - skip to System Testing-Outdoors)</i>	
Power on laptop	
Connect ground radio to laptop via USB-C cable	
Verify the ground radio has green scrolling LEDs	
Connect laptop to hotspot/internet source	
Open an NTRIP client <i>(can be found on Evault under 27300 folder)</i>	
Connect to NTRIP network & set mountpoint	
Enter current LAT/LON/ALT of current location	

Set output to serial with appropriate COM port and bitrate (115200)	
Start corrections stream and verify output	
Disconnect from NTRIP network	
System Testing - Outdoors	
Ground Radio Checkout (Base Station or Laptop NTRIP)	
Selection ground radio corrections source type	Base Station / Laptop NTRIP
Setup base station / laptop	
Verify corrections are ready <i>Base Station: Self survey is complete</i> <i>Laptop: corrections stream is running</i>	
Power on aircraft	
Verify status LED on module illuminates solid red	
Power on hand controllers and open IGC	
Verify status LED on module turns green	
Verify the sensor starts a session	
Verify GPS fix type	Standard GPS / RTK Float / RTK Fixed
Verify module achieves an RTK Fixed solution	
Webpage verification <i>Open web browser on hand controller and navigate to 192.168.144.141</i>	
Sentera camera interface verification <i>Camera icon in the upper right hand corner of IGC v1.4 and greater</i>	
Take 5 images	
Power down ground radio	
Verify the the GPS status returns to standard GPS	
Webpage verification <i>Open web browser on hand controller and navigate to 192.168.144.141</i>	
Sentera camera interface verification <i>Camera icon in the upper right hand corner of IGC v1.4 and greater</i>	
Hand Controller NTRIP	
Connect hotspot to hand controller	

Open NTRIP menu in IGC (Located top center, ((T)) Icon)	
Connect to the NTRIP network	
Verify the GPS fix type	Standard GPS / RTK Float / RTK Fixed
Verify module achieves an RTK Fixed solution	
Sentera camera interface verification <i>Camera icon in the upper right hand corner of IGC v1.4 and greater</i> DO NOT USE WEBPAGE	
Take 5 images	
Power down systems	
Disconnect and Pack System	
Remove USB-C to USB-C Cable and clips and pack in RTK-PPK case	
Remove 900 Mhz antenna from aircraft and pack in RTK-PPK case	
Disconnect coax cable from module and aircraft, pack in RTK-PPK case	
Remove module from aircraft, pack in RTK-PPK case	
Ensure all remaining items originally in RTK-PPK case are placed back inside	
Data Retention - Indoors	
Navigate to: \\taurus\production\System & Kits\21076-XX -- RTK PPK Module	
Create a folder with the module serial number as the folder name If this is for a camera RMA place these item into the appropriate RMA folder	
Place data into the folder	
Scan and upload a copy of this document to the same folder	