

Data Hiway, Box/Slot, and Data Point Forms

HG88-600

Implementation Configuration Forms

Data Hiway, Box/Slot, and Data Point Forms

HG88-600
Release 681

09/08

NOTE

This document was last updated for R681.
For information about those parameters introduced post R681,
refer to the Hiway Gateway Parameter Reference Dictionary.

Notices and Trademarks

Copyright 2002 – 2008 by Honeywell Inc.
Revision 7 September 2008

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customers.

In no event is Honeywell liable to anyone for any indirect, special or consequential damages. The information and specifications in this document are subject to change without notice.

Honeywell and **TotalPlant** are registered trademarks of Honeywell International Inc.

Other brand or product names are trademarks of their respective owners.

Honeywell International
Process Solutions
2500 West Union Hills Drive
Phoenix, AZ 85027
1-800 343-0228

About This Publication

This publication supports **TotalPlant** Solution (TPS) System network Releases 500 - 681. TPS is the evolution of TDC 3000^X.

This manual consists of configuration forms. These forms are designed to facilitate the collection and organization of data for subsequent entry into the TPS system through the Universal Station.

Support and Other Contacts

Location	Organization	Address	Phone/Facsimile
United States and Canada	Honeywell Solution Support Center	Honeywell TAC, MS P13, 2500 West Union Hills Drive, Phoenix, AZ, 85027	Phone: 1-800 822-7673 602- 313-5558 (In Arizona) Facsimile: (602) 313-3293
Note: Calls are answered by dispatcher between 6:00 A.M. and 4:00 P.M. Mountain Standard Time. Emergency calls outside normal working hours are received by an answering service and returned within one hour.			
Europe	Honeywell TAC-EMEA	TAC-BE02 Hermes Plaza Hermeslaan, 1HB-1831 Diegem, Belgium	Phone: +32-2-728-2732 Facsimile: +32-2-728-2696
Pacific	Honeywell Global TAC – Pacific	Honeywell Limited Australia 5 Kitchener Way Burswood 6100, Western Australia Email: GTAC@honeywell.com	Phone: 1300-300-4822 (toll free within Australia) +61-8-9362-9559 (outside Australia) Facsimile: +61-8-9362-9564
India	Honeywell Global TAC – India	Honeywell Automation India Ltd. 56 and 57, Hadapsar Industrial Estate Hadapsar, Pune –411 013, India Email: Global-TAC- India@honeywell.com	Phone: +91-20- 66039400 Facsimile: +91-20- 66039800
Korea	Honeywell Global TAC – Korea	Honeywell Co., Ltd 17F, Kikje Center B/D, 191, Hangangro-2Ga Yongsan-gu, Seoul, 140- 702, Korea Email: Global-TAC- Korea@honeywell.com	Phone: +82-2-799-6317 +82-11-9227-6324 Facsimile: +82-2-792-9015

Support and Other Contacts

Location	Organization	Address	Phone/Facsimile
People's Republic of China	Honeywell Global TAC – China	Honeywell (China) Co., Ltd 33/F, Tower A, City Center, 100 Zunyi Rd., Shanghai 200051, People's Republic of China Email: Global-TAC-China@honeywell.com	Phone: +86- 21-52574568
Singapore	Global TAC – South East Asia	Honeywell Private Limited Honeywell Building 17, Changi Business Park Central 1, Singapore 486073 Email: GTAC-SEA@honeywell.com	Phone: +65-6580-3500 Facsimile: +65-6580-3501 +65-6445-3033
Taiwan	Global TAC – Taiwan	Honeywell Taiwan Ltd. 17F-1, No. 260, Jhongshan 2nd Road, Cianjhen District Kaohsiung, Taiwan, ROC Email: Global-TAC-Taiwan@honeywell.com	Phone: +886- 7- 536 2567 Facsimile: +886-7-536 2039
Japan	Global TAC – Japan	Honeywell Japan Inc. New Pier Takeshiba, South Tower Building, 20th Floor, 1-16-1 Kaigan, Minato-ku, Tokyo 105-0022, Japan Email: Global-TAC-JapanJA25@honeywell.com	Phone: +81-3-6730-7160 Facsimile: +81-3-6730-7228
Elsewhere	Call your nearest Honeywell office.		
World Wide Web	Honeywell Solution Support Online: http://www.honeywell.com/ps		
Training Classes	Honeywell Automation College: http://www.automationcollege.com		

Table of Contents

Error! No table of contents entries found.

Hiway Configuration Form.....	SW88-630
HG Box Data Point Configuration Form.....	SW88-631
CB Box Data Point Configuration Form.....	SW88-632
DHP/620-HIM Box Data Point Configuration Form.....	SW88-633
EC Box Data Point Configuration Form.....	SW88-634
HLPIU Box Data Point Configuration Form.....	SW88-635
LEPIU Box Data Point Configuration Form.....	SW88-636
LLPIU Box Data Point Configuration Form.....	SW88-637
MC Box Data Point Configuration Form.....	SW88-638
AU, GPCI, H4500 & RCDBox Data Point Configuration Form.....	SW88-639

CB REGULATORY DATA POINT CONFIGURATION FORM	9	
CB REGULATORY DATA POINT CONFIGURATION FORM	14	
CB REGULATORY DATA POINT CONFIGURATION FORM	15	
DHP/620-HIM ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM		17
DHP/620-HIM ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	21	
DHP/620-HIM DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM		25
DHP/620-HIM DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM		26
DHP/620-HIM DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM		28
DHP/620-HIM DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	29	
DHP/620-HIM DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	30	
DHP/620-HIM DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	32	
DHP/620-HIM COUNTER DATA POINT CONFIGURATION FORM	33	
EC DIGITAL INPUT DATA POINT CONFIGURATION FORM	35	
EC DIGITAL INPUT DATA POINT CONFIGURATION FORM	36	
EC REGULATORY DATA POINT CONFIGURATION FORM	37	
EC REGULATORY DATA POINT CONFIGURATION FORM	38	
EC REGULATORY DATA POINT CONFIGURATION FORM	39	
EC REGULATORY DATA POINT CONFIGURATION FORM	40	
EC REGULATORY DATA POINT CONFIGURATION FORM	43	
EC REGULATORY DATA POINT CONFIGURATION FORM	45	
EC REGULATORY DATA POINT CONFIGURATION FORM	46	
HLPIU ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	47	
HLPIU ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	51	
HLPIU ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	53	
HLPIU ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	54	
HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	55	
HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	56	
HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	57	
HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	58	
HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	59	
HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	60	
HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	61	
HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	62	
HLPIU COUNTER (16-BIT) DATA POINT CONFIGURATION FORM	63	
HLPIU COUNTER (16-BIT) DATA POINT CONFIGURATION FORM	64	
HLPIU CONTROL COUNTER (32-BIT) DATA POINT CONFIGURATION FORM	65	
LEPIU ANALOG INPUT DATA POINT CONFIGURATION FORM	67	
LLPIU ANALOG INPUT DATA POINT CONFIGURATION FORM	71	
MC ANALOG INPUT DATA POINT (WITH ACCUMULATION) CONFIGURATION FORM		75
MC ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	79	
MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	83	
MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	84	

MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	85
MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM	86
MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	87
MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	88
MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	89
MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM	90
MC DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	91
MC DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	92
MC DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM	93
MC COUNTER DATA POINT CONFIGURATION FORM	95
MC COUNTER DATA POINT CONFIGURATION FORM	96
MC PROCESS MODULE DATA POINT CONFIGURATION FORM	97
MC REGULATORY DATA POINT CONFIGURATION FORM	99
MC REGULATORY DATA POINT CONFIGURATION FORM	100
MC REGULATORY DATA POINT CONFIGURATION FORM	101
MC REGULATORY DATA POINT CONFIGURATION FORM	102
MC REGULATORY DATA POINT CONFIGURATION FORM	103
MC REGULATORY DATA POINT CONFIGURATION FORM	104
MC REGULATORY DATA POINT CONFIGURATION FORM	105
MC REGULATORY DATA POINT CONFIGURATION FORM	107
MC FLAG DATA POINT CONFIGURATION FORM	109
MC FLAG DATA POINT CONFIGURATION FORM	110
MC NUMERIC DATA POINT CONFIGURATION FORM	111
MC TIMER DATA POINT CONFIGURATION FORM	113
HIWAY CONFIGURATION FORM	115
MC LOGIC BLOCK DATA POINT CONFIGURATION FORM	117
HG BOX DATA POINT CONFIGURATION FORM	119
BATCH ASSIGN DATA POINT CONFIGURATION FORM	121
CB BOX DATA POINT CONFIGURATION FORM	123
DHP/620-HIM BOX DATA POINT CONFIGURATION FORM	125
EC BOX DATA POINT CONFIGURATION FORM	133
HLPIU BOX DATA POINT CONFIGURATION FORM	135
LEPIU BOX DATA POINT CONFIGURATION FORM	147
LLPIU BOX DATA POINT CONFIGURATION FORM	149
MC BOX DATA POINT CONFIGURATION FORM	151
SW88-639	155
AU, GPCI, H4500 & RCD BOX DATA POINT CONFIGURATION FORM	155

[illegible]

HG PV CONFIGURATION DISPLAY									
20	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _ _	(Default = All Blanks)						
21	CHARACTERIZATION (PVCHAR)	LINEAR	JTHERM	KTHERM	TTHERM				
		STHERM	SQRR00T	BURNSRDT	RADIAMAT				
		(Default = LINEAR)							
22	INPUT CONDITIONING (INPTCOND)	LINEAR	SQRR00T	(Default = LINEAR)					
23	PV DECIMAL FORMAT (PVFORMAT)	D0 D1	D2 D3	(Default = D0)					
24	TEMP DISPLAY (PVTEMP)	DEGREESF	DEGREESC	(Default = DEGREESF)					
25	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0)						
25A	PV DISPLAY LOW (PVDSPL0)	_ _ _ _ _ _ _	(Default = NaN)						
26	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0)						
26A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)						
27	TARGET (SP)	_ _ _ _ _ _ _	(Default = 0.0)						
28	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0%)						

CB RV DATA POINT CONFIGURATION FORM

PV CONFIGURATION DISPLAY

29	PV RANGE (PVRNGOP)	OPTION	NONE	FULLRNG	CLMPZERO (Default = NONE)
30	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)	
31	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _	(Default = 0.0)		

HG ALARMING DISPLAY

39	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later		
40	ALARM FORMAT (ALFMT)	NO ALARM	ALFMT00	(Default = ALFMT00)	
40A	ALARM DELAY OPTION (\$ALDLOPT)	NONE ONDLYLO	OFFDLYLO ONDLYHI	OFFDLYHI ONDLYEM	OFFDLYEM
(Default = NONE)					
40B	DELAY TIME (DLYTIME)	_ _ _ _ _ _ _	(Default = 0.0)		
40C	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _	(Default = 0) R660 & later		
41	PVLOTP (PVLOTP)	_ _ _ _ _ _ _	(Default = 0)		
42	PVHITP (PVHITP)	_ _ _ _ _ _ _	(Default = 0)		
43	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT
(Default = NOACTION)(R670)					
44	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT
(Default = NOACTION)(R670)					
44A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)	
45	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT
(Default = NOACTION)(R670)					
45A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)	
45B	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = LOW)	
46	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)

CB RV DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
46A PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _	(Default = All Underscores)		
47 EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _	(Default = All Underscores)		
48 EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGHR	RETURN LOW	(Default = Any) LOWR
49 EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)	
50 ALARM ENABLE STATUS (ALENBST)	ENABLE	<u>Displayed</u> Yes	<u>Logged</u> Yes	<u>Reported to EIP</u> Yes
	DISABLE	No	Yes	Yes
	INHIBIT	No	No	No
	(Default = ENABLE)			

[illegible]

NOTES: 1. For Lines 41-73, refer to the name of the algorithm in the HG Parameter Reference Dictionary to determine which lines have to be filled out.

2. Use Configuration Form HG88-603 if OVERHISL or OVERLOSL is to be configured.

20	EU. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)
21	CHARACTERIZATION (PVCHAR)	LINEAR STHERM	JTHERM SORROOT
		KTHERM BURNS	TTHERM(Default = LINEAR) RADIAMAT

CB REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISL and OVERLOSL)

HG PV CONFIGURATION DISPLAY					
22	INPUT CONDITIONING (INPTCOND)	LINEAR	SQRR00T	(Default = LINEAR)	
22A	PV DECIMAL FORMAT (PVFORMAT)	D0	D1	D2	D3 (Default = D0)
22B	TEMP DISPLAY (PVTEMP)	DEGREESF	DEGREESC	(Default = DEGREESF)	
23	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0)		
23A	PV DISPLAY LOW (PVDSPLO)	_ _ _ _ _ _ _	(Default = NaN)		
24	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0)		
24A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)		
25	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0%)		
26	PV RANGE OPTION (PVRNGOP)	NONE	FULLRNG	CLMPZERO	(Default = NONE)
27	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)	
28	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _	(Default = 0.0)		
HG ALARMING DISPLAY					
29	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later		
30	ALARM FORMAT (ALFMT)	ALFMT00	ALFMT01	(Default = ALFMT00)	
30i	ALARM DELAY OPTION (\$ALDLOPT)	NONE	OFFDLYLO	OFFDLYHI	OFFDLYEM
		ONDLYLO	ONDLYHI	ONDLYEM	(Default = NONE)
30ii	DELAY TIME (DLTIME)	_ _ _ _ _ _ _	(Default = 0.0)		
30iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _	(Default = 0) R660 & later		
30A	PVLOTP (PVLOTP)	_ _ _ _ _ _ _	(Default = 0.0)		
30B	PVHITP (PVHITP)	_ _ _ _ _ _ _	(Default = 0.0)		
30C	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _	(Default = 0.0%)		
30D	DEVHITP (DEVHITP)	_ _ _ _ _ _ _	(Default = 0.0%)		
30E	OP ALARM ENABLE (\$OPALEN)	DISABLE	ENABLE	(Default = DISABLE)	
30F	OP ALARM DEADBAND (OPALDB)	_ _ _ _ _ _ _	(Default = 5.0)		
30G	OPLOTP (OPLOTP)	_ _ _ _ _ _ _	(Default = 0.0)		
30H	OPHITP (OPHITP)	_ _ _ _ _ _ _	(Default = 0.0)		

CB REGULATORY DATA POINT CONFIGURATION FORM

(For all algorithms except OVERHISL and OVERLOSL)

HG ALARMING DISPLAY

31	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
32	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
32A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELECT)	CUTOUT ALLOW (Default = CUTOUT)(R681)	

HG PV CONFIGURATION DISPLAY

33	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
33A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELECT)	CUTOUT ALLOW (Default = CUTOUT)(R681)	
34	PV HIGH ALARM PRIORITY(PVHIPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
34A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT ALLOW (Default = CUTOUT)(R681)	
35	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
35A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT ALLOW (Default = CUTOUT)(R681)	
35B	OP HIGH ALARM PRIORITY (OPHIPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
35C	OP LOW ALARM PRIORITY (OPLOPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER (Default = NOACTION)(R670)	JNLPRINT
35D	CRITICAL ALARM SCANNING (CRITSCAN)	OFF ON (Default = OFF)	
36	CONTACT CUTOUT RANK (CCRANK)	NEITHER PRIMARY SECNDARY (Default = NEITHER)	
36A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)	
37	EIP POINT (EIPPCODE)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)	

CB REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISL and OVERLOSL)

HG PV CONFIGURATION DISPLAY

38	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH R	RETURN LOW	(Default = Any) LOW R
39	EIP ENABLE (EIPENB)	ENABLE DISABLE (Default = Enable)			
39A	ALARM ENABLE STATUS (ALENBST)		<u>Displayed</u>	<u>Logged</u>	<u>Reported to EIP</u>
		ENABLE	Yes	Yes	Yes
		DISABLE	No	Yes	Yes
		INHIBIT	No	No	No
		(Default = ENABLE)			

HG OPERATING CONFIGURATION DISPLAY

40	DISPLAY SUPPRESSION (SUPPIO)	NOSUPPR	INPSUPPR	OUTSUPPR	(Default = NOSUPPR)
41*	CONTROL ACTION (CTLACTN)	DIRECT	REVERSE		(Default = DIRECT)

HG OPERATING CONFIGURATION DISPLAY

42*	CONTROL EQUATION (CTLEQN)	EQA	EQB		(Default = EQA)
43*	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE		(Default = DIRECT)
44*	PV SIGNAL TYPE (PVSIGNAL)	OUTPUT	PV	RV	LSP (Default = PV)
45*	PV INPUT SOURCE (PVSLT SRC)	_ _ _ _ _ _ _ _ _ (Default = Tag name from Line 1)			

HG PV CONFIGURATION DISPLAY

46*	SP SIGNAL TYPE (SPSIGNAL)	OUTPUT	PV	RV	LSP (Default = LSP)
47*	SP INPUT SOURCE (SPSLT SRC)	_ _ _ _ _ _ _ _ _ (Default = Tag name from Line 1)			
48*	PV TRACKING (PVTRACK)	NOTRACK	TRACK		(Default = NOTRACK)
49*	INITIALIZATION (INITCONF)	NOINIT	INIT		(Default = NOINIT)

CB REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISL and OVERLOSL)

HG OPERATING CONFIGURATION DISPLAY

50* SETPOINT (SP) | | | | | | | (Default = 0.0)
 51* OUTPUT LOW LIMIT(%) | | | | | | | (Default = -5.0%)
 (OPLOLM)
 52* OUTPUT HIGH LIMIT(%) | | | | | | | (Default = 105.0%)
 (OPHILM)
 53* OUTPUT TOLERANCE (%) | | | | | | | (Default = 0.0)
 (\$OPTOL)
 54* INTEGRAL LOW LIMIT | | | | | | | (Default = -5.0)
 (ITLOLM)
 55* INTEGRAL HIGH LIMIT | | | | | | | (Default = 105.0)
 (ITHILM)
 56* FILTER CONSTANT(TD) | | | | | | | (Default = 0.0)
 57* K (K) | | | | | | | (Default = 0.0)
 58* T1 (T1) | | | | | | | (Default = 0.01)
 59* T2 (T2) | | | | | | | (Default = 0.0)
 60* RATIO (RATIO) | | | | | | | (Default = 1.0)
 61* BIAS (BIAS) | | | | | | | (Default = 0.0)
 62* T1 (T1) | | | | | | | (Default = 0.01)[LAG TIME]
 63* T2 (T2) | | | | | | | (Default = 0.01)[LEAD TIME]
 64* K (K) | | | | | | | (Default = 0)[Y SCALE FACTOR]
 65* K1 (K1) | | | | | | | (Default = 0)[X SCALE FACTOR]
 66* K2 (K2) | | | | | | | (Default = 0)[BIAS]

HG MODE CONFIGURATION DISPLAY

(For all algorithms except PIDCMA, PIDCM, PIDSPC, and PIDPL50C)

70* NORMAL MODE MAN AUTO CAS BCAS NONE (Default = NONE)
 (NMODE)
 70A* NORMAL MODE ATTRIBUTE OPERATOR PROGRAM NONE (Default = NONE)
 (NMODATTR)
 71* PAST MODE RECALL NOPASTMR PASTMR (Default = NOPASTMR)
 (PSTMODE)

CB REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISL and OVERLOSL)

HG MODE CONFIGURATION DISPLAY				
(For all algorithms except PIDCMA, PIDCM, PIDSPC, and PIDPL50C)				
72*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)
73*	OPERATING MODE (MODE)			(Default = MAN)
73i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO	PROG CAS	(Default = All are allowed)

HG MODE CONFIGURATION DISPLAY				
(For PIDCMA, PIDCM, PIDSPC, and PIDPL50C algorithms)				
70*	NORMAL MODE (NMODE)	MAN	AUTO	CAS BCAS NONE (Default = NONE)
70A*	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE (Default = NONE)
71*	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR	(Default = NOPASTMR)
72*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)
73*	OPERATING MODE (MODE)			(Default = MAN)
73i	MODE SELECTION LIST are allowed)	MAN (\$MODESEL)	PROG AUTO	BCAS CAS (Default = All)

[illegible]

20	DISPLAY SUPPRESSION (SUPPIO)	NOSUPPR	INPSUPPR	OUTSUPPR	(Default = NOSUPPR)
21	OUTPUT INDICATION (OUTIND)	DIRECT		REVERSE	(Default = DIRECT)
22A	SLOT 1 SELECTION (OVINSS1)	NOSEL		SEL	(Default = NOSEL)
22B	SLOT 2 SELECTION (OVINSS2)	NOSEL		SEL	(Default = NOSEL)
22C	SIGNAL TYPE SLOTS 1 & 2 (SGNLTY12)	OUTPUT		RV	(Default = RV)
23A	SLOT 3 SELECTION (OVINSS3)	NOSEL		SEL	(Default = NOSEL)

CB REGULATORY DATA POINT CONFIGURATION FORM
(For OVERHISL and OVERLOSL Algorithms)

HG OPERATING CONFIGURATION DISPLAY				
23B SLOT 4 SELECTION (OVINSS4)	NOSEL	SEL	(Default = NOSEL)	
23C SIGNAL TYPE SLOTS 3 & 4 (SGNLTY34)	OUTPUT	RV	(Default = RV)	
24A SLOT 5 SELECTION (OVINSS5)	NOSEL	SEL	(Default = NOSEL)	
24B SLOT 6 SELECTION (OVINSS6)	NOSEL	SEL	(Default = NOSEL)	
24C SIGNAL TYPE SLOTS 5 & 6 (SGNLTY56)	OUTPUT	RV	(Default = RV)	
25A SLOT 7 SELECTION (OVINSS7)	NOSEL	SEL	(Default = NOSEL)	
25B SLOT 8 SELECTION (OVINSS8)	NOSEL	SEL	(Default = NOSEL)	
25C SIGNAL TYPE SLOTS 7 & 8 (SGNLTY78)	OUTPUT	RV	(Default = RV)	
26 OUTPUT LOW LIMIT(%) (OPLOLM)	_ _ _ _ _ _ _	(Default = -5)		
27 OUTPUT HIGH LIMIT(%) (OPHILM)	_ _ _ _ _ _ _	(Default = 105)		
28* OUTPUT TORERANCE(%) (\$OPTOL)	_ _ _ _ _ _ _	(Default = 0.0)		
29 FILTER CONSTANT (TD)	_ _ _ _ _ _ _	(Default = 0%)		

HG MODE CONFIGURATION DISPLAY					
40	NORMAL MODE (NMODE)	MAN	AUTO	CAS	NONE (Default = NONE)
40A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR		PROGRAM	NONE (Default = NONE)
41	PAST MODE RECALL (PSTMODE)	NOPASTMR		PASTMR	(Default = NOPASTMR)
42	OPERATOR MODE CHANGE (MODEPERM)	PERMIT		NOPERMIT	(Default = PERMIT)
43	OPERATING MODE (MODE)				(Default = MAN)
43i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO	PROG CAS		(Default = All are allowed)

[illegible]

20	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)
21	OUTPUT TOLERANCE (%) (\$OPTOL)	_ _ _ _ _ _ _		(Default = 0.0)
22	PC BOX INDEX (PNTBOX0T)	_		(Default = 1)
23	PC TYPE (PNTPCTY)	ALLENBRD	MODICON	HONYWELL (Default = ALLENBRD)
23A	OUTPUT PC ADDRESS (PCADDR01)	_ _ _ _ _		(Default = 0)
23B	SPECIFIER CODE (SPECIF01)	_		(Default = 0)
24	PC RANGE CODE (RNGCODE2)	_		(Default = 0)

DHP/620-HIM ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY (For Analog Output Data Point)				
30	NORMAL MODE (NMODE)	MAN	CAS	NONE (Default = NONE)
30	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE (Default = NONE)
31	CASCADE (RCASENB)	OFF	ON	(Default = OFF)
32	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)
33	OPERATING MODE (MODE)			(Default = MAN)
33i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG (Default = All are allowed)

HG PV CONFIGURATION DISPLAY (For Analog Input Data Point)				
40	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _ _		(Default = All Blanks)
41	DECIMAL FORMAT (PVFORMAT)	D0	D1	D2 D3 (Default = D0)
42	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _		(Default = 0.0)
42A	PV DISPLAY LOW (PVDSPL0)	_ _ _ _ _ _ _		(Default = NaN)
43	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _		(Default = 100.0)
43A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _		(Default = NaN)
44	OVERVIEW VALUE (OVERVAL)	_ _ _ _		(Default = 0%)
45	PV RANGE OPTION (PVRNGOP)	NONE	FULLRNG	CLMPZERO (Default = NONE)
45A	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)
46	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _		(Default = 0.0)

DHP/620-HIM ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY (For Analog Input Data Point)	
49	AUXILIARY UNIT (\$AUXUNIT) (Default = - -) R520 & later
50	ALARM FORMAT (ALFMT) ALFMT00 ALFMT01 (Default = ALFMT00)
50i	ALARM DELAY OPTION (\$ALDLOPT) NONE OFFDLYLO OFFDLYHI OFFDLYEM ONDLYLO ONDLYHI ONDLYEM (Default = NONE)
50ii	DELAY TIME (DLYTIME) (Default = 0.0)
50iii	RE-ALARMING INTERVAL (\$REALARM) (Default = 0) R660 & later
50A	PVLOTP (PVLOTP) (Default = 0.0)
50B	PV ALARM DEADBAND (PVALDB) (Default = 0.0)
50C	PVHITP (PVHITP) (Default = 0.0)
50D	DEVLOTP (DEVLOTP) (Default = 0.0%)
50E	DEVHITP (DEVHITP) (Default = 0.0%)
51	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR) NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
52	DEVIATION HIGH ALARM PRIORITY (DEVHIPR) NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
52A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELECT) CUTOUT ALLOW (Default = CUTOUT)(R681)
53	DEVIATION LOW ALARM PRIORITY (DEVLOPR) NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
53A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELECT) CUTOUT ALLOW (Default = CUTOUT)(R681)
54	PV HIGH ALARM PRIORITY (PVHIPR) NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
54A	PV HIGH SELECTIVE CUTOUT (\$HISELCT) CUTOUT ALLOW (Default = CUTOUT)(R681)
55	PV LOW ALARM PRIORITY (PVLOPR) NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
55A	PV LOW SELECTIVE CUTOUT (\$LOSELCT) CUTOUT ALLOW (Default = CUTOUT)(R681)

DHP/620-HIM ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY (For Analog Input Data Point)					
56	UNREASONABLE ALARM PRIORITY (UNREASPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGENCY (R670)	LOW PRINTER (Default = LOW)	JNLPRINT
56A	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON		
57	CONTACT CUTOFF RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)
57A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)			
58	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)			
58A	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW	(Default = Any) LOW_R
59	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)	
HG OPERATING CONFIGURATION DISPLAY (For Analog Input Data Point)					
59A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISBALE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No
60	TARGET (PVTV)	_ _ _ _ _ _ _ _ _ (Default = 0.0)			
61	PC BOX INDEX (PNTBOXIN)	_ _ _ _ _ _ _ _ _ (Default = 1)			
62	PC TYPE (PNTPCTY)	ALLENBRD MODICON HONYWELL (Default = ALLENBRD)			
62A	INPUT PC ADDRESS (PCADDR1)	_ _ _ _ _ _ _ _ _ (Default = 0)			
62B	INPUT SPECIFIER CODE (SPECIFI1)	_ _ _ _ _ _ _ _ _ (Default = 0)			
63	PC RANGE CODE (RNGCODE1)	_ _ _ _ _ _ _ _ _ (Default = 0)			

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
2	UNIT ID (UNIT)	_ _ (Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks) _ _ _ _ _ _ _ _ _ _ _ _ _ _ _
4	POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
7	HIWAY NUMBER (HWYNUM)	_ _ _ (Default = 1)
8	BOX TYPE (PNTBOXTY)	HLPIU MC DHP (Enter DHP)
9	INPUT BOX NUMBER (BOXNUM)	_ _ _ (Default = 00)
10	OUTPUT BOX NUMBER (OUTBOXNM)	_ _ _ (Default = 00)
11	POINT DISCLOSURE (PTDISCL)	BRIEF FULL (Default = BRIEF)
12	INPUT SLOT (SLOTNUM)	_ _ _ (Default = 1)
13	INPUT SUBSLOT NUMBER (INPTSFLT)	_ _ (Default = 1)
14	OUTPUT SLOT NUMBER (OUTSLTNM)	_ _ _ (Default = 1)
15	OUTPUT SUBSLOT NUMBER (OUTSSLT)	_ _ (Default = 1)
16	LOAD DESTINATION (LOADDEST)	HG HG_HIWAY (Default = HG)

20	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)
21	DECIMAL FORMAT (PVFORMAT)	D0 D1 D2 D3	(Default = D0)
22	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0)
22A	PV DISPLAY LOW (PVDSPLO)	_ _ _ _ _ _ _	(Default = NaN)
23	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0)
23A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)
24	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0%)

DHP/620-HIM ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY				
25	PV RANGE OPTION (PVRNGOP)	NONE	FULLRNG	CLMPZERO (Default = NONE)
26	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)
27	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _		(Default = 0.0)
HG ALARMING DISPLAY (For Analog Input Point)				
29	AUXILIARY UNIT (\$AUXUNIT)	_ _ _		(Default = - -) R520 & later
30	ALARM FORMAT (ALFMT)	ALFMT00	ALFMT01	(Default = ALFMT00)
30i	ALARM DELAY OPTION (\$ALDLOPT)	NONE	OFFDLYLO OFFDLYHI OFFDLYEM	(Default = NONE)
30ii	DELAY TIME (DLYTIME)	_ _ _ _ _ _ _		(Default = 0.0)
30iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _		(Default = 0) R660 & later
30A	PVLOTP (PVLOTP)	_ _ _ _ _ _ _		(Default = 0.0)
30B	PVHITP (PVHITP)	_ _ _ _ _ _ _		(Default = 0.0)
30C	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _		(Default = 0.0%)
30D	DEVHITP (DEVHITP)	_ _ _ _ _ _ _		(Default = 0.0%)
31	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION	JOURNAL	LOW EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
32	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION	JOURNAL	LOW EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
32A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
33	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION	JOURNAL	LOW EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
33A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
34	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION	JOURNAL	LOW EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)

34A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT	ALLOW		
		(Default = CUTOUT)(R681)			
35	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION	JOURNAL	LOW	
		HIGH	EMERGNCY	PRINTER	JNLPRINT
		(Default = NOACTION)(R670)			
35A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT	ALLOW		
		(Default = CUTOUT)(R681)			
36	UNREASONABLE ALARM PRIORITY (UNREASPR)	NOACTION	JOURNAL	LOW	
		HIGH	EMERGNCY	PRINTER	JNLPRINT
		(Default = NOACTION)(R670)			
37	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = OFF)	
38	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)
38A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _			
		(Default = All Underscores)			

38B	ALARM ENABLE STATUS (ALENBST)	ENABLE	DISABLE	INHIBIT	(Default = ENABLE)	<u>Displayed</u>	<u>Logged</u>	<u>Reported to EIP</u>
		ENABLE	Yes	Yes	Yes			
		DISABLE	No	Yes	Yes			
		INHIBIT	No	No	No			
39	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _	(Default = All Underscores)					
40	EIP EVENT TYPE (EIPEVENT)	ANY	ALARM	RETURN	(Default = Any)			
		HIGH	HIGH_R	LOW	LOW_R			
41	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)				
42	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)				
43	OUTPUT TOLERANCE (%) (\$OPTOL)	_ _ _ _ _ _ _	(Default = 0.0)					
44	TARGET (PVTV)	_ _ _ _ _ _ _	(Default = 0)					
45	PC TYPE (PNTPCITY)	ALLENBRD	MODICON	HONYWELL	(Default = ALLENBRD)			
46	PC BOX INDEX (INPUT) (PNTBOXIN)	_	(Default = 1)					

DHP/620-HIM ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY					
47A	INPUT PC ADDRESS (PCADDR11)	_ _ _ _			(Default = 0)
47B	SPECIFIER CODE (INPUT) (SPECIF11)	_			(Default = 0)
48	PC RANGE CODE (INPUT) (RNGCODE1)	_			(Default = 0)
49	PC BOX INDEX (OUTPUT) (PNTBOX0T)	_			(Default = 1)
50A	OUTPUT PC ADDRESS (PCADDR01)	_ _ _ _			(Default = 0)
50B	SPECIFIER CODE (OUTPUT) (SPECIF01)	_			(Default = 0)
51	PC RANGE CODE (OUTPUT) (RNGCODE2)	_			(Default = 0)

HG MODE CONFIGURATION DISPLAY					
52	NORMAL MODE (NMODE)	MAN	CAS	NONE	(Default = NONE)
52A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
53	CASCADE (RCASENB)	OFF	ON		(Default = OFF)
54	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)

HG MODE CONFIGURATION DISPLAY					
55	OPERATING MODE (MODE)				(Default = MAN)
55i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)

[illegible]

```

20 UPPER BOX TEXT (STATE2)      | _ | _ | _ | _ | _ | _ | (Default = UPPER)
21 LOWER BOX TEXT (STATE1)      | | | | | | | | (Default = LOWER)

```

DHP/620-HIM DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY (For Digital Output Data Point)					
22	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
23	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
24	MOMENTARY O/P IND (MOOUTIND)	NOMOMENT	MOMENT		(Default = NOMOMENT)
25	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE		(Default = DIRECT)
26	PC BOX INDEX (PNTBOXOT)	__			(Default = 1)
27	PC TYPE (PNTPCTY)	ALLENBRD	MODICON	HONYWELL	(Default = ALLENBRD)
27A	OUTPUT 1 PC ADDRESS (PCADDR01)	_ _ _ _			(Default = 0)
27B	OUTPUT 1 BIT POSITION (PCBIT01)	_ _			(Default = 0)
27C	OUTPUT 1 SPECIFIER CODE (SPECIF01)	_			(Default = 0)
27D	OUTPUT 2 PC ADDRESS (PCADDR02)	_ _ _ _			(Default = 0)
27E	OUTPUT 2 BIT POSITION (PCBIT02)	_ _			(Default = 0)
27F	OUTPUT 2 SPECIFIER CODE (SPECIF02)	_			(Default = 0)
HG MODE CONFIGURATION DISPLAY (For Digital Output Data Point)					
30	NORMAL MODE (NMODE)	MAN	CAS	NONE	(Default = NONE)
30A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
31	CASCADE (RCASENB)	OFF	ON		(Default = OFF)
32	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)

DHP/620-HIM DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY (For Digital Output Data Point)				
33	OPERATING MODE (MODE)	(Default = MAN)		
33i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG (Default = All are allowed)
HG ALARMING DISPLAY (For Digital Input Data Point)				
39	AUXILIARY UNIT (\$AUXUNIT)	_ _	(Default = - -) R520 & later	
39A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _	(Default = 0) R660 & later	
40	ALARM FORMAT (DIGALFMT) [Single Input]	STATE1	STATE2	CHNGOFST (Default = CHNGOFST)
41	ALARM FORMAT (DIGALFMT) [Dual Inputs]	INPUT1 BOTH	INPUT2 CHNGOFST	EITHER (Default = CHNGOFST)
42	DELAY TIME (DLTIME)	_	(R600 & later)	
42	CHANGE OF STATE ALARM PRIORITY (CHOFSTPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
43	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
44	OFF NORMAL ALARM PRIORITY (OFFNRMPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
44A	OFF NORMAL SELECTIVE CUTOUT (\$OFSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
44B	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = OFF)
45	CONTACT CUTOUT RANK (CCRANK)	NEITHER PRIMARY	SECNDARY	(Default = NEITHER)
45A	PRIMARY POINT ID (CCPRIPNT)	_ _ _ _ _ _ _	(Default = All Underscores)	
46	NON-COMP STATE 00 TEXT (ZZTEXT)	TEXT1	TEXT2	(Default = TEXT1)
47	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _	(Default = All Underscores)	
48	EIP EVENT TYPE (EIP EVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2 (Default = Any)
49	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)

DHP/620-HIM DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY (For Digital Input Data Point)				
49A ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No
50 UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _			(Default = UPPER)
51 LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _			(Default = LOWER)
52 UPPER BOX COLOR (UBOXCLR)	RED GREEN CYAN YELLOW	WHITE BLUE	BLACK MAGENTA	(Default = RED)
53 LOWER BOX COLOR (LBOXCLR)	RED GREEN CYAN YELLOW	WHITE BLUE	BLACK MAGENTA	(Default = RED)
54 OVERVIEW VALUE (OVERVAL)	OFF ON			(Default = OFF)
55 INPUT DIRECTION (INPTDIR)	DIRECT REVERSE			(Default = DIRECT)
56 PC BOX INDEX (PNTBOXIN)	_			(Default = 1)
57 PC TYPE (PNTPCTY)	ALLENBRD MODICON HONYWELL			(Default = ALLENBRD)
57A INPUT 1 PC ADDRESS (PCADDRI1)	_ _ _ _			(Default = 0)
57B INPUT 1 BIT POSITION (PCBITI1)	_ _			(Default = 0)
57C INPUT 1 SPECIFIER CODE (SPECIFI1)	_			(Default = 0)
57D INPUT 2 PC ADDRESS (PCADDRI2)	_ _ _ _			(Default = 0)
57E INPUT 2 BIT POSITION (PCBITI2)	_ _			(Default = 0)
57F INPUT 2 SPECIFIER CODE (SPECIFI2)	_			(Default = 0)

[illegible]

DHP/620-HIM DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY

19	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later		
19A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _	(Default = 0) R660 & later		
20	ALARM FORMAT (DIGALFMT) [Single Input]	STATE1 STATE2 CHNGOFST	CMDDIS (Default = CHNGOFST)		
21	DELAY TIME (DLTIME)	_	(R600 & later)		
22	ALARM FORMAT (DIGALFMT) [Dual Inputs]	INPUT1 INPUT2 EITHER	CMDDIS (Default = CHNGOFST)		
23	CHANGE OF STATE ALARM PRIORITY (CHOFSTPR)	NOACTION HIGH	JOURNAL EMERGENCY	LOW PRINTER	JNLPRINT
24	COMMAND DISAGREE ALARM PRIORITY (CMDDISPR)	NOACTION HIGH	JOURNAL EMERGENCY	LOW PRINTER	JNLPRINT
25	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH	JOURNAL EMERGENCY	LOW PRINTER	JNLPRINT
26	OFF NORMAL ALARM PRIORITY (OFFNRMPR)	NOACTION HIGH	JOURNAL EMERGENCY	LOW PRINTER	JNLPRINT
26A	OFF NORMAL SELECTIVE CUTOFF (\$OFSELCT)	CUTOFF	ALLOW	(Default = CUTOFF)(R681)	
27	CRITICAL ALARM SCANNING (CRITSCAN)	OFF ON	(Default = OFF)		
28	CONTACT CUTOFF RANK (CCRANK)	NEITHER PRIMARY	SECNDARY	(Default = NEITHER)	
28A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _	(Default = All Underscores)		
29	NON-COMP STATE 00 TEXT (ZZTEXT)	TEXT1	TEXT2	(Default = TEXT1)	
30	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _	(Default = All Underscores)		
31	EIP EVENT TYPE (EIPEVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2	(Default = Any)
32	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)	
32A	ALARM ENABLE STATUS (ALENBST)	ENABLE	<u>Displayed</u>	<u>Logged</u>	<u>Reported to EIP</u>
		DISABLE	Yes	Yes	Yes
		INHIBIT	No	Yes	Yes
			No	No	No
		(Default = ENABLE)			

DHP/620-HIM DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY			
40	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _	(Default = UPPER)
41	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _	(Default = LOWER)
42	UPPER BOX COLOR (UBOXCLR)	RED GREEN WHITE BLACK CYAN YELLOW BLUE MAGENTA	(Default = RED)
43	LOWER BOX COLOR (LBOXCLR)	RED GREEN WHITE BLACK CYAN YELLOW BLUE MAGENTA	(Default = RED)
44	MOMENTARY O/P INDICATION (MOOUTIND)	NOMOMENT MOMENT	(Default = NOMOMENT)
45	FEEDBACK TIME (FBTIME)	_ _ _ _	(Default = 00)
46	OUTPUT INDICATION (OUTIND)	DIRECT REVERSE	(Default = DIRECT)
47	OVERVIEW VALUE (OVERVAL)	OFF ON	(Default = OFF)
48	INPUT DIRECTION (INPTDIR)	DIRECT REVERSE	(Default = DIRECT)
39	PC TYPE (PNTPCY)	ALLENBRD MODICON HONYWELL	(Default = ALLENBRD)
40	PC BOX INDEX (INPUT) (PNTBOXIN)	_	(Default = 1)
41A	INPUT 1 PC ADDRESS (PCADDRI1)	_ _ _ _ _	(Default = 0)
41B	INPUT 1 BIT POSITION (PCBITI1)	_ _	(Default = 0)
41C	INPUT 1 SPECIFIER CODE (SPECIFI1)	_	(Default = 0)
41D	INPUT 2 PC ADDRESS (PCADDRI2)	_ _ _ _ _	(Default = 0)
41E	INPUT 2 BIT POSITION (PCBITI2)	_ _	(Default = 0)
41F	INPUT 2 SPECIFIER CODE (SPECIFI2)	_	(Default = 0)
42	PC BOX INDEX (OUTPUT) (PNTBOXOT)	_	(Default = 1)
43A	OUTPUT 1 PC ADDRESS (PCADDR01)	_ _ _ _ _	(Default = 0)

DHP/620-HIM DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY					
43B	OUTPUT 1 BIT POSITION (PCBIT01)	_ _			(Default = 0)
43C	OUTPUT 1 SPECIFIER CODE (SPECIF01)	_			(Default = 0)
43D	OUTPUT 2 PC ADDRESS (PCADDR02)	_ _ _ _			(Default = 0)
43E	OUTPUT 2 BIT POSITION (PCBIT02)	_ _			(Default = 0)
43F	OUTPUT 2 SPECIFIER CODE (SPECIF02)	_			(Default = 0)

HG MODE CONFIGURATION DISPLAY					
50	NORMAL MODE (NMODE)	MAN	CAS	NONE	(Default = NONE)
50A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
51	CASCADE (RCASENB)	OFF	ON		(Default = OFF)
52	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)
53	OPERATING MODE (MODE)				(Default = MAN)
53i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)

[illegible]

DHP/620-HIM COUNTER DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
19	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later	
19A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _	(Default = 0) R660 & later	
20	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
21	COUNTER OVERFLOW ALARM PRIORITY (COUNTRPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
22	ALARM PRIORITY (ALPRIOR)	NOACTION HIGH	JOURNAL (Default = LOW)	LOW
23	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _	(Default = All Underscores)	
24	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)
24A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No <u>Reported to EIP</u> Yes Yes No

HG OPERATING CONFIGURATION DISPLAY				
30	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)	
31	DECIMAL POINT POSITION (AVFORMAT)	D0 D1 D2 D3	(Default = D0)	
32	PRESET VALUE (PRESET)	_ _ _ _ _ _	(Default = 0.0)	
33	SCALE FACTOR (AVCONV)	_ _ _ _ _ _	(Default = 1.0)	
34	PC BOX INDEX (PNTBOXIN)	_	(Default = 1)	
35	PC TYPE (PNTPCY)	ALLENBRD MODICON HONYWELL	(Default = ALLENBRD)	
35A	INPUT PC ADDRESS (PCADDR1)	_ _ _ _	(Default = 0)	
35B	INPUT SPECIFIER CODE (SPECIF1)	_	(Default = 0)	

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
2	UNIT ID (UNIT)	_ _ _	(Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
4	POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
7	HIWAY NUMBER (HWYNUM)	_ _ _	(Default = 01)
8	BOX TYPE (PNTBOXTY)	HLPIU EC MC DHP	(Enter EC)
9	BOX NUMBER (BOXNUM)	_ _ _	(Default = 00)
10	POINT DISCLOSURE (PTDISCL)	BRIEF FULL	(Default = BRIEF)
11	LOAD DESTINATION (LOADDEST)	HG HG_HIWAY	(Default = HG)
12	INPUT SLOT NUMBER (SLOTNUM)	_ _ _	(Default = 1)
13	NUMBER OF INPUTS (NMBRINPT)	_	(Default = 1)

19	AUXILIARY UNIT (\$AUXUNIT)	_ _ (Default = - -) R520 & later
19A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ (Default = 0) R660 & later
20	ALARM FORMAT (DIGALFMT) [Single Input]	STATE1 STATE2 CHNGOFST (Default = CHNGOFST)
21	ALARM FORMAT (DIGALFMT) [Dual Inputs]	INPUT1 NPUT2 EITHER BOTH CHNGOFST (Default = CHNGOFST)
22	DELAY TIME (DLYTIME)	_ (R600 & later)
23	CHANGE OF STATE ALARM PRIORITY (CHOFSTPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER JNLPRINT (Default = NOACTION)(R670)
24	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER JNLPRINT (Default = NOACTION)(R670)

EC DIGITAL INPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
25	OFF NORMAL ALARM PRIORITY (OFFNRMPR)	NOACTION HIGH (Default = NOACTION)(R670)	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT
25A	OFF NORMAL SELECTIVE CUTOUT (\$OFSELCT)	CUTOUT (Default = CUTOUT)(R681)	ALLOW	
26	CRITICAL ALARM SCANNING (CRITSCAN)	OFF ON	(Default = OFF)	
27	CONTACT CUTOUT RANK (CCRANK)	NEITHER PRIMARY	SECNDARY (Default = NEITHER)	
27A	RIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _	(Default = All Underscores)	
28	NON-COMP STATE 00 TEXT TEXT1 TEXT2 (ZZTEXT)		(Default = TEXT1)	
29	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _	(Default = All Underscores)	
30	EIP EVENT TYPE (EIPEVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2 (Default = Any)
31	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)
31A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No <u>Reported to EIP</u> Yes Yes No

HG OPERATING CONFIGURATION DISPLAY				
40	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _	(Default = UPPER)	
41	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _	(Default = LOWER)	
42	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE BLACK MAGENTA (Default = RED)
43	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE BLACK MAGENTA (Default = RED)
44	OVERVIEW VALUE (OVERVAL)	OFF	ON	(Default = OFF)
45	INPUT DIRECTION (INPTDIR)	DIRECT	REVERSE	(Default = DIRECT)

[illegible]

20 E.U. DESCRIPTOR (EUDESC) | | | | | | | | (Default = All Blanks)

EC REGULATORY DATA POINT CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY	
21 CHARACTERIZATION OF X (PVCHAR)	LINEAR JTHERM KTHERM TTHERM STHERM SQRR00T BURNSRTD RADIAMAT BTHERM ETHERM RTHERM RPTHERM DINRTD JISRTD (Default = LINEAR)
22 INPUT CONDITIONING (INPTCOND)	LINEAR SQRR00T (Default = LINEAR)
22A DECIMAL FORMAT OF X (PVFORMAT)	D0 D1 D2 D3 (Default = D0)
22B TEMP DISPLAY OF X (PVTEMP)	DEGREESF DEGREESC DEGREESR DEGREESK (Default = DEGREESF)
23 PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _ (Default = 0.0)
23A PV DISPLAY RANGE LOW (PVDSPL0)	_ _ _ _ _ _ _ (Default = NaN)
24 PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _ (Default = 100.0)
24A PV DISPLAY RANGE HIGH (PVDSPHI)	_ _ _ _ _ _ _ (Default = NaN)
25 OVERVIEW VALUE (OVERVAL)	_ _ _ _ (Default = 0%)
26 PV RANGE OPTION (PVRNGOP)	NONE FULLRNG CLMPZERO (Default = NONE)
27 CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP CLAMP (Default = NOCLAMP)
28 CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _ (Default = 0.0)
HG ALARMING DISPLAY	
19 AUXILIARY UNIT (\$AUXUNIT)	_ _ _ (Default = - -) R520 & later
30 ALARM FORMAT (ALFMT)	ALFMT00 ALFMT01 ALFMT02 ALFMT03 ALFMT04 ALFMT05 ALFMT06 ALFMT07 ALFMT08 ALFMT09 ALFMT10 ALFMT11 ALFMT12 ALFMT13 ALFMT14 ALFMT15 ALFMT16 ALFMT17 ALFMT18 ALFMT19 (For Analog Input Point)
30i ALARM DELAY OPTION (\$ALDLOPT)	NONE OFFDLYLO OFFDLYHI OFFDLYEM (Default = NONE) ONDLYLO ONDLYHI ONDLYEM
30ii DELAY FOR BADPV (\$DLBADAL)	NONE OFFDELAY (Default = NONE)
30iii DELAY TIME (DLYTIME)	_ _ _ _ _ _ _ (Default = 0.0)
30iv RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _ (Default = 0) R660 & later
30A - - - - -	_ _ _ _ _ _ _ (The alarm format selected
30B - - - - -	_ _ _ _ _ _ _ in Line 30 determines the
30C - - - - -	_ _ _ _ _ _ _ alarm types and values that

EC REGULATORY DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY					
30D	----- _ _ _ _ _ _ _	are to be entered in Lines (Default = 0.0 30A-30D.Refer to the definition for PV, 0% for of ALFMT in the HG Parameter DEV and ROC) Reference Dictionary.)			
31	BAD PV ALARM PRIORITY (BADPVPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
31A	OP ALARM ENABLE (\$OPALEN)	DISABLE	ENABLE (Default = DISABLE)		
31B	OP ALARM DEADBAND (OPALDB)	_ _ _ _ _ _ _	(Default = 5.0)		
31C	OPLOTP (OPLOTP)	_ _ _ _ _ _ _	(Default = 0.0)		
31D	OPHITP (OPHITP)	_ _ _ _ _ _ _	(Default = 0.0)		
32	COMPUTER SHED ALARM PRIORITY (CMPSHDPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
33	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
34	DEVIATION HIGH HIGH HIGH ALARM PRIORITY (DEVHHHPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
35	DEVIATION HIGH HIGH ALARM PRIORITY (DEVHHPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
36	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
36A	DEVIATION HIGH SELECTIVE CUTOOUT (\$DHSELECT)	CUTOOUT (Default = CUTOOUT)	ALLOW (R681)		
37	DEVIATION LOW LOW LOW ALARM PRIORITY (DEVLLLPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
38	DEVIATION LOW LOW ALARM PRIORITY (DEVLLPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT

EC REGULATORY DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY					
39	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
39A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
40	RAMPSOAK OFFSET 1 ALARM PRIORITY (OFFST1PR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
41	RAMPSOAK OFFSET 2 ALARM PRIORITY (OFFST2PR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
42	RAMPSOAK OFFSET 3 ALARM PRIORITY (OFFST3PR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
43	PV HIGH HIGH HIGH ALARM PRIORITY (PVHHHPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
44	PV HIGH HIGH ALARM PRIORITY (PVHHPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
44A	PV HIGH HIGH SELECTIVE CUTOUT (\$HHSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
45	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
45A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
46	PV LOW LOW LOW ALARM PRIORITY (PVLLLPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
47	PV LOW LOW ALARM PRIORITY (PVLLPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
47A	PV LOW LOW SELECTIVE CUTOUT (\$LLSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		

EC REGULATORY DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY						
48	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT	
48A	PV LOW SELECTIVE CUTOOUT (\$LOSELCT)	CUTOOUT (Default = CUTOOUT)	ALLOW (R681)			
49	PV RATE OF CHANGE ALARM PRIORITY (PVROCPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT	
49A	OP HIGH ALARM PRIORITY (OPHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT	
49B	OP LOW ALARM PRIORITY (OPLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT	
50	LOGIC GATE 4 ALARM PRIORITY (S4LOGCPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT	
51	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _ (Default = 0.0)				
52	DEVHITP (DEVHITP)	_ _ _ _ _ _ _ (Default = 0.0)				
52A	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = LOW)		
53	CONTACT CUTOOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)	
53A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ (Default = All Underscores)				
54	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ (Default = All Underscores)				
54A	EIP EVENT TYPE (EIP EVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW	(Default = Any) LOW_R	
54B	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)		
55	ALARM MASK (ALMASK)	NOALARM	S1	S1S2	S1S3	S1S4
		S1S2S3	S1S2S4	S1S3S4	S1S2S3S4	S2
		S2S3	S2S4	S2S3S4	S3	S3S4
		S4	(Default = S1S2S3S4)			

EC REGULATORY DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY					
55A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No
HG OPERATING CONFIGURATION DISPLAY					
60	DISPLAY SUPPRESSION (SUPPIO)	NOSUPPR INPSUPPR OUTSUPPR	(Default = NOSUPPR)		
61*	CONTROL ACTION (CTLACTN)	DIRECT REVERSE	(Default = DIRECT)		
62*	CONTROL EQUATION (CTLEQN)	EQA EQB EQC	(Default = EQA)		
63	OUTPUT INDICATION (OUTIND)	DIRECT REVERSE	(Default = DIRECT)		
64	PV SIGNAL TYPE (PVSIGNAL)	OUTPUT PV HWY LSP S1 S2 S3 S4 SI S5 NOTCONFIG (Default = PV)			
65	PV INPUT SOURCE (PVSLTSRC)	_ _ _ _ _ _ _ _	(Default = Tag name from Line 1)		
66*	SP SIGNAL TYPE (SPSIGNAL)	OUTPUT PV HWY LSP S1 S2 S3 S4 SI S5 NOTCONFIG (Default = LSP)			
67*	SP INPUT SOURCE (SPSLTSRC)	_ _ _ _ _ _ _ _	(Default = Tag name from Line 1)		
68*	PV TRACKING (PVTRACK)	NOTRACK TRACK	(Default = NOTRACK)		
69*	INITIALIZATION (INITCONF)	NOINIT INIT	(Default = NOINIT)		
HG ALARMING DISPLAY					
70*	CHARACTERIZATION OF Y (SPCHAR)	LINEAR JTHERM KTHERM TTHERM STHERM SQRROOT BURNSRTD RADIAMAT BTHERM ETHERM RTHERM RPHERM DINRTD JISRTD (Default = LINEAR)			
71*	DECIMAL FORMAT OF Y (SPFORMAT)	D0 D1 D2 D3	(Default = D0)		
72*	TEMP DISPLAY OF Y (SPTEMP)	DEGREESF DEGREESC DEGREESR DEGREESK	(Default = DEGREESF)		
73*	SP RANGE LOW (SPEULO)	_ _ _ _ _ _ _	(Default = 0.0)		

EC REGULATORY DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY

73A SP DISPLAY RANGE LOW (SPDSPLO)	_ _ _ _ _ _ _	(Default = NaN)
74* SP RANGE HIGH (SPEUHI)	_ _ _ _ _ _ _	(Default = 100.0)
74A SP DISPLAY RANGE HIGH (SPDSPHI)	_ _ _ _ _ _ _	(Default = NaN)
75 SP LOW LIMIT (SPLOLM)	_ _ _ _ _ _ _	(Default = 0)
76* SP HIGH LIMIT (SPHILM)	_ _ _ _ _ _ _	(Default = 0)
77 SP TOLERANCE (\$SPTOL)	_ _ _ _ _ _ _	(Default = 0.0)
78* SETPOINT (SP)	_ _ _ _ _ _ _	(Default = 0.0)
79 SOA SIGNAL TYPE (SOASIGNL)	NONE S1 S2 S3 S4 S5 S6 S7 SI	(Default = NONE)
80 SOA INPUT SOURCE (SOASRC)	_ _ _ _ _ _ _	(Default = Tag name from Line 1)

HG ALARMING DISPLAY

81 SOB SIGNAL TYPE (SOBSIGNL)	NONE S1 S2 S3 S4 S5 S6 S7 SI	(Default = NONE)
82 SOB INPUT SOURCE (SOBSRC)	_ _ _ _ _ _ _	(Default = Tag name from Line 1)
83* Z SIGNAL TYPE (ZSIGNAL)	OUTPUT PV HWY LSP S1 S2 S3 S4 SI S5 NOTCONFIG (Default = NOTCONFIG)	
84* Z INPUT SOURCE (ZSLT SRC)	_ _ _ _ _ _ _	(Default = Tag name from Line 1)
85 M SIGNAL TYPE (MSIGNAL)	OUTPUT PV HWY LSP S1 S2 S3 S4 SI S5 NOTCONFIG (Default = NOTCONFIG)	
86 M INPUT SOURCE (MSLT SRC)	_ _ _ _ _ _ _	(Default = Tag name from Line 1)

HG OPERATING CONFIGURATION DISPLAY

87 A SIGNAL TYPE (ASIGNAL)	OUTPUT PV HWY LSP S1 S2 S3 S4 SI S5 NOTCONFIG (Default = NOTCONFIG)	
88 A INPUT SOURCE (ASLT SRC)	_ _ _ _ _ _ _	(Default = Tag name from Line 1)

EC REGULATORY DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY

89*	C SIGNAL TYPE (CSIGNAL)	OUTPUT S2	PV S3	HWY S4	LSP SI	S1 S5	
		(Default = NOTCONFIG)					
90*	C INPUT SOURCE (CSLTSRC)	_ _ _ _ _ _ _ _	(Default = Tag name from Line 1)				
91	SP INDICATOR SIGNAL Y TYPE (GREENSG)	RATIO	BIAS	NOTCONFIG		(Default = NOTCONFIG)	
92	SP INDICATOR SOURCE (GREENSRC)	_ _ _ _ _ _ _ _	(Default = Tag name from Line 1)				
93	SENSE OF S0 DRIVERS (SENSSTOP)	CLOSED	OPEN	(Default = CLOSED)			

Parameter Name	Value
94*	_ _ _ _ _ _
95*	_ _ _ _ _ _
96*	_ _ _ _ _ _
97*	_ _ _ _ _ _
98*	_ _ _ _ _ _
99*	_ _ _ _ _ _
100*	_ _ _ _ _ _
101*	_ _ _ _ _ _
102*	_ _ _ _ _ _
103*	_ _ _ _ _ _
104*	_ _ _ _ _ _
105*	_ _ _ _ _ _
106*	_ _ _ _ _ _
107*	_ _ _ _ _ _
108*	_ _ _ _ _ _
109*	_ _ _ _ _ _
110*	_ _ _ _ _ _
111*	_ _ _ _ _ _
112*	_ _ _ _ _ _
113*	_ _ _ _ _ _
114*	_ _ _ _ _ _
115*	_ _ _ _ _ _

(Refer to the name of the algorithm in the HG Parameter Reference Dictionary to determine the parameter names and values that are to be entered on Lines 73-94.)

HG MODE CONFIGURATION DISPLAY

(For AUTOMAN, SWITCH, MID OF 3, LOGIC, DEADTM, and CHARACT algorithm)

120*	NORMAL MODE (NMODE)	MAN	AUTO	CAS	BCAS	NONE (Default = NONE)
------	------------------------	-----	------	-----	------	--------------------------

EC REGULATORY DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY (For AUTOMAN, SWITCH, MID OF 3, LOGIC, DEADTM, and CHARACT algorithm)						
120A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE		(Default = NONE)
121*	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR			(Default = NOPASTMR)
122*	CASCADE (RCASENB)	OFF	ON			(Default = OFF)
123*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT			(Default = PERMIT)
124*	SHEDMODE (SHEDMODE)	NOSHED	MAN	AUTO	BCAS	(Default = MAN)
125*	EXTERNAL MODE SWITCH (EMSENB)	DISABLE	ENABLE			(Default = DISABLE)
126*	OPERATING MODE (MODE)	MAN				(Default = MAN)
126i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO	PROG			(Default = All are allowed)
HG MODE CONFIGURATION DISPLAY (For MASSFLOW algorithm)						
120*	NORMAL MODE (NMODE)	MAN	AUTO	CAS	BCAS	NONE (Default = NONE)
120A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE		(Default = NONE)
121*	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR			(Default = NOPASTMR)
122*	CASCADE (RCASENB)	OFF	ON			(Default = OFF)
123*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT			(Default = PERMIT)
124*	SHEDMODE (SHEDMODE)	NOSHED	MAN	AUTO	BCAS	(Default = MAN)
125*	EXTERNAL MODE SWITCH (EMSENB)	DISABLE	ENABLE			(Default = DISABLE)
126*	OPERATING MODE (MODE)	MAN				(Default = MAN)
126i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO CAS	PROG			(Default = All are allowed)

EC REGULATORY DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY					
(For all algorithms except AUTOMAN, SWITCH, MID OF 3, LOGIC, DEADTM, CHARACT and MASSFLOW)					
120*	NORMAL MODE (NMODE)	MAN	AUTO	CAS	BCAS NONE (Default = NONE)
120A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
121*	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR		(Default = NOPASTMR)
122*	CASCADE (RCASENB)	OFF	ON		(Default = OFF)
123*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)
124*	SHEDMODE (SHEDMODE)	NOSHED	MAN	AUTO	BCAS (Default = MAN)
125*	EXTERNAL MODE SWITCH (EMSENB)	DISABLE	ENABLE		(Default = DISABLE)
126*	OPERATING MODE (MODE)	MAN			(Default = MAN)
126i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO CAS BCAS	PROG		(Default = All are allowed)

[illegible]

20	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)
21	OUTPUT TOLERANCE (%) (\$OPTOL)	_ _ _ _ _ _ _		(Default = 0.0)

30	NORMAL MODE (NMODE)	MAN	CAS	NONE (Default = NONE)
30A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE (Default = NONE)
31	CASCADE (RCASENB)	OFF	ON	(Default = OFF)

HLPIU ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY
(For Analog Output Data Point)

32	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)
33	OPERATING MODE (MODE)	(Default = MAN)		
33i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG (Default = All are allowed)

HG PV CONFIGURATION DISPLAY
(For Analog Input Data Point)

38	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)
39	CHARACTERIZATION (PVCHAR)	SENSR300 SENSR308 SENSR319 SENSR320 SENSR324 SENSR325	SENSR309 SENSR317 SENSR318 SENSR321 SENSR322 SENSR323 (No Default)
40	INPUT CONDITIONING (INPTCOND)	LINEAR SQRR00T	(Default = LINEAR)
40A	DECIMAL FORMAT (PVFORMAT)	D0D1 D2 D3	(Default = D0)
40B	TEMP. DISPLAY (PVTEMP)	DEGREESF DEGREESC	(Default = DEGREESF)
41	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0)
41A	PV DISPLAY LOW (PVDSPLO)	_ _ _ _ _ _ _	(Default = NaN)
42	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0)
42A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)
44	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0)
45	PV RANGE OPTION (PVRNGOP)	NONE FULLRNG CLMPZERO	(Default = NONE)
46	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP CLAMP	(Default = NOCLAMP)
47	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _	(Default = 0.0)

HG ALARMING DISPLAY
(For Analog Input Data Point)

48	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later
48A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _	(Default = 0) R660 & later
49	ALARM FORMAT (ALFMT)	ALFMT00 ALFMT01	(Default = ALFMT00)

HLPIU ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY (For Analog Input Data Point)				
49i ALARM DELAY OPTION (\$ALDLOPT)	NONE ONDLYLO	OFFDLYLO ONDLYHI	OFFDLYHI ONDLYEM	OFFDLYEM
			(Default = NONE)	(Default = 0.0)
49ii DELAY TIME (DLYTIME)	_ _ _ _			
49A PVLOTP (PVLOTP)	_ _ _ _		(Default = 0.0)	
49B PVHITP (PVHITP)	_ _ _ _		(Default = 0.0)	
49C DEVLOTP (DEVLOTP)	_ _ _ _		(Default = 0.0%)	
49D DEVHITP (DEVHITP)	_ _ _ _		(Default = 0.0%)	
50 CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT	
51 DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT	
51A DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
52 DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT	
52B DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
53 PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER	JNLPRINT
53A PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
54 PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER	JNLPRINT
54A PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		

HLPIU ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY (For Analog Input Data Point)					
55	UNREASONABLE ALARM PRIORITY (UNREASPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER	JNLPRINT
56	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = OFF)	
57	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)
57A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _			(Default = All Underscores)
58	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _			(Default = All Underscores)
58A	EIP EVENT TYPE (EIP EVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW	(Default = Any) LOW_R
59	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)	
59A	ALARM ENABLE STATUS (ALENBST)		<u>Displayed</u>	<u>Logged</u>	<u>Reported to EIP</u>
		ENABLE	Yes	Yes	Yes
		DISABLE	No	Yes	Yes
		INHIBIT	No	No	No
		(Default = ENABLE)			
60	SCAN FREQUENCY (SCANFREQ)	OFFSCAN SCAN_25	SCAN60 SCAN_05	SCAN15 RESERVED	SCAN5 SCAN1 (Default = OFFSCAN)
61	SMOOTHING COEFFICIENT (PIUSMOTH)	NONE CODE05 CODE10 (Default = NONE)	CODE01 CODE06 CODE11	CODE02 CODE07 CODE12	CODE03 CODE08 CODE13
				CODE04 CODE09 CODE14	
62	TARGET (PVTV)	_ _ _ _ _ _ _ _ (Default = 0.0)			

HG POINT ASSIGNMENT DISPLAY

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
2	UNIT ID (UNIT)	_ _ _	(Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
4	POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
7	HIWAY NUMBER (HWYNUM)	_ _ _	(Default = 1)
8	BOX TYPE (PNTBOXTY)	HLPIU MC DHP	(Enter HLPIU)
9	INPUT BOX NUMBER (BOXNUM)	_ _ _	(Default = 00)
10	OUTPUT BOX NUMBER (OUTBOXNM)	_ _ _	(Default = 00)
11	POINT DISCLOSURE (PIDISCL)	BRIEF FULL	(Default = BRIEF)
12	INPUT SLOT (SLOTNUM)	_ _ _	(Default = 1)
13	INPUT SUBSLOT NUMBER (INPTSSLT)	_	(Default = 1)
14	OUTPUT SLOT NUMBER (OUTSLTNM)	_ _ _	(Default = 1)
15	OUTPUT SUBSLOT NUMBER (OUTSSLT)	_	(Default = 1)
16	LOAD DESTINATION (LOADDEST)	HG HG_HIWAY	(Default = HG)

HG PV CONFIGURATION DISPLAY

20	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)
21	CHARACTERIZATION (PVCHAR)	SENSR300 SENSR319 SENSR324	SENSR308 SENSR320 SENSR325 (No Default)
22	INPUT CONDITIONING (INPTCOND)	LINEAR	SQRR00T (Default = LINEAR)
22A	DECIMAL FORMAT (PVFORMAT)	D0 D1 D2 D3	(Default = D0)

HLPIU ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY				
22B	TEMP DISPLAY (PVTEMP)	DEGREESF	DEGREESC	(Default = DEGREESF)
23	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _		(Default = 0.0)
23A	PV DISPLAY LOW (PVDSPL0)	_ _ _ _ _ _ _		(Default = NaN)
24	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _		(Default = 100.0)
24A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _		(Default = NaN)
25	OVERVIEW VALUE (OVERVAL)	_ _ _ _		(Default = 0%)
26	RANGE OPTION (PVRNGOP)	NONE	FULLRNG	CLMPZERO (Default = NONE)
27	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)
28	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _		(Default = 0.0)
HG ALARMING DISPLAY				
29	AUXILIARY UNIT (\$AUXUNIT)	_ _ _		(Default = - -) R520 & later
29A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _		(Default = 0) R660 & later
30	ALARM FORMAT (ALFMT)	ALFMT00	ALFMT01	(Default = ALFMT00) (For Analog Input)
30i	ALARM DELAY OPTION (\$ALDLOPT)	NONE	OFFDLYLO	OFFDLYHI OFFDLYEM ONDLYLO ONDLYHI ONDLYEM (Default = NONE)
30ii	DELAY TIME (DLTIME)	_ _ _ _ _ _ _		(Default = 0.0)
30A	PVL0TP (PVL0TP)	_ _ _ _ _ _ _		(Default = 0.0)
30B	PVH0TP (PVH0TP)	_ _ _ _ _ _ _		(Default = 0.0)
30C	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _		(Default = 0.0%)
30D	DEVH0TP (DEVH0TP)	_ _ _ _ _ _ _		(Default = 0.0%)
31	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION	JOURNAL	LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
32	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION	JOURNAL	LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)
32A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELECT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
33	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION	JOURNAL	LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)

HLPIU ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
33A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
34	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
34A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
35	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH	JOURNAL EMERGNCY PRINTER	LOW JNLPRINT (Default = NOACTION)(R670)
35A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
36	UNREASONABLE ALARM PRIORITY (UNREASPR)	NOACTION HIGH	JOURNAL EMERGNCY PRINTER	LOW JNLPRINT (Default = NOACTION)(R670)
36A	CRITICAL ALARM SCANNING	OFF	ON	(Default = OFF)
37	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY (Default = NEITHER)
37A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)		
38	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)		
39	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW (Default = Any) LOW_R
39A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No <u>Reported to EIP</u> Yes Yes No

HG OPERATING CONFIGURATION DISPLAY			
40	EIP ENABLE (EIPENB)	ENABLE	DISABLE (Default = Enable)
41	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE (Default = DIRECT)
42	OUTPUT TOLERANCE (%) (\$OPTOL)	_ _ _ _ _ _ _ _ _ (Default = 0.0)	

HLPIU ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY						
43	SCAN FREQUENCY (SCANFREQ)	OFFSCAN SCAN_25	SCAN60 SCAN_05	SCAN15 RESERVED	SCAN5 (Default = OFFSCAN)	SCAN1
44	SMOOTHING COEFFICIENT (PIUSMOTH)	NONE CODE05 CODE10 (Default = NONE)	CODE01 CODE06 CODE11	CODE02 CODE07 CODE12	CODE03 CODE08 CODE13	CODE04 CODE09 CODE14
45	TARGET (PVTV)	_ _ _ _ _ _ _ (Default = 0.0)				
50	NORMAL MODE (NMODE)	MAN	CAS	NONE	(Default = NONE)	
50A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)	
51	CASCADE (RCASENB)	OFF	ON	(Default = OFF)		
52	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)		
53	OPERATING MODE (MODE)	(Default = MAN)				
53i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)	

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
2	UNIT ID (UNIT)	_ _	(Default = 1)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
4	POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
7	HIWAY NUMBER (HWYNUM)	_ _ _	(Default = 1)
8	BOX TYPE (PNTBOXTY)	HLPIU EC MC DHP	(Enter HLPIU)
9	BOX NUMBER (BOXNUM or OUTBOXNM)	_ _ _	(Default = 00)
10	POINT DISCLOSURE (PTDISCL)	BRIEF FULL	(Default = BRIEF)
11	LOAD DESTINATION (LOADDEST)	HG HG_HIWAY	(Default = HG)
12	INPUT SLOT NUMBER (SLOTNUM)	_ _ _	(Default = 1)
13	INPUT SUBSLOT NUMBER (INPTSSLT)	_ _ _	(Default = 1)
14	NUMBER OF INPUTS (NMBRINPT)	_	(Default = 1)
15	OUTPUT SLOT NUMBER (OUTSLTNM)	_ _ _	(Default = 1)
16	OUTPUT SUBSLOT NUMBER (OUTSSLT)	_	(Default = 1)
17	NUMBER OF OUTPUTS (NMBROUT)	_	(Default = 1)

```

20 UPPER BOX TEXT (STATE2) | _ | _ | _ | _ | _ | _ | (Default = UPPER)
21 LOWER BOX TEXT (STATE1) | _ | _ | _ | _ | _ | _ | (Default = LOWER)

```

HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY (For Digital Output Data Point)					
22	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
23	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
24	OUTPUT TYPE (PNTOPOP)	PULSEOUT	LATCHOUT	(Default = PULSEOUT)	
24A	MOMENTARY O/P IND (MOOUTIND)	NOMOMENT	MOMENT	(Default = NOMOMENT)	
24B	PULSE WIDTH (PULSEWTH)	_ _ _ _ _ _ _			(Default = 16.0)
25	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)	
HG MODE CONFIGURATION DISPLAY (For Digital Output Data Point)					
30	NORMAL MODE (NMODE)	MAN	CAS	NONE	(Default = NONE)
30A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
31	CASCADE (RCASENB)	OFF	ON	(Default = OFF)	
32	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)	
33	OPERATING MODE (MODE)	(Default = MAN)			
33i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)
HG ALARMING DISPLAY (For Digital Input Data Point)					
39	AUXILIARY UNIT (\$AUXUNIT)	_ _ _ (Default = - -) R520 & later			
39A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _ (Default = 0) R660 & later			
40	POINT CARD OPTION (IPCRDOP)	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
40A	ALARMING FUNCTION (DIGALARM)	DISABLE	ENABLE	(Default = DISABLE)	
41	ALARM FORMAT (DIGALFMT) [Single Input]	STATE1	STATE2	CHNGOFST	(Default = CHNGOFST)
42	ALARM FORMAT (DIGALFMT) [Dual Inputs]	INPUT1 BOTH	INPUT2 CHNGOFST	EITHER	(Default = INPUT1)
43	DELAY TIME (DLYTIME)	_ _ (R600 & later)			

HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY (For Digital Input Data Point)					
44	CHANGE OF STATE ALARM PRIORITY (CHOFSTPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER	JNLPRINT
45	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER	JNLPRINT
46	OFF NORMAL ALARM PRIORITY (OFFNRMPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER	JNLPRINT
46A	OFF NORMAL SELECTIVE CUTOUT (\$OFSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)		
46B	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON		(Default = OFF)
47	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDAR	(Default = NEITHER)
47A	PRIMARY POINT ID (CCPRIPNT)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)
48	NON-COMP STATE 00 TEXT (ZZTEXT)	TEXT1	TEXT2		(Default = TEXT1)
49	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)
50	EIP EVENT TYPE (EIPEVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2	(Default = Any)
51	ENABLE (EIPENB)	ENABLE	DISABLE		(Default = Enable)
51A	ALARM ENABLE STATUS (ALENBST)	ENABLE	<u>Displayed</u> Yes	<u>Logged</u> Yes	<u>Reported to EIP</u> Yes
		DISABLE	No	Yes	Yes
		INHIBIT	No	No	No
		(Default = ENABLE)			

HLPIU DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY (For Digital Input Data Point)					
60	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _	(Default = UPPER)		
61	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _	(Default = LOWER)		
62	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
63	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
64	OVERVIEW VALUE (OVERVAL)	OFF	ON	(Default = OFF)	
65	INPUT DIRECTION (INPTDIR)	DIRECT	REVERSE (Default = DIRECT)		

[illegible]

HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY	
19	AUXILIARY UNIT (\$AUXUNIT) (Default = - -) R520 & later
19A	RE-ALARMING INTERVAL (\$REALARM) (Default = 0) R660 & later
20	POINT CARD OPTION NOTIFYST CHNGDECT SOE (Default = NOTIFYST) (IPCRDOP)
20A	ALARMING FUNCTION DISABLE ENABLE (Default = ENABLE) (DIGALARM)
21	ALARM FORMAT (DIGALFMT) STATE1 STATE2 CHNGOFST CMDDIS [Single Input] (Default = CHNGOFST)
22	ALARM FORMAT (DIGALFMT) INPUT1 INPUT2 EITHER [Dual Inputs] BOT CHNGOFST CMDDIS (Default = CHNGOFST)
23	DELAY TIME (DLTIME) (R600 & later)
24	CHANGE OF STATE NOACTION JOURNAL LOW ALARM PRIORITY HIGH EMERGNCY PRINTER JNLPRINT (CHOFSTPR) (Default = NOACTION)(R670)
25	COMMAND DISAGREE NOACTION JOURNAL LOW ALARM PRIORITY HIGH EMERGNCY PRINTER JNLPRINT (CMDDISPR) (Default = NOACTION)(R670)
26	CONFIGURATION ERROR NOACTION JOURNAL LOW ALARM PRIORITY HIGH EMERGNCY PRINTER JNLPRINT (CNFERRPR) (Default = NOACTION)(R670)
27	OFF NORMAL NOACTION JOURNAL LOW ALARM PRIORITY HIGH EMERGNCY PRINTER JNLPRINT (OFFNRMPR) (Default = NOACTION)(R670)
27A	OFF NORMAL CUTOUT ALLOW SELECTIVE CUTOOT (Default = CUTOOT)(R681) (\$OFSELCT)
27B	CRITICAL ALARM SCANNING OFF ON (Default = OFF) (CRITSCAN)
28	CONTACT CUTOOT RANK NEITHER PRIMARY SECNDARY (Default = NEITHER) (CCRANK)
28A	PRIMARY POINT ID (Default = All (CCPRIPNT) Underscores)
29	NON-COMP STATE 00 TEXT TEXT1 TEXT2 (Default = TEXT1) (ZZTEXT)
30	EIP POINT ID (Default = All (EIPPCODE) Underscores)
31	EIP EVENT TYPE ANY ALARM RETURN (Default = Any) (EIPVENT) CHGSTATE STATE1 STATE2

HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
32	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default - Enable)
32A	ALARM ENABLE STATUS (ALENBST)		<u>Displayed</u>	<u>Logged</u> <u>Reported to EIP</u>
		ENABLE	Yes	Yes Yes
		DISABLE	No	Yes Yes
		INHIBIT	No	No No
		(Default = ENABLE)		
HG OPERATING CONFIGURATION DISPLAY				
33	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _ (Default = UPPER)		
34	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _ (Default = LOWER)		
35	UPPER BOX COLOR (UBOXCLR)	RED	GREEN	WHITE
		CYAN	YELLOW	BLUE
		BLACK MAGENTA (Default = RED)		
36	LOWER BOX COLOR (LBOXCLR)	RED	GREEN	WHITE
		CYAN	YELLOW	BLUE
		BLACK MAGENTA (Default = RED)		
37	OUTPUT TYPE (PNTOPOP)	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
37A	MOMENTARY O/P IND (MOOUTIND)	NOMOMENT	MOMENT	(Default = NOMOMENT)
HG OPERATING CONFIGURATION DISPLAY				
37B	PULSE WIDTH (PULSEWTH)	_ _ _ _ _ _ _ (Default = 16.0)		
38	FEEDBACK TIME (FBTIME)	_ _ _ _ _ _ _ (Default = 0)		
39	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)
40	OVERVIEW VALUE (OVERVAL)	OFF	ON	(Default = OFF)
41	INPUT DIRECTION (INPTDIR)	DIRECT	REVERSE	(Default = DIRECT)
HG MODE CONFIGURATION DISPLAY				
42	NORMAL MODE (NMODE)	MAN	CAS	NONE (Default = NONE)
42A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE (Default = NONE)
43	CASCADE (RCASENB)	OFF	ON	(Default = OFF)

HLPIU DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY					
44	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)
45	OPERATING MODE (MODE)				(Default = MAN)
45i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)

HG POINT ASSIGNMENT DISPLAY

1 TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
2 UNIT ID	_ _	(Default = 1)
3 POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
4 POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
5 PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
6 POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6i POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
7 HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)
8 BOX TYPE (PNTBOXTY)	HLPIU MC DHP	(Enter HLPIU)
9 BOX NUMBER (BOXNUM)	_ _	(Default = 00)
10 POINT DISCLOSURE (PTDISCL)	BRIEF FULL	(Default = BRIEF)
11 INPUT SLOT NUMBER (SLOTNUM)	_ _	(Default = 1)
12 INPUT SUBSLOT NUMBER (INPTSSLT)	_	(Default = 1)
13 LOAD DESTINATION (LOADDEST)	HG HG_HIWAY	(Default = HG)

HG ALARMING DISPLAY

19 AUXILIARY UNIT (\$AUXUNIT)	_ _ (Default = - -) R520 & later
19A RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ (Default = 0) R660 & later
20 CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER JNLPRINT (Default = NOACTION)(R670)
21 COUNTER OVERFLOW ALARM PRIORITY (COUNTRPR)	NOACTION JOURNAL LOW HIGH EMERGENCY PRINTER JNLPRINT (Default = NOACTION)(R670)
22 EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)

HLPIU COUNTER (16-BIT) DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY					
23 EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)		
24 ALARM ENABLE STATUS (ALENBST)		<u>Displayed</u>	<u>Logged</u>	<u>Reported to EIP</u>	
	ENABLE	Yes	Yes	Yes	
	DISABLE	No	Yes	Yes	
	INHIBIT	No	No	No	
	(Default = ENABLE)				
HG OPERATING CONFIGURATION DISPLAY					
30 E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)			
31 DECIMAL POINT POSITION (AVFORMAT)	D0	D1	D2	D3	(Default = D0)
32 SCALE FACTOR (AVCONV)	_ _ _ _ _ _ _	(Default = 1.0)			
33 PRESET VALUE (PRESET)	_ _ _ _ _ _ _	(Default = 0)			
34 OPERATOR PRESET CHANGE (PRESLOCK)	PERMIT	NOPERMIT	(Default = PERMIT)		
35 OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0)			

1 TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
2 UNIT ID (UNIT)	_ _ _	(Default = All Blanks)
3 POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
4 POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
5 POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6i POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6 HIWAY NUMBER (HWYNUM)	_ _ _	(Default = 1)
7 BOX TYPE (PNTBOXTY)	HLPIU	(Enter HLPIU)
8 BOX NUMBER (BOXNUM)	_ _ _	(Default = 00)
9 INPUT SLOT NUMBER (SLOTNUM)	_ _ _	(Default = 1)
10 INPUT SUBSLOT NUMBER	_ _	(Default = 1) (INPTSSTL)

HG POINT ASSIGNMENT DISPLAY

[illegible]

HG PV CONFIGURATION DISPLAY

18	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)
19	CHARACTERIZATION (PVCHAR)	SENSR500 SENSR501 SENSR502 SENSR503 SENSR504 SENSR505 SENSR506 SENSR511 SENSR515 SENSR516 SENSR520 SENSR521 SENSR522 (No Default)	
20	OPEN THERM. DETECTION (PIU0TDCF)	DISABLE ENABLE	(Default = DISABLE)
21	INPUT CONDITIONING (INPTCOND)	LINEAR SQRR00T	(Default = LINEAR)
21A	DECIMAL FORMAT (PVFORMAT)	D0 D1 D2 D3	(Default = D0)
21B	TEMP DISPLAY (PVTEMP)	DEGREESF DEGREESC	(Default = DEGREESF)
22	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0)
22A	PV DISPLAY RANGE LOW (PVDSPLO)	_ _ _ _ _ _ _	(Default = NaN)
23	PV RANGE HIGH (PVEUH1)	_ _ _ _ _ _ _	(Default = 100.0)

LEPIU ANALOG INPUT DATA POINT CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY				
23A	PV DISPLAY RANGE HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)	
24	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0%)	
25	PV RANGE OPTION (PVRNGOP)	NONE FULLRNG CLMPZERO	(Default = NONE)	
26	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP CLAMP	(Default = NOCLAMP)	
27	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _	(Default = 0.0)	
HG ALARMING DISPLAY				
28	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later	
29	ALARM FORMAT (ALFMT)	ALFMT00 ALFMT01	(Default = ALFMT00)	
29i	ALARM DELAY OPTION (\$ALDLOPT)	NONE OFFDLYLO OFFDLYHI OFFDLYEM ONDLYLO ONDLYHI ONDLYEM (Default = NONE)		
29ii	DELAY TIME (DLYTIME)	_ _ _ _ _ _	(Default = 0.0)	
29iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _	(Default = 0) R660 & later	
29A	PVLOTP (PVLOTP)	_ _ _ _ _ _ _	(Default = 0.0)	
29B	PVHITP (PVHITP)	_ _ _ _ _ _ _	(Default = 0.0)	
29C	PV ALARM DEADBAND (PVALDB)	_ _ _ _	(Default = 0.0)	
29D	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _	(Default = 0.0%)	
29E	DEVHITP (DEVHITP)	_ _ _ _ _ _ _	(Default = 0.0%)	
30	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)		
31	DEVIATION HIGH ALARM PRIORITY(DEVHIPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)		
31A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELCT)	CUTOUT ALLOW (Default = CUTOUT)(R681)		
32	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT (Default = NOACTION)(R670)		
32A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT ALLOW (Default = CUTOUT)(R681)		

LEPIU ANALOG INPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY						
33	OPEN THERMOCOUPLE ALARM PRIORITY (OPNTHRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT		
34	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT		
34A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)			
35	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT		
35A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)			
36	UNREASONABLE ALARM PRIORITY (UNREASPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT		
36A	CRITICAL ALARM SCANNING (CRITISCAN)	OFF	ON	(Default = OFF)		
37	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)	
37A	PRIMARY POINT ID (CCPRIPNT)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)	
38	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)	
39	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW	(Default = Any) LOW_R	
40	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)		
41	ALARM ENABLE STATUS (ALENBST)	ENABLE	<u>Displayed</u> Yes	<u>Logged</u> Yes	<u>Reported to EIP</u> Yes	
		DISABLE	No	Yes	Yes	
		INHIBIT	No	No	No	
		(Default = ENABLE)				
HG OPERATING CONFIGURATION DISPLAY						
42	SCAN FREQUENCY (SCANFREQ)	OFFSCAN	SCAN60	SCAN15	SCAN5	(Default = OFFSCAN)
43	SMOOTHING COEFFICIENT (PIUSMOTH)	NONE	CODE01	CODE02	CODE03	CODE04
		CODE05	CODE06	CODE07	CODE08	CODE09
		CODE10	CODE11	CODE12	CODE13	CODE14
		(Default = NONE)				
44	TARGET (PVTV)	_ _ _ _ _ _ _ _ _ (Default = 0.0)				

LLPIU ANALOG INPUT DATA POINT CONFIGURATION FORM

HG POINT ASSIGNMENT DISPLAY

[illegible]

HG PV CONFIGURATION DISPLAY

20	E.U. DESCRIPTOR (EUEDESC)	_ _ _ _ _ _ _	(Default = All Blanks)
21	CHARACTERIZATION (PVCHAR)	SENSR400 SENSR401 SENSR402 SENSR403 SENSR404 SENSR405 SENSR406 SENSR408 SENSR409 SENSR410 SENSR411 SENSR415 SENSR416 SENSR417 SENSR418 SENSR419 SENSR420 SENSR421 SENSR422 SENSR423 * SENSR424 SENSR425 SENSR426 SENSR427 (No Default)	
22	OPEN THERM. DETECTION (PIUDOTCF)	DISABLE ENABLE	(Default = DISABLE)
23	INPUT CONDITIONING (INPTCOND)	LINEAR SQRRROOT	(Default = LINEAR)

*SENSR424-SENSR427 are optional and require special firmware

LLPIU ANALOG INPUT DATA POINT CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY				
24A	DECIMAL FORMAT (PVFORMAT)	D0	D1	D2 D3 (Default = D0)
24B	TEMP DISPLAY (PVTEMP)	DEGREESF	DEGREESC	(Default = DEGREESF)
25	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _		(Default = 0.0)
25A	PV DISPLAY LOW (PVDSPLO)	_ _ _ _ _ _ _		(Default = NaN)
26	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _		(Default = 100.0)
26A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _		(Default = NaN)
27	OVERVIEW VALUE (OVERVAL)	_ _ _ _		(Default = 0%)
28	PV RANGE OPTION (PVRNGOP)	NONE	FULLRNG CLMPZERO	(Default = NONE)
29	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)
30	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _		(Default = 00)
HG ALARMING DISPLAY				
31	AUXILIARY UNIT (\$AUXUNIT)	_ _ _		(Default = - -) R520 & later
32	ALARM FORMAT (ALFMT)	ALFMT00	ALFMT01	(Default = ALFMT00)
32i	ALARM DELAY OPTION (\$ALDLOPT)	NONE OFFDLYLO OFFDLYHI OFFDLYEM	ONDLYLO ONDLYHI ONDLYEM	(Default = NONE)
32ii	DELAY TIME (DLYTIME)	_ _ _ _ _ _ _		(Default = 0.0)
32iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _		(Default = 0) R660 & later
32A	PVLOTP (PVLOTP)	_ _ _ _ _ _ _		(Default = 0.0)
32B	PV ALARM DEADBAND (PVALDB)	_ _ _ _ _ _ _		(Default = 0.0)
32C	PVHITP (PVHITP)	_ _ _ _ _ _ _		(Default = 0.0)
32D	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _		(Default = 0.0%)
32E	DEVHITP (DEVHITP)	_ _ _ _ _ _ _		(Default = 0.0%)
33	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
34	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
34A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
35	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)

35A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSLCT)	CUTOUT	ALLOW		(Default = CUTOUT)(R681)
36	OPEN THERMOCOUPLE ALARM PRIORITY (OPNTHRPR)	NOACTION	JOURNAL	LOW	PRINTER JNLPRINT (Default = NOACTION)(R670)
37	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION	JOURNAL	LOW	PRINTER JNLPRINT (Default = NOACTION)(R670)
37A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT	ALLOW		(Default = CUTOUT)(R681)
38	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION	JOURNAL	LOW	PRINTER JNLPRINT (Default = NOACTION)(R670)
38A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT	ALLOW		(Default = CUTOUT)(R681)
39	UNREASONABLE ALARM PRIORITY (UNREASPR)	NOACTION	JOURNAL	LOW	PRINTER JNLPRINT (Default = NOACTION)(R670)
39A	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON		(Default = LOW)
40	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)
40A	PRIMARY POINT ID (CCPRIPNT)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)
41	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)
43	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW	(Default = Any) LOW_R
44	EIP ENABLE (EIPENB)	ENABLE	DISABLE		(Default = Enable)
45	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No

LLPIU ANALOG INPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY						
50	SCAN FREQUENCY (SCANFREQ)	OFFSCAN SCAN_25	SCAN60 (Default = OFFSCAN)	SCAN15	SCAN5	SCAN1
51	SMOOTHING COEFFICIENT (PIUSMOTH)	NONE CODE05 CODE10 (Default = NONE)	CODE01 CODE06 CODE11	CODE02 CODE07 CODE12	CODE03 CODE08 CODE13	CODE04 CODE09 CODE14
52	TARGET (PVTV)	_ _ _ _ _ _ _ (Default = 0.0)				

MC ANALOG INPUT DATA POINT (WITH ACCUMULATION) CONFIGURATION FORM

HG POINT ASSIGNMENT DISPLAY	
1	TAG NAME (NAME) (Default = All Underscores)
2	UNIT ID (UNIT) (Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC) (Default = All Blanks)
4	POINT KEYWORD (KEYWORD) (Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD) (Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP) (Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL) (Default = All Blanks)
7	HIWAY NUMBER (HWYNUM) (Default = 1)
8	BOX TYPE (PNTBOXTY) CB HLPIU LLPIIU LEPIU MC DHP NOTCONFIG (Enter MC)
9	BOX NUMBER (BOXNUM) (Default = 0)
10	POINT DISCLOSURE (PTDISCL) BRIEF FULL (Default = BRIEF)
11	SLOT NUMBER (SLOTNUM) (Default = 1)
12	SUBSLOT NUMBER (INPTSSLT) (Default = 1)
13	LOAD DESTINATION (LOADDEST) HG HG_HIWAY (Default = HG)
14	ACCUMULATION OPTION (AVOPTION) DISABLE ENABLE (Enter = ENABLE)

HG PV CONFIGURATION DISPLAY	
20	E.U. DESCRIPTOR (EUDESC) (Default = All Blanks)
21	CHARACTERIZATION (PVCHAR) LINEAR JTHERM KTHERM TTHERM ETHERM RTHERM RPTHERM STHERM BURNSRTD RADIAMAT DINRTD JISRTD (Default = LINEAR)
22	INPUT CONDITIONING (INPTCOND) LINEAR SQRR00T (Default = LINEAR)
22A	DECIMAL FORMAT (PVFORMAT) D0 D1 D2 D3 (Default = D0)
22B	TEMP. DISPLAY (PVTEMP) DEGREESF DEGREESC (Default = DEGREESF)
23	PV RANGE LOW (PVEULO) (Default = 0.0)
23A	PV DISPLAY RANGE LOW (PVDSPL0) (Default = NaN)

MC ANALOG INPUT DATA POINT (WITH ACCUMULATION) CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY			
24	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0)
24A	PV DISPLAY RANGE HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)
25	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0%)
26	PV RANGE OPTION (PVRNGOP)	NONE FULLRNG CLMPZERO	(Default = NONE)
27	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP CLAMP	(Default = NOCLAMP)
28	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _	(Default = 0.0)
HG ALARMING DISPLAY			
29	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later
30	ALARM FORMAT (ALFMT)	ALFMT00 ALFMT01	(Default = ALFMT00)
30i	ALARM DELAY OPTION (\$ALDLOPT)	NONE OFFDLYLO OFFDLYHI OFFDLYEM ONDLYLO ONDLYHI ONDLYEM	(Default = NONE)
30ii	DELAY TIME (DLYTIME)	_ _ _ _ _ _ _	(Default = 0.0)
30iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _	(Default = 0) R660 & later
30A	PVLOTP (PVLOTP)	_ _ _ _ _ _ _	(Default = 0)
30B	PVHITP (PVHITP)	_ _ _ _ _ _ _	(Default = 0)
30C	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _	(Default = 0%)
30D	DEVHITP (DEVHITP)	_ _ _ _ _ _ _	(Default = 0%)
31	CONFIGURATION ERROR ALARM PRIORITY(CNFERRPR)	NOACTION HIGH JOURNAL EMERGNCY LOW PRINTER JNLPRINT	(Default = LOW)
32	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH JOURNAL EMERGNCY LOW PRINTER JNLPRINT	(Default = LOW)
32A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT ALLOW	(Default = CUTOUT)(R681)
33	PV LOW ALARM PRIORITY(PVLOPR)	NOACTION HIGH JOURNAL EMERGNCY LOW PRINTER JNLPRINT	(Default = LOW)
33A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT ALLOW	(Default = CUTOUT)(R681)

MC ANALOG INPUT DATA POINT (WITH ACCUMULATION) CONFIGURATION FORM

HG ALARMING DISPLAY

33B	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = LOW)
34	CONTACT CUTOFF RANK (CCRANK)	NEITHER PRIMARY		SECNDARY (Default = NEITHER)
34A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)		
35	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _ (Default = All Underscores)		
36	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW LOW_R (Default = Any)
37	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)
37A	ALARM ENABLE STATUS (ALENBST)		<u>Displayed</u>	<u>Logged</u> <u>Reported to EIP</u>
		ENABLE	Yes	Yes Yes
		DISABLE	No	Yes Yes
		INHIBIT	No	No No
		(Default = ENABLE)		

HG OPERATING CONFIGURATION DISPLAY

40	FILTERING CONSTANT CODE (FLTRCNST)	_ _ _	(Default = 0)
41	ACCUMULATION CONFIG (AVCONFIG)	_	(Default = 1)
42	ACCUMULATION CUTOFF (AVCUTOFF)	CUTOFF0 CUTOFF10	(Default = CUTOFF0)

[illegible]

20	OUTPUT INDICATION (OUTIND)	DIRECT REVERSE	(Default = DIRECT)
21	OUTPUT TOLERANCE (%) (\$OPTOL)	_ _ _ _ _ _ _	(Default = 0.0)

30	NORMAL MODE (NMODE)	MAN	CAS	NONE (Default = NONE)
30A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE (Default = NONE)

MC ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY (For Analog Output Data Point)				
31	CASCADE (RCASENB)	OFF	ON	(Default = OFF)
32	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)
33	OPERATING MODE (MODE)			(Default = MAN)
33i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG (Default = All are allowed)

HG PV CONFIGURATION DISPLAY (For Analog Input Data Point)				
40	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _ (Default = All Blanks)		
41	CHARACTERIZATION (PVCHAR)	LINEAR ETHERM BURNSRTD	JTHERM RTHERM RADIAMAT	KTHERM TTHERM RPTHERM STHERM DINRTD JISRTD (Default = LINEAR)
42	INPUT CONDITIONING (INPTCOND)	LINEAR	SQR00T	(Default = LINEAR)
42A	DECIMAL FORMAT (PVFORMAT)	D0	D1	D2 D3 (Default = D0)
42B	TEMP. DISPLAY (PVTEMP)	DEGREESF	DEGREESC	(Default = DEGREESF)
43	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _ (Default = 0.0)		
43A	PV DISPLAY LOW (PVDSPL0)	_ _ _ _ _ _ _ (Default = NaN)		
44	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _ (Default = 100.0)		
44A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _ (Default = NaN)		
45	OVERVIEW VALUE (OVERVAL)	_ _ _ _ (Default = 0%)		
46	PV RANGE OPTION (PVRNGOP)	NONE	FULLRNG	CLMPZERO (Default = NONE)
47	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)
48	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _ (Default = 0)		

MC ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY
(For Analog Input Data Point)

49	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -)	R520 & later
50	ALARM FORMAT (ALFMT)	ALFMT00	ALFMT01	(Default = ALFMT00)
50i	ALARM DELAY OPTION (\$ALDLOPT)	NONE ONDLYLO	OFFDLYLO ONDLYHI	OFFDLYHI OFFDLYEM (Default=NONE) ONDLYEM
50ii	DELAY TIME (DLYTIME)	_ _ _ _		(Default = 0.0)
50iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _		(Default = 0) R660 & later
50A	PVLOTP (PVLOTP)	_ _ _ _		(Default = 0)
50B	PVHITP (PVHITP)	_ _ _ _		(Default = 0)
50C	DEVLOTP (DEVLOTP)	_ _ _ _		(Default = 0%)
50D	DEVHITP (DEVHITP)	_ _ _ _		(Default = 0%)
51	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
52	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
52A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
53	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
53A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
54	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
54A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
55	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)

MC ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY
(For Analog Input Data Point)

55A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	
55B	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = OFF)
56	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY (Default = NEITHER)
56A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _		(Default = All Underscores)
57	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _		(Default = All Underscores)
58	EIP EVENT TYPE (EIPPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW LOW_R (Default = Any)
59	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)

HG OPERATING CONFIGURATION DISPLAY
(For Analog Input Data Point)

59A	ALARM ENABLE STATUS (ALENBST)	ENABLE	<u>Displayed</u> Yes	<u>Logged</u> Yes	<u>Reported to EIP</u> Yes
		DISABLE	No	Yes	Yes
		INHIBIT	No	No	No
		(Default = ENABLE)			
60	FILTERING CONSTANT CODE (FLTRCNST)	_ _			(Default = 0)
61	TARGET (PVTV	_ _ _ _ _ _ _			(Default = 0)

HG POINT ASSIGNMENT DISPLAY

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _				(Default = All Underscores)
2	UNIT ID (UNIT)	_ _ _				(Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _				(Default = All Blanks)
4	POINT KEYWORD	_ _ _ _ _ _ _ _ _ _ _ _ _				(Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _				(Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _				(Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _				(Default = All Blanks)
7	HIWAY NUMBER (HWYNUM)	_ _ _				(Default = 1)
8	BOX TYPE (PNTBOXTY)	HLPIU		MC	DHP	(Enter HLPIU)
9	INPUT BOX NUMBER (BOXNUM)	_ _ _				(Default = 00)
10	OUTPUT BOX NUMBER (OUTBOXNM)	_ _ _				(Default = 00)
11	POINT DISCLOSURE (PIDISCL)	BRIEF		FULL		(Default = BRIEF)
12	INPUT SLOT (SLOTNUM)	_ _ _				(Default = 1)
13	INPUT SUBSLOT NUMBER (INPTSFLT)	_				(Default = 1)
14	OUTPUT SLOT NUMBER (OUTSLTNM)	_ _ _				(Default = 1)
15	OUTPUT SUBSLOT NUMBER (OUTSSFLT)	_				(Default = 1)
16	LOAD DESTINATION (LOADDEST)	HG		HG_HIWAY		(Default = HG)

HG PV CONFIGURATION DISPLAY

20	E.U. DESCRIPTOR (EUDESC)							(Default = All Blanks)
21	CHARACTERIZATION (PVCHAR)	LINEAR	JTHERM	KTHERM	TTHERM	(Default = LINEAR)		
		ETHERM	RTHERM	RP THERM	STHERM			
		BURNSRTD	RADIAMAT	DINRTD	JISRTD			
22	INPUT CONDITIONING (INPTCOND)	LINEAR	SQRR00T (Default = LINEAR)					
22A	DECIMAL FORMAT (PVFORMAT)	D0	D1	D2	D3	(Default = D0)		

MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG PV CONFIGURATION DISPLAY			
22B	TEMP DISPLAY (PVTEMP)	DEGREESF DEGREESC	(Default = DEGREESF)
23	PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0)
23A	PV DISPLAY LOW (PVDSPLO)	_ _ _ _ _ _ _	(Default = NaN)
24	PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0)
24A	PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)
25	OVERVIEW VALUE (OVERVAL)	_ _ _ _	(Default = 0%)
26	PV RANGE OPTION (PVRNGOP)	NONE FULLRNG CLMPZERO	(Default = NONE)
27	CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP CLAMP	(Default = NOCLAMP)
28	CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _	(Default = 0)

HG ALARMING DISPLAY			
29	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later
30	ALARM FORMAT (ALFMT)	ALFMT00 ALFMT01	(Default = ALFMT00)

(For Analog Input Point)

30i	ALARM DELAY OPTION (\$ALDLOPT)	NONE OFFDLYLO OFFDLYHI OFFDLYEM ONDLYLO ONDLYHI ONDLYEM	(Default = NONE)
30ii	DELAY TIME (DLYTIME)	_ _ _ _ _	(Default = 0.0)
30iii	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _	(Default = 0) R660 & later
30A	PVLOTP (PVLOTP)	_ _ _ _ _ _ _	(Default = 0.0)
30B	PVHITP (PVHITP)	_ _ _ _ _ _ _	(Default = 0.0)
30C	DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _	(Default = 0.0%)
30D	DEVHITP (DEVHITP)	_ _ _ _ _ _ _	(Default = 0.0%)
31	CONFIGURATION ERROR ALARM PRIORITY(CNFERRPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT	(Default = NOACTION)(R670)
32	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT	(Default = NOACTION)(R670)
32A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELCT)	CUTOUT ALLOW	(Default = CUTOUT)(R681)
33	DEVIATION LOW ALARM PRIORITY(DEVLOPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT	(Default = NOACTION)(R670)
33A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELCT)	CUTOUT ALLOW	(Default = CUTOUT)(R681)
34	PV HIGH ALARM PRIORITY (PVHIPR)	NOACTION JOURNAL LOW HIGH EMERGNCY PRINTER JNLPRINT	(Default = NOACTION)(R670)

MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
34A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
35	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION	JOURNAL HIGH EMERGNCY	LOW PRINTER JNLPRINT (Default = NOACTION)(R670)
35A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT	ALLOW	(Default = CUTOUT)(R681)
36	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY(Default = NEITHER)
36A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _	(Default = All Blanks)	
37	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _	(Default = All Underscores)	
37A	ALARM ENABLE STATUS (ALENBST)	ENABLE	<u>Displayed</u> Yes	<u>Logged</u> Yes
		DISABLE	No	Yes
		INHIBIT	No	No
		(Default = ENABLE)		
Reported to EIP				
				Yes
				Yes
				No

HG OPERATING CONFIGURATION DISPLAY				
38	EIP EVENT TYPE (EIPEVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW LOW_R (Default = Any)
39	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)
40	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)
41	OUTPUT TOLERANCE (%) (\$OPTOL)	_ _ _ _ _ _ _	(Default = 0.0)	
42	FILTERING CONSTANT CODE (FLTRCNST)	_ _ _	(Default = 0)	
43	TARGET (PVTV)	_ _ _ _ _ _ _	(Default = 0.0)	

HG MODE CONFIGURATION DISPLAY				
50	NORMAL MODE (NMODE)	MAN	CAS	NONE (Default = NONE)
50A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE (Default = NONE)

MC ANALOG COMPOSITE DATA POINT CONFIGURATION FORM

HG MODE CONFIGURATION DISPLAY					
51	CASCADE (RCASENB)	OFF	ON		(Default = OFF)
52	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)
53	OPERATING MODE (MODE)				(Default = MAN)
53i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)

[illegible]

MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY (For Digital Output Data Point)					
20	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _	(Default = UPPER)		
21	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _	(Default = LOWER)		
22	UPPER BOX COLOR (UBOXCLR)	RED GREEN WHITE BLACK CYAN YELLOW BLUE MAGENTA	(Default = RED)		
23	LOWER BOX COLOR (LBOXCLR)	RED GREEN WHITE BLACK CYAN YELLOW BLUE MAGENTA	(Default = RED)		
24	OUTPUT TYPE (PNTOPOP)	PULSEOUT LATCHOUT	(Default = PULSEOUT)		
24A	MOMENTARY O/P IND (MOOUTIND)	NOMOMENT MOMENT	(Default = NOMOMENT)		
24B	PULSEWIDTH (PULSEWTH)	_ _ _ _ _ _ _	(Default = 16.0)		
25	OUTPUT INDICATION (OUTIND)	DIRECT REVERSE	(Default = DIRECT)		
HG MODE CONFIGURATION DISPLAY (For Digital Output Data Point)					
30	NORMAL MODE (NMODE)	MAN CAS NONE	(Default = NONE)		
30A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR PROGRAM NONE	(Default = NONE)		
31	CASCADE (RCASENB)	OFF ON	(Default = OFF)		
32	OPERATOR MODE CHANGE (MODEPERM)	PERMIT NOPERMIT	(Default = PERMIT)		
33	OPERATING MODE (MODE)		(Default = MAN)		
33i	MODE SELECTION LIST (\$MODESEL)	MAN CAS PROG	(Default = All are allowed)		
HG ALARMING DISPLAY (For Digital Input Data Point)					
34	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later		
34i	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _	(Default = 0) R660 & later		
35	ALARM FORMAT (DIGALFMT) [Single Input]	NOALARM STATE1 STATE2 (Default = NOALARM)			
36	ALARM FORMAT (DIGALFMT) [Dual Inputs]	NOALARM INPUT1 INPUT2 EITHER (No Default)			
37	DELAY TIME (DLYTIME)	_ _ (R600 & later)			

MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY (For Digital Input Data Point)					
38	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
39	OFF NORMAL ALARM PRIORITY (OFFNRMPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER (R670)	JNLPRINT
39A	OFF NORMAL SELECTIVE CUTOFF (\$OFSELC)	CUTOFF (Default = CUTOFF)	ALLOW (R681)		
39B	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON		(Default = OFF)
40	CONTACT CUTOFF RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)
40A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)
41	NON-COMP STATE 00 TEXT (ZZTEXT)	TEXT1	TEXT2		(Default = TEXT1)
42	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _			(Default = All Underscores)
43	EIP EVENT TYPE (EIPPEVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2	(Default = Any)
44	EIP ENABLE (EIPENB)	ENABLE	DISABLE		(DEFAULT = Enable)
44A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No
HG OPERATING CONFIGURATION DISPLAY (For Digital Input Data Point)					
50	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _ _ _			(Default = UPPER)
51	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _ _ _			(Default = LOWER)
52	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
53	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)

MC DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY
(For Digital Input Data Point)

54	OVERVIEW VALUE (OVERVAL)	OFF	ON	(Default = OFF)
55	INPUT DIRECTION (INPTDIR)	DIRECT	REVERSE	(Default = DIRECT)

[illegible]

19	AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -)	R520 & later
19A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _	(Default = 0)	R660 & later
20	ALARM FORMAT (DIGALFMT)	NOALARM	STATE1	STATE2
	[Single Input]		(Default = NOALARM)	
				CMDDIS

MC DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY					
21	ALARM FORMAT (DIGALFMT) [Dual Inputs]	NOALARM	INPUT1	INPUT2	EITHER CMDDIS (No Default)
22	DELAY TIME (DLYTIME)	_ _	(R600 & later)		
23	COMMAND DISAGREE ALARM PRIORITY (CMDDISPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
24	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
25	OFF NORMAL ALARM PRIORITY (OFFNRMPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER	JNLPRINT (R670)
25A	OFF NORMAL SELECTIVE CUTOUT (\$OFSELCT)	CUTOUT (Default = CUTOUT)	ALLOW	(R681)	
26	CRITICAL ALARM SCANNING (CRITSCAN)	OFF	ON	(Default = OFF)	
27	CONTACT CUTOUT RANK (CCRANK)	NEITHER	PRIMARY	SECNDARY	(Default = NEITHER)
27A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _	(Default = All Underscores)		
28	NON-COMP STATE 00 TEXT (ZZTEXT)	TEXT1	TEXT2	(Default = TEXT1)	
29	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _	(Default = All Underscores)		
30	EIP EVENT TYPE (EIPEVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2	(Default = Any)
31	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)	
31A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No
HG OPERATING CONFIGURATION DISPLAY					
32	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _ _ _	(Default = UPPER)		
33	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _ _ _	(Default = LOWER)		

MC DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM

HG OPERATING CONFIGURATION DISPLAY					
34	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
35	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
36	OUTPUT TYPE (PNTOPOP)	PULSEOUT LATCHOUT (Default = PULSEOUT)			
36A	MOMENTARY O/P IND (MOOUTIND)	NOMOMENT MOMENT (Default = NOMOMENT)			
36B	PULSEWIDTH (PULSEWTH)	_ _ _ _ _ _ _			(Default = 16.0)
37	OUTPUT INDICATION (OUTIND)	DIRECT REVERSE			(Default = DIRECT)
38	OVERVIEW VALUE (OVERVAL)	OFF	ON	(Default = OFF)	
39	INPUT DIRECTION (INPTDIR)	DIRECT REVERSE			(Default = DIRECT)
HG MODE CONFIGURATION DISPLAY					
40	NORMAL MODE (NMODE)	MAN	CAS	NONE	(Default = NONE)
40A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
41	CASCADE (RCASENB)	OFF	ON	(Default = OFF)	
42	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT	(Default = PERMIT)	
43	OPERATING MODE (MODE)	(Default = MAN)			
43i	MODE SELECTION LIST (\$MODESEL)	MAN	CAS	PROG	(Default = All are allowed)

[illegible]

19	AUXILIARY UNIT (\$AUXUNIT)	_ _ _ (Default = - -)	R520 & later
19A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ (Default = 0)	R660 & later
20	PRE-ALARM VALUE (PDEVTP)	_ _ _ _ _ _ (Default = 0.0)	
21	CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGENCY (R670)
22	PRESET ALARM PRIORITY (PRESETPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGENCY (R670)

MC COUNTER DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY				
23	PRE-PRESET ALARM PRIORITY (PRPRSTPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT (R670)
23A	CRITICAL ALARM SCANNING (CRITSCAN)	OFF ON	(Default = OFF)	
24	CONTACT CUTOFF RANK (CCRANK)	NEITHER PRIMARY SECNDARY	(Default = NEITHER)	
24A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _		(Default = All Underscores)
25	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _		(Default = All Underscores)
26	EIP ENABLE (EIPENB)	ENABLE DISABLE	(Default = Enable)	
26A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT (Default = ENABLE)	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No <u>Reported to EIP</u> Yes Yes No
HG OPERATING CONFIGURATION DISPLAY				
30	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _ _ _		(Default = All Blanks)
31	DECIMAL POINT POSITION (AVFORMAT)	D0 D1 D2 D3	(Default = D0)	
32	SCALE FACTOR (AVCONV)	_ _ _ _ _ _ _		(Default = 1.0)
33	PRESET VALUE (PRESET)	_ _ _ _ _ _ _		(Default = 0)
34	OPERATOR PRESET CHANGE (PRESLOCK)	PERMIT NOPERMIT	(Default = PERMIT)	
35	OPERATOR CONTROL CHANGE (CNTLLOCK)	PERMIT NOPERMIT	(Default = PERMIT)	
36	OVERVIEW VALUE (OVERVAL)	_ _ _ _		(Default = 0)

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
2	UNIT ID (UNIT)	_ _ _ (Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ All Blanks) (Default =
4	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
5	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
6i	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
6	HIWAY NUMBER (HWYNUM)	_ _ _ (Default = 1)
7	BOX TYPE (PNTBOXTY)	(Enter MC)
8	BOX NUMBER (BOXNUM)	_ _ _ (Default = 0)
9	SLOT NUMBER (SLOTNUM)	_ _ _ (Default = 1)

10 SEQUENCE SLOT SIZE (SEQSLTSZ) | | | | (Default = 0)

11 ADVANCED CONTROL POINT ID | | | | | | | | (Default = All
(ACP) Underscores)

1 TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)		
2 UNIT ID (UNIT)	_ _	(Default = All Blanks)		
3 POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)		
4 POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)		
5 PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)		
6 POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)		
6i POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)		
7 HIWAY NUMBER (HWYNUM)	_ _ _	(Default = 1)		
8 BOX TYPE (PNTBOXTY)	EC CB MC	(Enter MC)		
9 BOX NUMBER (BOXNUM)	_ _ _	(Default = 00)		
10 POINT DISCLOSURE (PTDISCL)	BRIEF FULL	(Default = BRIEF)		
11 SLOT NUMBER (SLOTNUM)	_ _ _	(Default = 1)		
12 LOAD DESTINATION (LOADDEST)	HG HG_HIWAY	(Default = HG)		
13 ALGORITHM (ALGIDDAC) (NOTE: For Lines 41-83, refer to the name of the algorithm in the HG Parameter Ref. Dictionary to determine which lines have to be filled out.)	DAS AUTOBIAS PIDERSQG OVERHISL AUTOMAN DIVIDR	PIDNORM PIDCMA PIDERSQI OVERLOSL SWITCH SQRT (NOTE: Use Configuration Form HG88-427 if OVERHISL or OVERLOSL is to be configured.)	PIDRATIO PIDCM PIDGAP SUMRWMAN CBSUMR HISEL	AUTRATIO PIDSPC LEAD LAG MULTWMAN MULT LOSEL

20	E.U. DESCRIPTOR (EUDESC)	_ _ _ _ _ _ _	(Default = All Blanks)		
21	CHARACTERIZATION (PVCHAR)	LINEAR ETHERM BURNSRTD (Default = LINEAR)	JTHERM RTHERM RADIAMAT	KTHERM RP THERM DINRTD	TTHERM STHERM JISRTD
22	INPUT CONDITIONING(INPTCOND)	LINEAR	SQRROOT	(Default = LINEAR)	

MC REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISL and OVERLOSL)

HG PV CONFIGURATION DISPLAY					
22A PV DECIMAL FORMAT (PVFORMAT)	D0	D1	D2	D3	(Default = D0)
22B TEMP DISPLAY (PVTEMP)	DEGREESF		DEGREESC		(DEGREESF)
23 PV RANGE LOW (PVEULO)	_ _ _ _ _ _ _	(Default = 0.0% value)			
23A PV DISPLAY LOW (PVDSPLO)	_ _ _ _ _ _ _	(Default = NaN)			
24 PV RANGE HIGH (PVEUHI)	_ _ _ _ _ _ _	(Default = 100.0% value)			
24A PV DISPLAY HIGH (PVDSPHI)	_ _ _ _ _ _ _	(Default = NaN)			
25 OVERVIEW VALUE(OVERVAL)	_ _ _ _	(Default = 0%)			
26 PV RANGE OPTION(PVRNGOP)	NONE	FULLRNG	CLMPZERO	(Default = NONE)	
27 CLAMP VALUE OPTION (PVCLAMP)	NOCLAMP	CLAMP	(Default = NOCLAMP)		
28 CALIBRATION OFFSET (CALIBOFF)	_ _ _ _ _ _ _	(Default = 0)			
HG ALARMING DISPLAY					
29 AUXILIARY UNIT (\$AUXUNIT)	_ _ _	(Default = - -) R520 & later			
30 ALARM FORMAT (ALFMT)	ALFMT00	ALFMT01	ALFMT02	(Default =ALFMT00)	
	(For Analog Input Point)				
30i ALARM DELAY OPTION (\$ALDLOPT)	NONE	OFFDLYLO	OFFDLYHI	OFFDLYEM	(Default = NONE)
	ONDLYLO	ONDLYHI	ONDLYEM		
30ii DELAY TIME (DLYTIME)	_ _ _ _ _ _ _	(Default = 0.0)			
30iii RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _ _ _	(Default = 0) R660 & later			
30A PVLOTP (PVLOTP)	_ _ _ _ _ _ _	(Default = 0.0)			
30B PVHITP (PVHITP)	_ _ _ _ _ _ _	(Default = 0.0)			
30C DEVLOTP (DEVLOTP)	_ _ _ _ _ _ _	(Default = 0%)			
30D DEVHITP (DEVHITP)	_ _ _ _ _ _ _	(Default = 0%)			
30E PVROCNTP (PVROCNTP)	_ _ _ _ _ _ _	(Default = -1.0)			
30F PVROCPTP (PVROCPTP)	_ _ _ _ _ _ _	(Default = 1.0)			
31 OP ALARM ENABLE (\$OPALEN)	DISABLE	ENABLE	(Default = DISABLE)		
31A OP ALARM DEADBAND (OPALDB)	_ _ _ _ _ _ _	(Default = 5.0)			
31B OPLOTP (OPLOTP)	_ _ _ _ _ _ _	(Default = 0.0)			
31C OPHITP (OPHITP)	_ _ _ _ _ _ _	(Default = 0.0)			

MC REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISEL and OVERLOSEL)

HG OPERATING CONFIGURATION DISPLAY				
31D	CONFIGURATION ERROR ALARM PRIORITY(CNFERRPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
32	DEVIATION HIGH ALARM PRIORITY (DEVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
32A	DEVIATION HIGH SELECTIVE CUTOUT (\$DHSELECT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	
33	DEVIATION LOW ALARM PRIORITY (DEVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
33A	DEVIATION LOW SELECTIVE CUTOUT (\$DLSELECT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	
34	PV HIGH ALARM PRIORITY(PVHIPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
34A	PV HIGH SELECTIVE CUTOUT (\$HISELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	
35	PV LOW ALARM PRIORITY (PVLOPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
35A	PV LOW SELECTIVE CUTOUT (\$LOSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	
36	PV NEGATIVE RATE OF CHANGE ALARM PRIORITY (PVROCNPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
36A	PV NEGATIVE RATE OF CHANGE SELECTIVE CUTOUT (\$RNSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	
37	PV POSITIVE RATE OF CHANGE ALARM PRIORITY (PVROCPPR)	NOACTION HIGH (Default = NOACTION)	JOURNAL EMERGNCY (R670)	LOW PRINTER JNLPRINT
37A	PV POSITIVE RATE OF CHANGE SELECTIVE CUTOUT (\$RPSELCT)	CUTOUT (Default = CUTOUT)	ALLOW (R681)	

MC REGULATORY DATA POINT CONFIGURATION FORM
(For all algorithms except OVERHISEL and OVERLOSEL)

HG OPERATING CONFIGURATION DISPLAY

37B	OP HIGH ALARM PRIORITY (OPHIPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW PRINTER JNLPRINT	(Default = NOACTION)(R670)
37C	OP LOW ALARM PRIORITY (OPLOPR)	NOACTION HIGH	JOURNAL EMERGNCY	LOW (Default = LOW) PRINTER JNLPRINT	(Default = NOACTION)(R670)
38	CRITICAL ALARM SCANNING (CRITSCAN)	OFF ON	(Default = OFF)		
39	CONTACT CUTOFF RANK (CCRANK)	NEITHER PRIMARY	SECNDARY (Default = NEITHER)		
39A	PRIMARY POINT (CCPRIPNT)	_ _ _ _ _ _ _ _ _	(Default = All Underscores)		
40	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _ _ _	(Default = All Underscores)		
41	EIP EVENT TYPE (EIP EVENT)	ANY HIGH	ALARM HIGH_R	RETURN LOW LOW_R	(Default = Any)
42	EIP ENABLE (EIPENB)	ENABLE	DISABLE	(Default = Enable)	
42A	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No
		(Default = ENABLE)			
60	DISPLAY SUPPRESSION (SUPPIO)	NOSUPPR	INPSUPPR	OUTSUPPR	(Default = NOSUPPR)
61*	CONTROL ACTION (CTLACTN)	REVERSE	(Default = DIRECT)		
62*	CONTROL EQUATION (CTLEQN)	EQA EQB	(Default = EQA)		
63*	ANALOG OUTPUT CARD (ANLGCARD)	NOSEL	SEL	(Default = NOSEL)	
64*	ALARM OUTPUT (ALMDIS)	DISABLE	ENABLE	(Default = DISABLE)	
65*	TREND CONFIGURATION (CONFTRND)	AVERAGE	INSTANT	(Default = AVERAGE)	
66*	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE	(Default = DIRECT)	
67*	PV SIGNAL TYPE (PVSIGNAL)	OUTPUT	PV AI	LSP	SQV
		(Default = PV)			
68*	PV INPUT SOURCE (PVSLTSRC)	_ _ _ _ _ _ _ _ _	(Default = Tag name from Line 1)		

MC REGULATORY DATA POINT CONFIGURATION FORM

(For all algorithms except OVERHISEL and OVERLOSEL)

HG MODE CONFIGURATION DISPLAY (For all algorithms except PIDCMA, PIDCM, and PIDSPC)						
100*	NORMAL MODE (NMODE)	MAN	AUTO	CAS	BCAS (Default = NONE)	NONE
100A*	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)	
101*	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR		(Default = NOPASTMR)	
102*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)	
103*	OPERATING MODE (MODE)	MAN			(Default = MAN)	
103i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO	PROG CAS		(Default = All are allowed)	

HG MODE CONFIGURATION DISPLAY (For PIDCMA, PIDCM, and PIDSPC algorithms)						
100*	NORMAL MODE (NMODE)	MAN	AUTO	CAS	BCAS (Default = NONE)	NONE
100A*	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)	
101*	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR		(Default = NOPASTMR)	
102*	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)	
103*	OPERATING MODE (MODE)	MAN			(Default = MAN)	
103i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO BCAS	PROG CAS		(Default = All are allowed)	

[illegible]

20	DISPLAY SUPPRESSION (SUPPIO)	NOSUPPR	INPSUPPR	OUTSUPPR	(Default = NOSUPPR)
21	ALARM OUTPUT (ALMDIS)	DISABLE	ENABLE		(Default = DISABLE)
22	TREND CONFIGURATION (CONFTRND)	AVERAGE	INSTANT		(Default = AVERAGE)
23	OUTPUT INDICATION (OUTIND)	DIRECT	REVERSE		(Default = DIRECT)
24	SLOT 1 SELECTION (OVINSS1)	NOSEL	SEL		(Default = NOSEL)
24A	SIGNAL TYPE (OVSGSS1)	PV	OUTPUT		(Default = OUTPUT)

MC REGULATORY DATA POINT CONFIGURATION FORM
(For OVERHISL and OVERLOSL algorithms)

HG OPERATING CONFIGURATION DISPLAY				
26	SLOT 2 SELECTION (OVINSS2)	NOSEL	SEL	(Default = NOSEL)
26A	SIGNAL TYPE (OVSGSS2)	PV	OUTPUT	(Default = OUTPUT)
27	SLOT 3 SELECTION (OVINSS3)	NOSEL	SEL	(Default = NOSEL)
27A	SIGNAL TYPE (OVSGSS3)	PV	OUTPUT	(Default = OUTPUT)
28	SLOT 4 SELECTION (OVINSS4)	NOSEL	SEL	(Default = NOSEL)
28A	SIGNAL TYPE (OVSGSS4)	PV	OUTPUT	(Default = OUTPUT)
29	SLOT 5 SELECTION (OVINSS5)	NOSEL	SEL	(Default = NOSEL)
29A	SIGNAL TYPE (OVSGSS5)	PV	OUTPUT	(Default = OUTPUT)
30	SLOT 6 SELECTION (OVINSS6)	NOSEL	SEL	(Default = NOSEL)
30A	SIGNAL TYPE (OVSGSS6)	PV	OUTPUT	(Default = OUTPUT)
31	SLOT 7 SELECTION (OVINSS7)	NOSEL	SEL	(Default = NOSEL)
31A	SIGNAL TYPE (OVSGSS7)	PV	OUTPUT	(Default = OUTPUT)
32	SLOT 8 SELECTION (OVINSS8)	NOSEL	SEL	(Default = NOSEL)
32A	SIGNAL TYPE (OVSGSS8)	PV	OUTPUT	(Default = OUTPUT)
33	SLOT 9 SELECTION (OVINSS9)	NOSEL	SEL	(Default = NOSEL)
33A	SIGNAL TYPE (OVSGSS9)	PV	OUTPUT	(Default = OUTPUT)
34	SLOT 10 SELECTION (OVINSS10)	NOSEL	SEL	(Default = NOSEL)
34A	SIGNAL TYPE (OVSGSS10)	PV	OUTPUT	(Default = OUTPUT)
35	SLOT 11 SELECTION (OVINSS11)	NOSEL	SEL	(Default = NOSEL)
35A	SIGNAL TYPE (OVSGSS11)	PV	OUTPUT	(Default = OUTPUT)
36	SLOT 12 SELECTION (OVINSS12)	NOSEL	SEL	(Default = NOSEL)
36A	SIGNAL TYPE (OVSGSS12)	PV	OUTPUT	(Default = OUTPUT)

MC REGULATORY DATA POINT CONFIGURATION FORM
(For OVERHISL and OVERLOSL algorithms)

HG OPERATING CONFIGURATION DISPLAY					
37	SLOT 13 SELECTION (OVINSS13)	NOSEL	SEL		(Default = NOSEL)
37A	SIGNAL TYPE (OVSGSS13)	PV	OUTPUT		(Default = OUTPUT)
38	SLOT 14 SELECTION (OVINSS14)	NOSEL	SEL		(Default = NOSEL)
38A	SIGNAL TYPE (OVSGSS14)	PV	OUTPUT		(Default = OUTPUT)
39	SLOT 15 SELECTION (OVINSS15)	NOSEL	SEL		(Default = NOSEL)
39A	SIGNAL TYPE (OVSGSS15)	PV	OUTPUT		(Default = OUTPUT)
40	SLOT 16 SELECTION (OVINSS16)	NOSEL	SEL		(Default = NOSEL)
40A	SIGNAL TYPE (OVSGSS16)	PV	OUTPUT		(Default = OUTPUT)
41	OUTPUT LOW LIMIT (%) (OPLOLM)	_ _ _ _ _ _ _			(Default = -5.0)
42	OUTPUT HIGH LIMIT (%) (OPHILM)	_ _ _ _ _ _ _			(Default = 105.0)
43	OUTPUT TOLERANCE (\$OPTOL)	_ _ _ _ _ _ _			(Default = 0.0)
44	FILTER CONSTANT (TD)	_ _ _ _ _ _ _			(Default = 0.0)
HG MODE CONFIGURATION DISPLAY					
50	NORMAL MODE (NMODE)	MAN	AUTO	CAS	NONE (Default = NONE)
50A	NORMAL MODE ATTRIBUTE (NMODATTR)	OPERATOR	PROGRAM	NONE	(Default = NONE)
51	PAST MODE RECALL (PSTMODE)	NOPASTMR	PASTMR		(Default = NOPASTMR)
52	OPERATOR MODE CHANGE (MODEPERM)	PERMIT	NOPERMIT		(Default = PERMIT)
53	OPERATING MODE (MODE)				(Default = MAN)
53i	MODE SELECTION LIST (\$MODESEL)	MAN AUTO	PROG CAS		(Default = All are allowed)

1 TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
2 UNIT ID (UNIT)	_ _ _	(Default = All Blanks)
3 POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
4 POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
5 PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Underscores)
6 POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
6i POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _	(Default = All Blanks)
7 HIWAY NUMBER (HWYNUM)	_ _ _	(Default = 1)
8 BOX TYPE (PNTBOXTY)	(Enter MC)	
9 BOX NUMBER (BOXNUM)	_ _ _	(Default = 00)

10	AUXILIARY UNIT (\$AUXUNIT)	_ _	(Default = - -)	R520 & later
10A	RE-ALARMING INTERVAL (\$REALARM)	_ _ _ _ _	(Default = 0)	R660 & later (Only the first 64 flag points can generate an alarm)
11	CONFIGURATION ERROR	NOACTION	JOURNAL	LOW
	ALARM PRIORITY (CNFERRPR)	HIGH	EMERGENCY	PRINTER JNLPRINT
		(Default = NOACTION)(R670)		
12	FLAG	NOACTION	JOURNAL	LOW
	ALARM PRIORITY (FLAGPR)	HIGH	EMERGENCY	PRINTER JNLPRINT
		(Default = NOACTION)(R670)		
12A	CRITICAL ALARM SCANNING	OFF	ON	(Default = OFF) (CRITSCAN)
13	CONTACT CUTOFF RANK (CCRANK)	NEITHER	PRIMARY	SECONDARY (Default = NEITHER)
13A	PRIMARY ID (CCPRIPNT)	_ _ _ _ _ _ _		(Default = All Underscores)
14	EIP POINT ID (EIPPCODE)	_ _ _ _ _ _ _		(Default = All Underscores)

MC FLAG DATA POINT CONFIGURATION FORM

HG ALARMING DISPLAY					
15	EIP EVENT TYPE (EIPEVENT)	ANY CHGSTATE	ALARM STATE1	RETURN STATE2	(Default = Any)
16	EIP ENABLE (EIPENB)	ENABLE	DISABLE		(Default = Enable)
17	ALARM ENABLE STATUS (ALENBST)	ENABLE DISABLE INHIBIT	<u>Displayed</u> Yes No No	<u>Logged</u> Yes Yes No	<u>Reported to EIP</u> Yes Yes No (Default = ENABLE)
HG OPERATING CONFIGURATION DISPLAY					
20	FLAG NUMBER (INTVARNM)	_ _ _			(Default = 1)
21	UPPER BOX TEXT (STATE2)	_ _ _ _ _ _			(Default = UPPER)
22	LOWER BOX TEXT (STATE1)	_ _ _ _ _ _			(Default = LOWER)
23	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
24	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
25	OVERVIEW VALUE (OVERVAL)	OFF	ON		(Default = OFF)

MC NUMERIC DATA POINT CONFIGURATION FORM

[illegible]

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
2	UNIT ID (UNIT)	_ _ (Default = All Blanks)
3	POINT DESCRIPTOR (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
4	POINT KEYWORD (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
5	PRIMARY MODULE POINT ID (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
6	POINT ASSOCIATED DISPLAY (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
6 <i>i</i>	POINT CUSTOM DISPLAY (\$CDETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
7	HIWAY NUMBER (HWYNUM)	_ _ _ (Default = 1)
8	BOX TYPE (PNTBOXTY)	(Enter MC)
9	BOX NUMBER (BOXNUM)	_ _ _ (Default = 00)
10	LOAD DESTINATION (LOADDEST)	HG HG_HIWAY (Default = HG)

11	TIMER NUMBER (INTVARNM)	_ _	(Default = 1)
12	TIME BASE (TIMEBASE)	SECONDS MINUTES	(Default = SECONDS)
13	PRESET TIME VALUE (SP)	_ _ _ _	(Default = 0)
14	OPERATOR PRESET CHANGE (SPLOCK)	PERMIT NOPERMIT	(Default = PERMIT)
15	OPERATOR CONTROL CHANGE (CNTLLOCK)	PERMIT NOPERMIT	(Default = PERMIT)
16	E.U. DESCRIPTOR (EUEDESC)	_ _ _ _ _ _ _	(Default = All Blanks)

HIWAY CONFIGURATION FORM

HG HIWAY POINT ASSIGNMENT DISPLAY

- | | | | |
|----|--------------------------------------|--|---------------------|
| 1 | HIWAY NUMBER
(HWYNUM) | _ _ | (Default = 01) |
| 2 | HTD ASSIGNMENT
(HWYHTD) | THISHG REMOTEHG HTD ADDEDHG | (Default = HTD) |
| 2A | SWITCH INTERVAL (MIN)
(HWYSWINT) | _ _ _ _ | (Default = 1440) |
| 2B | SWITCH BASE TIME (MIN)
(HWYSWBAS) | _ _ _ _ | (Default = 0) |
| 3 | SOE SYNCHRONIZATION
(SOESYNCH) | DISABLE ENABLE | (Default = DISABLE) |
| 4 | COMMAND DISAGREE TEXT
(CDTEXT) | _ _ _ _ _ _ _ _ | (Default = CMDDIS) |

DUAL DIGITAL INPUT NONCOMPLEMENTARY TEXT

- | | | | |
|---|---------------------------------|-----------------|---------------------|
| 5 | TEXT1
(NCMPTXT1) | _ _ _ _ _ _ _ _ | (Default = BADPV) |
| 6 | TEXT2
(NCMPTXT2) | _ _ _ _ _ _ _ _ | (Default = INBETWN) |
| 7 | \$OP SCAN PERIOD
(\$OPSNPRD) | _ _ _ _ | (Default = 0) |

1	TAG NAME (NAME)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
2	UNIT ID (UNIT) (PTDESC)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ All Blanks)
3	POINT DESCRIPTOR (KEYWORD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
4	POINT KEYWORD (KEYWORD) (PRIMMOD)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Underscores)
5	PRIMARY MODULE POINT ID (ASSOCDSP)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
6i	POINT ASSOCIATED DISPLAY (\$DETAIL)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = All Blanks)
7	POINT CUSTOM DISPLAY (HWYNUM)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = 1)
8	HIWAY NUMBER (HWYNUM) (PNTBOXTY)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (No entry is required)
9	BOX TYPE (PNTBOXTY) (BOXNUM)	_ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (Default = 00)

10	LOGIC BLOCK NUMBER (INTVARNM)	_ _ _	(Default = 1)		
11	UPPER BOX TEXT (STATE2)	_ _ _ _ _	(Default = UPPER)		
12	LOWER BOX TEXT (STATE1)	_ _ _ _ _	(Default = LOWER)		
13	UPPER BOX COLOR (UBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)
14	LOWER BOX COLOR (LBOXCLR)	RED CYAN	GREEN YELLOW	WHITE BLUE	BLACK MAGENTA (Default = RED)

HG BOX DATA POINT CONFIGURATION FORM

HG BOX POINT DISPLAY				
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)	
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI LLPIU ECRCD OPSTA NOTCONFG (Enter HG)
4	BOX ASSIGNMENT (BOXASSN)	THISHG	REMOTEHG	ADDEDHG (Default = THISHG)
5	EVENT PROCESSING (EVENTPRC)	DISABLE (Default = DISABLE only for this box type)		
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)	
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI LLPIU ECRCD OPSTA NOTCONFG (Enter HG)
4	BOX ASSIGNMENT (BOXASSN)	THISHG	REMOTEHG	ADDEDHG (Default = THISHG)
5	EVENT PROCESSING (EVENTPRC)	DISABLE (Default = DISABLE only for this box type)		
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)	
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI LLPIU ECRCD OPSTA NOTCONFG (Enter HG)
4	BOX ASSIGNMENT (BOXASSN)	THISHG	REMOTEHG	ADDEDHG (Default = THISHG)
5	EVENT PROCESSING (EVENTPRC)	DISABLE (Default = DISABLE only for this box type)		

CB BOX DATA POINT CONFIGURATION FORM

HG CB BOX POINT DISPLAY				
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)	
3	BOX TYPE (BOXTYPE)	CB	AU	HLPIU LLPIU
		LEPIU	CBRCDC	EC ECRCD
		MC	MCRCD	DHP OPSTA
		H4500	HG	GPCI NOTCONFG (Enter CB)
4	BOX ASSIGNMENT ** (BOXASSN)	THISHG	REMO TEHG	ADDEDHG H4500 (Default = THISHG)
5	LOAD DESTINATION ** (LOADDEST)	HG	HG HIWAY	(Default = HG)
6	CHANGE DETECTION (CHNGFLAG)	NOTCONFG	DETECT	SET (Default = NOTCONFG)
7	EVENT PROCESSING (EVENTPRC)	DISABLE	ENABLE	(Default = DISABLE)
8	BOX TRENDING (BOXTREND)	NOTREND	TREND	(Default = NOTREND)
9	TOG INTERVAL 1 *** (BOXTOG1)	_ _ _ _	(Default = 0 seconds)	
10	TOG INTERVAL 2 *** (BOXTOG2)	_ _ _ _	(Default = 0 seconds)	
10A	SLOT 1 TOG INTERVAL (TOGINTSL)	INTERV1	INTERV2	(Default = INTERV1)
10B	SLOT 2 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
10C	SLOT 3 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
10D	SLOT 4 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
10E	SLOT 5 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
10F	SLOT 6 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
10G	SLOT 7 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
10H	SLOT 8 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY				
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)	
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI NOTCONFG (Enter DHP)
4	BOX ASSIGNMENT ** (BOXASSN)	THISHG H4500	REMOTEHG	ADDEDHG (Default = THISHG)
5	LOAD DESTINATION ** (LOADDEST)	HG	HG HIWAY	(Default = HG)
6	DHP BOX SIZE (BOXSIZE)	REGULAR	EXTENDED	(Default = REGULAR)
7	BOX PROTOCOL (BOXPROT)	ALLENBRD	MODICON	HONYWELL (Default = ALLENBRD)
8	BOX STARTUP (BOXSTART)	COLD	HOT	(Default = COLD)
9	SCAN TIME(SEC) (SCANTIME)	_ _	(Default = 0)	
10	PC1 MODEL TYPE (PC1TYPE)	NOTCONFG	M384	M484 M584 (For Modicon)
		(Default = NOTCONFG)-----		
		NOTCONFG	APLC	APLC2 APLC215
		APLC220	APLC230	AMINPLC2 (For Allen Bradley)
		(Default = NOTCONFG)-----		
		NOTCONFG IPC620 (For Honeywell)		
		(Default = NOTCONFG)-----		
10A	PORT NUMBER (PC1PORT)	_	(Default = 1)	
10B	PORT ADDRESS (PC1PORTA)	_ _ _	(Default = 0)	
10C	KEEP ALIVE ADDRESS (PC1ALIVE)	_ _ _ _	(Default = 0)	
10D	KEEP ALIVE BIT POSITION (PC1ALVBT)	_ _	(Default = 0)	
10E	SPECIFIER (PC1ALVSP)	_	(Default = 0)	
11	PC2 MODEL TYPE (PC2TYPE)	NOTCONFG	M384	M484 M584 (For Modicon)

		NOTCONFG	APLC	APLC2 APLC215
		APLC220	APLC230	AMINPLC2 (For Allen Bradley)

		NOTCONFG IPC620 (For Honeywell)		

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY				
11A PORT NUMBER (PC2PORT)	__	(Default = 1)		
11B PORT ADDRESS (PC2PORTA)	__ __ __	(Default = 0)		
11C KEEP ALIVE ADDRESS (PC2ALIVE)	__ __ __ __	(Default = 0)		
11D KEEP ALIVE BIT POSITION (PC2ALVBT)	__ __	(Default = 0)		
11E SPECIFIER (PC2ALVSP)	__	(Default = 0)		
12 PC3 MODEL TYPE (PC3TYPE)	NOTCONFIG M384 M484 M584 (For Modicon) ----- NOTCONFIG APLC APLC2 APLC215 APLC220 APLC230 AMINPLC2 (For Allen Bradley) ----- NOTCONFIG IPC620 (For Honeywell) -----			
12A PORT NUMBER (PC3PORT)	__	(Default = 1)		
12B PORT ADDRESS (PC3PORT)	__ __ __	(Default = 0)		
12C KEEP ALIVE ADDRESS (PC3ALIVE)	__ __ __ __	(Default = 0)		
12D KEEP ALIVE BIT POSITION (PC3ALVBT)	__ __	(Default = 0)		
12E SPECIFIER (PC3ALVSP)	__	(Default = 0)		
13 PC4 MODEL TYPE (PC4TYPE)	NOTCONFIG M384 M484 M584 (For Modicon) ----- NOTCONFIG APLC APLC2 APLC215 APLC220 APLC230 AMINPLC2 (For Allen Bradley) ----- NOTCONFIG IPC620 (For Honeywell) -----			
13A PORT NUMBER (PC4PORT)	__	(Default = 1)		
13B PORT ADDRESS (PC4PORTA)	__ __ __	(Default = 0)		
13C KEEP ALIVE ADDRESS (PC4ALIVE)	__ __ __ __	(Default = 0)		
13D KEEP ALIVE BIT POSITION (PC4ALVBT)	__ __	(Default = 0)		
13E SPECIFIER (PC4ALVSP)	__	(Default = 0)		

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY				
14	PC5 MODEL TYPE (PC5TYPE)	NOTCONFG	M384	M484 M584 (For Modicon)

		NOTCONFG	APLC	APLC2 APLC215
		APLC220	APLC230	AMINPLC2 (For Allen Bradley)

		NOTCONFG	IPC620	(For Honeywell)

14A	PORT NUMBER (PC5PORT)	__	(Default = 1)	
14B	PORT ADDRESS (PC5PORTA)	__ __ __	(Default = 0)	
14C	KEEP ALIVE ADDRESS (PC5ALIVE)	__ __ __ __	(Default = 0)	
14D	KEEP ALIVE BIT POSITION (PC5ALVBT)	__ __	(Default = 0)	
14E	SPECIFIER (PC5ALVSP)	__	(Default = 0)	
15	PC6 MODEL TYPE (PC6TYPE)	NOTCONFG	M384	M484 M584 (For Modicon)

		NOTCONFG	APLC	APLC2 APLC215
		APLC220	APLC230	AMINPLC2 (For Allen Bradley)

		NOTCONFG	IPC620	(For Honeywell)

15A	PORT NUMBER (PC6PORT)	__	(Default = 1)	
15B	PORT ADDRESS (PC6PORTA)	__ __ __	(Default = 0)	
15C	KEEP ALIVE ADDRESS (PC6ALIVE)	__ __ __ __	(Default = 0)	
15D	KEEP ALIVE BIT POSITION (PC6ALVBT)	__ __	(Default = 0)	
15E	SPECIFIER (PC6ALVSP)	__	(Default = 0)	
16	PC7 MODEL TYPE (PC7TYPE)	NOTCONFG	M384	M484 M584 (For Modicon)

		NOTCONFG	APLC	APLC2 APLC215
		APLC220	APLC230	AMINPLC2 (For Allen Bradley)

		NOTCONFG	IPC620	(For Honeywell)

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY				
16A	PORT NUMBER (PC7PORT)	__	(Default = 1)	
16B	PORT ADDRESS (PC7PORTA)	__ __ __	(Default = 0)	
16C	KEEP ALIVE ADDRESS (PC7ALIVE)	__ __ __	(Default = 0)	
16D	KEEP ALIVE BIT POSITION (PC7ALVBT)	__ __	(Default = 0)	
16E	SPECIFIER (PC7ALVSP)	__	(Default = 0)	
17	PC8 MODEL TYPE (PC8TYPE)	NOTCONFG M384 M484 M584 (For Modicon) ----- NOTCONFG APLC APLC2 APLC215 APLC220 APLC230 AMINPLC2 (For Allen Bradley) ----- NOTCONFG IPC620 (For Honeywell) -----		
17A	PORT NUMBER (PC8PORT)	__	(Default = 1)	
17B	PORT ADDRESS (PC8PORTA)	__ __ __	(Default = 0)	
17C	KEEP ALIVE ADDRESS (PC8ALIVE)	__ __ __	(Default = 0)	
17D	KEEP ALIVE BIT POSITION (PC8ALVBT)	__ __	(Default = 0)	
17E	SPECIFIER (PC8ALVSP)	__	(Default = 0)	
18	SLOT 1 TYPE (PIUCRDY)	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
19	SLOT 2 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
20	SLOT 3 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
21	SLOT 4 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
22	SLOT 5 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
23	SLOT 6 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
24	SLOT 7 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY				
25	SLOT 8 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
26	SLOT 9 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
27	SLOT 10 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
28	SLOT 11 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
29	SLOT 12 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
30	SLOT 13 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
31	SLOT 14 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
32	SLOT 15 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
33	SLOT 17 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
34	SLOT 18 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
35	SLOT 19 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
36	SLOT 20 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
37	SLOT 21 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
38	SLOT 22 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
39	SLOT 23 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER
40	SLOT 24 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT (Default = NONE) COUNTER

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY				
41	SLOT 25 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
42	SLOT 26 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
43	SLOT 27 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
44	SLOT 28 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
45	SLOT 29 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
46	SLOT 30 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
47	SLOT 31 TYPE	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER (Default = NONE)
48	CHANGE DETECTION (CHNGFLAG)	NOTCONFG	DETECT	SET (Default = NOTCONFG)
49	EVENT PROCESSING (EVENTPRC)	DISABLE	ENABLE	(Default = DISABLE)
50	VARIABLE DEADBAND (BOXVDB)	OFF	ON	(Default = OFF)
50 ***	TOG INTERVAL 1 (BOXTOG1)	_ _ _ _		(Default = 0 seconds)
51 ***	TOG INTERVAL 2 (BOXTOG2)	_ _ _ _		(Default = 0 seconds)
51A	SLOT 1 TOG INTERVAL (TOGINTSL)	INTERVL1	INTERVL2	(Default = INTERVL1)
51B	SLOT 2 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)
51C	SLOT 3 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)
51D	SLOT 4 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)
51E	SLOT 5 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)
51F	SLOT 6 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)
51G	SLOT 7 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)
51H	SLOT 8 TOG INTERVAL	INTERVL1	INTERVL2	(Default = INTERVL1)

DHP/620-HIM BOX DATA POINT CONFIGURATION FORM

HG DHP BOX POINT DISPLAY		
52I SLOT 9 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52J SLOT 10 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52K SLOT 11 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52L SLOT 12 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52M SLOT 13 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52N SLOT 14 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52O SLOT 15 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AA SLOT 17 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AB SLOT 18 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AC SLOT 19 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AD SLOT 20 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AE SLOT 21 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AF SLOT 22 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AG SLOT 23 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AH SLOT 24 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AI SLOT 25 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AJ SLOT 26 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AK SLOT 27 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AL SLOT 28 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AM SLOT 29 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AN SLOT 30 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)
52AO SLOT 31 TOG INTERVAL	INTERVL1	INTERVL2 (Default = INTERVL1)

EC BOX DATA POINT CONFIGURATION FORM

HG EC BOX POINT DISPLAY				
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 5)	
3	BOX TYPE (BOXTYPE)	CB	AU	HLPIU LLPIU
		LEPIU	CBRCD	EC ECRCD
		MC	MCRCD	DHP OPSTA
		H4500	HG	GPCI NOTCONFG (Enter EC)
4	BOX ASSIGNMENT ** (BOXASSN)	THISHG	REMOTEHG	ADDEDHG (Default = THISHG)
5	LOAD DESTINATION ** (LOADDEST)	HG	HG HIWAY	(Default = HG)
6	CHANGE DETECTION (CHNGFLAG)	NOTCONFG	DETECT	SET (Default = NOTCONFG)
7	EVENT PROCESSING (EVENTPRC)	DISABLE	ENABLE	(Default = DISABLE)
8	TOG INTERVAL 1 *** (BOXTOG1)	_ _ _ _	(Default = 0)	
9	TOG INTERVAL 2 *** (BOXTOG2)	_ _ _ _	(Default = 0)	
9A	SLOT 1 TOG INTERVAL (TOGINTSL)	INTERV1	INTERV2	(Default = INTERV1)
9B	SLOT 2 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9C	SLOT 3 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9D	SLOT 4 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9F	SLOT 5 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9G	SLOT 6 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9H	SLOT 7 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9I	SLOT 8 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9J	SLOT 9 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9K	SLOT 10 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9L	SLOT 11 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9M	SLOT 12 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9N	SLOT 13 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9O	SLOT 14 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9P	SLOT 15 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
9Q	SLOT 16 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)		
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)		
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI	LLPIU ECRCD OPSTA NOTCONFG (Enter HLPIU)
4	BOX ASSIGNMENT ** (BOXASSN)	THISHG	REMOTEHG	ADDEDHG	SET (Default = THISHG)
5	LOAD DESTINATION ** (LOADDEST)	HG	HG HIWAY		(Default = HG)
6	PIU BOX SIZE (BOXSIZE)	REGULAR	EXTENDED		(Default = REGULAR)
7	SLOT 1 CARD TYPE (PIUCRDY)	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER	(Default = NONE)
7A	SLOT 1 CARD OPTION (PIUCRDOP)	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
7B	SLOT 1 CARD OPTION (PIUCRDOP)	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
7C	SLOT 1 CARD OPTION (PIUCRDOP)	COUNTR16	COUNTR32		(Default = COUNTR16)
8	SLOT 2 CARD TYPE (PIUCRDY)	NONE ANALOGIN	DIGIN ANALOGOT	DIGOUT COUNTER	(Default = NONE)
8A	SLOT 2 CARD OPTION (PIUCRDOP)	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
8B	SLOT 2 CARD OPTION (PIUCRDOP)	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
8C	SLOT 2 CARD OPTION (PIUCRDOP)	COUNTR16	COUNTR32		(Default = COUNTR16)

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY					
9	SLOT 3 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
9A	SLOT 3 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
9B	SLOT 3 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
9C	SLOT 3 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
10	SLOT 4 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
10A	SLOT 4 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
10B	SLOT 4 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
10C	SLOT 4 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
11	SLOT 5 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
11A	SLOT 5 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
11B	SLOT 5 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
11C	SLOT 5 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
12	SLOT 6 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
12A	SLOT 6 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
12B	SLOT 6 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
12C	SLOT 6 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

13	SLOT 7 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
13A	SLOT 7 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
13B	SLOT 7 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
13C	SLOT 7 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
14	SLOT 8 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
14A	SLOT 8 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
14B	SLOT 8 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
14C	SLOT 8 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
15	SLOT 9 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
15A	SLOT 9 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
15B	SLOT 9 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PI9CRDOP)				
15C	SLOT 9 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
16	SLOT 10 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
16A	SLOT 10 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
16B	SLOT 10 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
16C	SLOT 10 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY				
17	SLOT 11 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
17A	SLOT 11 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
17B	SLOT 11 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
17C	SLOT 11 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			
18	SLOT 12 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
18A	SLOT 12 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
18B	SLOT 12 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
18C	SLOT 12 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			
19	SLOT 13 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
19A	SLOT 13 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
19B	SLOT 13 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
19C	SLOT 13 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			
20	SLOT 14 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
20A	SLOT 14 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
20B	SLOT 14 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
20C	SLOT 14 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

21	SLOT 15 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
21A	SLOT 15 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
21B	SLOT 15 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
21C	SLOT 15 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
22	SLOT 16 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
22A	SLOT 16 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
22B	SLOT 16 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
22C	SLOT 16 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
23	SLOT 17 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
23A	SLOT 17 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
23B	SLOT 17 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
23C	SLOT 17 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
24	SLOT 18 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
24A	SLOT 18 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
24B	SLOT 18 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
24C	SLOT 18 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY					
25	SLOT 19 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
25A	SLOT 19 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
25B	SLOT 19 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
25C	SLOT 19 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
26	SLOT 20 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
26A	SLOT 20 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
26B	SLOT 20 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
26C	SLOT 20 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
27	SLOT 21 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
27A	SLOT 17 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
27B	SLOT 17 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
27C	SLOT 17 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
28	SLOT 18 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
28A	SLOT 18 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
28B	SLOT 18 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
28C	SLOT 18 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

29	SLOT 23 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
29A	SLOT 23 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
29B	SLOT 23 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
29C	SLOT 23 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
30	SLOT 24 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
30A	SLOT 24 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
30B	SLOT 24 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
30C	SLOT 24 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
31	SLOT 25 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
31A	SLOT 25 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
31B	SLOT 25 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
31C	SLOT 25 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
32	SLOT 26 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
32A	SLOT 26 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
32B	SLOT 26 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
32C	SLOT 26 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY				
33	SLOT 27 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
33A	SLOT 27 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
33B	SLOT 27 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
33C	SLOT 27 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			
34	SLOT 28 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
34A	SLOT 28 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
34B	SLOT 28 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
34C	SLOT 28 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			
35	SLOT 29 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
35A	SLOT 29 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
35B	SLOT 29 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
35C	SLOT 29 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			
36	SLOT 30 CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER
36A	SLOT 30 CARD OPTION	NOTIFYST	CHNGDECT	SOE (Default = NOTIFYST)
	(PIUCRDOP)			
36B	SLOT 30 CARD OPTION	PULSEOUT	LATCHOUT	(Default = PULSEOUT)
	(PIUCRDOP)			
36C	SLOT 30 CARD OPTION	COUNTR16	COUNTR32	(Default = COUNTR16)
	(PIUCRDOP)			

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

37	SLOT 31 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
37A	SLOT 31 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
37B	SLOT 31 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
37C	SLOT 31 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				
38	SLOT 32 CARD TYPE	NONE	DIGIN	DIGOUT	(Default = NONE)
	(PIUCRDY)	ANALOGIN	ANALOGOT	COUNTER	
38A	SLOT 32 CARD OPTION	NOTIFYST	CHNGDECT	SOE	(Default = NOTIFYST)
	(PIUCRDOP)				
38B	SLOT 32 CARD OPTION	PULSEOUT	LATCHOUT		(Default = PULSEOUT)
	(PIUCRDOP)				
38C	SLOT 32 CARD OPTION	COUNTR16	COUNTR32		(Default = COUNTR16)
	(PIUCRDOP)				

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

39	CHANGE DETECTION (CHNGFLAG)	NOTCONFIG	DETECT	SET	(Default = NOTCONFIG)
40	EVENT PROCESSING (EVENTPRC)	DISABLE	ENABLE		(Default = DISABLE)
41	TOG INTERVAL 1 *** (BOXTOG1)	_ _ _ _			(Default = 0 seconds)
42	TOG INTERVAL 2 *** (BOXTOG2)	_ _ _ _			(Default = 0 seconds)
42A	SLOT 1 TOG INTERVAL (TOGINTSL)	INTERV1	INTERV2		(Default = INTERV1)
42B	SLOT 2 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42C	SLOT 3 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42D	SLOT 4 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42E	SLOT 5 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42F	SLOT 6 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42G	SLOT 7 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42H	SLOT 8 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42I	SLOT 9 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42J	SLOT 10 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42K	SLOT 11 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42L	SLOT 12 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42M	SLOT 13 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42N	SLOT 14 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)
42O	SLOT 15 TOG INTERVAL	INTERV1	INTERV2		(Default = INTERV1)

HLPIU BOX DATA POINT CONFIGURATION FORM

HG HLPIU BOX POINT DISPLAY

42P	SLOT 16	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42Q	SLOT 17	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42R	SLOT 18	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42S	SLOT 19	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42T	SLOT 20	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42U	SLOT 21	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42V	SLOT 22	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42W	SLOT 23	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42X	SLOT 24	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42Y	SLOT 25	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42Z	SLOT 26	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42AA	SLOT 27	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42AB	SLOT 28	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42AC	SLOT 29	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42AD	SLOT 30	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42AE	SLOT 31	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
42AF	SLOT 32	TOG	INTERVAL	INTERV1	INTERV2	(Default = INTERV1)

LEPIU BOX DATA POINT CONFIGURATION FORM

HG LEPIU BOX POINT DISPLAY					
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)		
2	BOX NUMBER (BOXNUM)	_ _	(Default = 5)		
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI	LLPIU ECRCD OPSTA NOTCONF (Enter LEPIU)
4	BOX ASSIGNMENT (BOXASSN)	THISHG	REMOTEHG	ADDEDHG	H4500 (Default = THISHG)
5	LOAD DESTINATION (LOADDEST)	HG	HG HIWAY	(Default = HG)	
6	PIU BOX SIZE (BOXSIZE)	REGULAR	EXTENDED	(Default = REGULAR)	
7	SLOT 1 CARD TYPE (PIUCRDY)	NONE	ANALOGIN	(Default = NONE for each Card Slot)	
8	SLOT 2 CARD TYPE	NONE	ANALOGIN		
9	SLOT 3 CARD TYPE	NONE	ANALOGIN		
10	SLOT 4 CARD TYPE	NONE	ANALOGIN		
11	SLOT 5 CARD TYPE	NONE	ANALOGIN		
12	SLOT 6 CARD TYPE	NONE	ANALOGIN		
13	SLOT 7 CARD TYPE	NONE	ANALOGIN		
14	SLOT 8 CARD TYPE	NONE	ANALOGIN		
15	SLOT 9 CARD TYPE	NONE	ANALOGIN		
16	SLOT 10 CARD TYPE	NONE	ANALOGIN		
17	SLOT 11 CARD TYPE	NONE	ANALOGIN		
18	SLOT 12 CARD TYPE	NONE	ANALOGIN		
19	SLOT 13 CARD TYPE	NONE	ANALOGIN		
20	SLOT 14 CARD TYPE	NONE	ANALOGIN		
21	SLOT 15 CARD TYPE	NONE	ANALOGIN		
22	SLOT 16 CARD TYPE	NONE	ANALOGIN		

LEPIU BOX DATA POINT CONFIGURATION FORM

HG LEPIU BOX POINT DISPLAY					
23	SLOT 17	CARD TYPE	NONE	ANALOGIN	(Default = NONE for each Card Slots)
24	SLOT 18	CARD TYPE	NONE	ANALOGIN	
25	SLOT 19	CARD TYPE	NONE	ANALOGIN	
26	SLOT 20	CARD TYPE	NONE	ANALOGIN	
27	SLOT 21	CARD TYPE	NONE	ANALOGIN	
28	SLOT 22	CARD TYPE	NONE	ANALOGIN	
29	SLOT 23	CARD TYPE	NONE	ANALOGIN	
30	SLOT 24	CARD TYPE	NONE	ANALOGIN	
31	SLOT 25	CARD TYPE	NONE	ANALOGIN	
32	SLOT 26	CARD TYPE	NONE	ANALOGIN	
33	SLOT 27	CARD TYPE	NONE	ANALOGIN	
34	SLOT 28	CARD TYPE	NONE	ANALOGIN	
35	SLOT 29	CARD TYPE	NONE	ANALOGIN	
36	SLOT 30	CARD TYPE	NONE	ANALOGIN	
37	SLOT 31	CARD TYPE	NONE	ANALOGIN	
38	SLOT 32	CARD TYPE	NONE	ANALOGIN	
39	CHANGE DETECTION (CHNGFLAG)	NOTCONFIG	DETECT	SET	(Default = NOTCONFIG)
40	EVENT PROCESSING (EVENTPRC)	DISABLE	ENABLE		(Default = DISABLE)

LLPIU BOX DATA POINT CONFIGURATION FORM

HG LLPIU BOX POINT DISPLAY				
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)	
2	BOX NUMBER (BOXNUM)	_ _	(Default = 5)	
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRC D MCRCD HG	HLPIU EC DHP GPCI LLPIU ECRCD OPSTA NOTCONF (Enter LLPIU)
4	BOX ASSIGNMENT (BOXASSN)	THISHG	REMOTEHG	ADDEDHG H4500 (Default = THISHG)
5	LOAD DESTINATION (LOADDEST)	HG	HG HIWAY	(Default = HG)
6	PIU BOX SIZE (BOXSIZE)	REGULAR	EXTENDED	
7	SLOT 1 CARD TYPE (PIUCRDY)	NONE	ANALOGIN (Default = NONE for all Card Types)	
8	SLOT 2 CARD TYPE	NONE	ANALOGIN	
9	SLOT 3 CARD TYPE	NONE	ANALOGIN	
10	SLOT 4 CARD TYPE	NONE	ANALOGIN	
11	SLOT 5 CARD TYPE	NONE	ANALOGIN	
12	SLOT 6 CARD TYPE	NONE	ANALOGIN	
13	SLOT 7 CARD TYPE	NONE	ANALOGIN	
14	SLOT 8 CARD TYPE	NONE	ANALOGIN	
15	SLOT 9 CARD TYPE	NONE	ANALOGIN	
16	SLOT 10 CARD TYPE	NONE	ANALOGIN	
17	SLOT 11 CARD TYPE	NONE	ANALOGIN	
18	SLOT 12 CARD TYPE	NONE	ANALOGIN	
19	SLOT 13 CARD TYPE	NONE	ANALOGIN	
20	SLOT 14 CARD TYPE	NONE	ANALOGIN	
21	SLOT 15 CARD TYPE	NONE	ANALOGIN	
22	SLOT 16 CARD TYPE	NONE	ANALOGIN	

LLPIU BOX DATA POINT CONFIGURATION FORM

HG LLPIU BOX POINT DISPLAY					
23	SLOT 17 CARD TYPE	NONE	ANALOGIN	(Default = NONE for all Card Types)	
24	SLOT 18 CARD TYPE	NONE	ANALOGIN		
25	SLOT 19 CARD TYPE	NONE	ANALOGIN		
26	SLOT 20 CARD TYPE	NONE	ANALOGIN		
27	SLOT 21 CARD TYPE	NONE	ANALOGIN		
28	SLOT 22 CARD TYPE	NONE	ANALOGIN		
29	SLOT 23 CARD TYPE	NONE	ANALOGIN		
30	SLOT 24 CARD TYPE	NONE	ANALOGIN		
31	SLOT 25 CARD TYPE	NONE	ANALOGIN		
32	SLOT 26 CARD TYPE	NONE	ANALOGIN		
33	SLOT 27 CARD TYPE	NONE	ANALOGIN		
34	SLOT 28 CARD TYPE	NONE	ANALOGIN		
35	SLOT 29 CARD TYPE	NONE	ANALOGIN		
36	SLOT 30 CARD TYPE	NONE	ANALOGIN		
37	SLOT 31 CARD TYPE	NONE	ANALOGIN		
38	SLOT 32 CARD TYPE	NONE	ANALOGIN		
39	CHANGE DETECTION (CHNGFLAG)	NOTCONFIG	DETECT	SET	(Default = NOTCONFIG)
40	EVENT PROCESSING (EVENTPRC)	DISABLE	ENABLE		(Default = DISABLE)
41	VARIABLE DEADBAND (BOXDVB)	OFF	ON		(Default = OFF)

MC BOX DATA POINT CONFIGURATION FORM

HG MC BOX POINT DISPLAY					
1	HIWAY NUMBER (HWYNUM)	__	(Default = 1)		
2	BOX NUMBER (BOXNUM)	__	(Default = 0)		
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRC MCRCD HG	HLPIU EC DHP GPCI	LLPIU ECRCD OPSTA NOTCONFG (Enter MC) H4500
4	BOX ASSIGNMENT ** (BOXASSN)	THISHG	REMOTEHG	ADDEDHG	
5	LOAD DESTINATION ** (LOADDEST)	HG	HG HIWAY	(Default = HG)	
6	MC REVISION CODE (MCREV)	REV20	REV30	REV31	(Default = REV30)
7	BOX TRENDING (BOXTREND)	NOTREND	TREND	(Default = NOTREND)	
8	ADDITIONAL SOPL MEMORY (SOPLMEM)	NOSOPL	SOPL	(Default = NOSOPL)	
9	C-LINK NUMBER (BOXCLINK)	__	(Default = 1)		
10	ADDRESS NUMBER ON C-LINK (CLINKNUM)	__	(Default = 1)		
11	LIBRARY (LIBRYNUM)	__	(Default = 1)		
12	NUMBER OF I/O FILES (NMBRBCFL)	__	(Default = 0)		
12A	SLOT 1 CARD TYPE (PIUCRDTY)	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
12A1	SLOT 1 CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12A2	SLOT 1 CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
12B	SLOT 2 CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
12B1	SLOT 2 CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12B2	SLOT 2 CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
12C	SLOT 3 CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
12C1	SLOT 3 CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12C2	SLOT 3 CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
12D	SLOT 4 CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
12D1	SLOT 4 CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12D2	SLOT 4 CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	

MC BOX DATA POINT CONFIGURATION FORM

HG MC BOX POINT DISPLAY							
12E	SLOT 5	CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)	ANALOGOT	COUNTER
12E1	SLOT 5	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12E2	SLOT 5	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12F	SLOT 6	CARD TYPE	NONE	DIGIN	DIGOUT (Default = NONE)	ANALOGOT	COUNTER
12F1	SLOT 6	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12F2	SLOT 6	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12G	SLOT 7	CARD TYPE	NONE	DIGIN	DIGOUT		
			ANALOGIN	ANALOGOT	COUNTER (Default = NONE)		
12G1	SLOT 7	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12G2	SLOT 7	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12H	SLOT 8	CARD TYPE	NONE	DIGIN	DIGOUT		
			ANALOGIN	ANALOGOT	COUNTER (Default = NONE)		
12H1	SLOT 8	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12H2	SLOT 8	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12J	SLOT 9	CARD TYPE	NONE (Default = NONE)	DIGIN	DIGOUT	ANALOGOT	COUNTER
12J1	SLOT 9	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12J2	SLOT 9	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12K	SLOT 10	CARD TYPE	NONE (Default = NONE)	DIGIN	DIGOUT	ANALOGOT	COUNTER
12K1	SLOT 10	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12K2	SLOT 10	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12L	SLOT 11	CARD TYPE	NONE (Default = NONE)	DIGIN	DIGOUT	ANALOGOT	COUNTER
12L1	SLOT 11	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12L2	SLOT 11	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		
12M	SLOT 12	CARD TYPE	NONE (Default = NONE)	DIGIN	DIGOUT	ANALOGOT	COUNTER
12M1	SLOT 12	CARD OPTION	STATUS	LATCHIN	(Default = neither)		
12M2	SLOT 12	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)		

MC BOX DATA POINT CONFIGURATION FORM

HG MC BOX POINT DISPLAY (CONTINUED)						
12N	SLOT 13	CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
			(Default = NONE)			
12N1	SLOT 13	CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12N2	SLOT 13	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
12P	SLOT 14	CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
			(Default = NONE)			
12P1	SLOT 14	CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12P2	SLOT 14	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
12Q	SLOT 15	CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
			(Default = NONE)			
12Q1	SLOT 15	CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12Q2	SLOT 15	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
12R	SLOT 16	CARD TYPE	NONE	DIGIN	DIGOUT	ANALOGOT COUNTER
			(Default = NONE)			
12R1	SLOT 16	CARD OPTION	STATUS	LATCHIN	(Default = neither)	
12R2	SLOT 16	CARD OPTION	PULSEOUT	LATCHOUT	(Default = neither)	
13	CHANGE DETECTION		NOTCONFIG	DETECT	SET (Default = NOTCONFIG)	
			(CHNGFLAG)			
14	EVENT PROCESSING		DISABLE	ENABLE	(Default = DISABLE)	
			(EVENTPRC)			
15	TOG INTERVAL 1		_ _ _ _		(Default = 0 seconds)	
***	(BOXTOG1)					
16	TOG INTERVAL 2		_ _ _ _		(Default = 0 seconds)	
***	(BOXTOG2)					
16A	SLOT 1	TOG INTERVAL (TOGINTSL)	INTERV1	INTERV2	(Default = INTERV1)	
16B	SLOT 2	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	
16C	SLOT 3	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	
16D	SLOT 4	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	
16E	SLOT 5	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	
16F	SLOT 6	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	
16H	SLOT 7	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	
16I	SLOT 8	TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)	

MC BOX DATA POINT CONFIGURATION FORM

HG MC BOX POINT DISPLAY (CONTINUED)			
16J SLOT 9 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16K SLOT 10 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16L SLOT 11 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16M SLOT 12 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16N SLOT 13 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16O SLOT 14 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16P SLOT 15 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
16Q SLOT 16 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17A IO SLOT 1 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17B IO SLOT 2 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17C IO SLOT 3 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17D IO SLOT 4 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17E IO SLOT 5 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17F IO SLOT 6 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17G IO SLOT 7 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)
17H IO SLOT 8 TOG INTERVAL	INTERV1	INTERV2	(Default = INTERV1)

AU, GPCI, H4500 & RCD BOX DATA POINT CONFIGURATION FORM

HG BOX DATA POINT DISPLAY					
1	HIWAY NUMBER (HWYNUM)	_ _	(Default = 1)		
2	BOX NUMBER (BOXNUM)	_ _	(Default = 0)		
3	BOX TYPE (BOXTYPE)	CB LEPIU MC H4500	AU CBRCD MCRCD HG	HLPIU EC DHP GPCI	LLPIU ECRCD OPSTA NOTCONFIG
3A	BOX ASSIGNMENT (BOXASSN)	THISHG	REMOETHG	ADDEDHG	4500

Honeywell

Process Solutions

2500 West Union Hills Drive
Phoenix, AZ 85027