

Logic Manager Forms

LM88-600

Implementation/
Logic Manager

Logic Manager Forms

LM88-600
Release 670
06/06

NOTE

This document was last updated for R670.
For information about those parameters introduced post R670,
refer to the Logic Manager Parameter Reference Dictionary.

Notices and Trademarks

Copyright 2001 - 2006 by Honeywell International Inc.
Release June 2006

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customers.

In no event is Honeywell liable to anyone for any indirect, special or consequential damages. The information and specifications in this document are subject to change without notice.

Honeywell and **TotalPlant** are registered trademarks of Honeywell International Inc.

Other brand or product names are trademarks of their respective owners.

These forms support **TotalPlant** Solution (TPS) System network release up to and including R660. TPS is the evolution of TDC 3000^x.

Honeywell International
Process Solutions
2500 West Union Hills Drive
Phoenix, AZ 85027
1-800 343-0228

About This Publication

This publication supports **TotalPlant** Solution (TPS) System network Release 670. TPS is the evolution of TDC 3000^X.

This manual consists of configuration forms. These forms are designed to facilitate the collection and organization of data for subsequent entry into the TPS system through the Universal Station and Global User Station.

Table of Contents

LOGIC MANAGER FORMS

<u>Form Name</u>	<u>Form ID</u>
LM UCN Node Configuration	LM88-601A
LM Node Specific Configuration	LM88-601B
LM Analog Input Data Point	LM88-602
LM Analog Output Data Point	LM88-603
LM Digital Composite Data Point	LM88-607
LM Digital Input Data Point	LM88-608
LM Digital Output Data Point	LM88-609
LM Logic Data Point	LM88-614
LM Flag Point	LM88-628
LM Timer Point	LM88-629
LM Numeric Point	LM88-630

LM UCN Node Configuration

LM88-601A

Page 1 of 2

12/01

LM UCN Node Configuration	Engineer:	Date:
---------------------------	-----------	-------

UCN Node Configuration Display

NOTE

This form is intended primarily for use in configuring each LM on your system by selecting **LM** for **NODETYP** below. This same form can be used to configure each NIM on your system by selecting **NIM** for **NODETYP** (some different targets will appear as shown). If your system has other UCN devices, the NIMs can also be configured using the forms contained in the documentation for those devices.

NTWKNUM NIM's UCN That LM Is Connected To (Process Network Number)		range = 1 to 20 default = Not applicable
NODENUM LMM's or NIM's Address On The UCN		range = 1 to 64 default = Not applicable
NODETYP Type Of Node On The UCN	NotConfg Nim PM APM HPM LM SM	This NIM or LM not configured on UCN Network Interface Process Manager Advanced Process Manager High Performance Process Manager Logic Manager Safety Manager
NODEASSN Node Assignment	ThisNim RemotNim	NIM assigned to report alarms and perform checkpointing for network specified in NTWKNUM Additional NIM on a network that already has "ThisNIM" defined

Applicable only if NODETYP = Nim

LOADSCOP Load Scope	NimOnly NimAndPm	Configured data goes to the NIM only Configured data goes to NIM and LM
NMSGTXT Number of Message Text Items		range = 0 to 15 default = 0
TIMESYNC SOE Time Synchronization	Disable Enable	Applicable only if the UCN has at least one APM or HPM

DIGITAL COMPOSITE PV STATE TEXT

MOVPTXT Moving Text	Moving	Individual point configuration specifies which input state is associated with this moving text. If NODENUM is even, this parameter is hidden.
BADPV TXT Bad Text	Bad	Individual point configuration specifies which input state is associated with the bad text. If NODENUM is even, this parameter is hidden.

LM UCN Node Configuration

LM UCN Node Configuration	Engineer:	Date:
---------------------------	-----------	-------

Status Message Text Configuration Display

N/A if NMSGTXT = 0

MSGTXT (1) Status Message Text #1	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (2) Status Message Text #2	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (3) Status Message Text #3	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (4) Status Message Text #4	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (5) Status Message Text #5	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (6) Status Message Text #6	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (7) Status Message Text #7	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (8) Status Message Text #8	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (9) Status Message Text #9	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (10) Status Message Text #10	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (11) Status Message Text #11	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (12) Status Message Text #12	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (13) Status Message Text #13	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (14) Status Message Text #14	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank
MSGTXT (15) Status Message Text #15	_ _ _ _ _ _ _	<i>range =</i> Eight Character String <i>default =</i> Blank

LM Node Specific Configuration

LM88-601B

Page 1 of 2

12/01

LM Configuration	Engineer:	Date:
------------------	-----------	-------

WARNING: If the point mix or the scan rate is changed, then the node's full database will be set to its default.

LM Node Configuration Display

NTWKNUM NIM's UCN That LMM Is Connected To	_ _	range = 1 to 20 default = Not applicable
NODENUM LMM's Address On The UCN	_ _	range = 1 to 64 default = Not applicable
NODETYPE Type Of Node On The UCN	PM APM HPM LM SM	Process Manager Advanced Process Manager High Performance Process Manager Logic Manager Safety Manager
NAISLOT # Of Analog Input Slots	_ _ _	range = 0 to 127 for .5 second scanrate 0 to 254 for 1 second scanrate default = 0
NAOSLOT # Of Analog Output Slots	_ _ _	range = 0 to 482 for .5 second scanrate 0 to 965 for 1 second scanrate default = 0
NDISLOT # Of Digital Input Slots	_ _ _	range = 0 to 1866 default = 0
NDOSLOT # Of Digital Output Slots	_ _ _	range = 0 to 4000 default = 0
NLOGSLOT # Of Logic Slots	_ _ _	range = 0 to 14 default = 0
NDCSLOT # Of Digital Composite Slots	_ _ _	range = 0 to 350 default = 0
NONETXT Digital Composite None State	_ _ _ _ _ _ _	range = Not applicable default = None
NNUMERIC # Of Numerics	_ _ _ _	range = 0 to 1024 default = 0

N/A if NNUMERIC = 0.

NNLSBA LM Start Addr of NUM Array	_ _ _ _	range = -1, 4096 to 8191 default = -1
PVFLTOPT LM Data Conversion Option	Unsigned	Signed Floating
NFLAG # Of Flags	_ _ _ _	range = 0 to 1024 default = 0

LM Node Specific Configuration

N/A if NFLAG = 0.

FLLSBA		_ . _ . _ . _	<i>range</i> = -1 to 4095	
LM Start Addr of Flag Array			<i>default</i> = -1	
NTIMER		_ . _ . _ . _	<i>range</i> = 0 to 700	
# Of Timers			<i>default</i> = 0	
SCANRATE			<u>Analog Scan Rate</u>	<u>Dig & Timer Scan</u>
<u>Rate</u>				
LMM's Scan Rate In Times Per Second		AR1DT2	1/sec.	2/sec.
		AR2DT2	<i>default</i> = 2/sec.	<i>default</i> = 2/sec.

LM Analog Input Data Point

LM88-602

Page 1 of 4

06/06

LM Analog Input Data Point	Engineer:	Date:
----------------------------	-----------	-------

Point Assignment Display

NAME Tag Name		<i>range =</i> Not applicable <i>default =</i> Blank
NODETYPE Type Of Node On The UCN	PM APM HPM LM SM	<i>range =</i> Not applicable <i>default =</i> PM
PNTFORM Point Form	Full Componnt	Point is fully displayed and alarmed Pt. is partially displayed but not alarmed
PTDESC Point Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
EUDESC Engineering Units Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
KEYWORD Point Keyword Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
ASSOCDSP Associated Display		<i>range =</i> Not applicable <i>default =</i> Blank
\$CDETAIL (R620 and later) Point Custom Display		<i>range =</i> Not applicable <i>default =</i> Blank
UNIT Process Unit Point Is Assigned To		<i>range =</i> Alphanumeric <i>default =</i> Not applicable
NTWKNUM NIM's UCN That Contains This Point		<i>range =</i> 1 to 20 <i>default =</i> Not applicable
NODENUM LMM's Address On The UCN		<i>range =</i> 1 to 64 <i>default =</i> Not applicable
SLOTNUM Slot Number		<i>range =</i> 1 to 127 for .5 second scanrate 1 to 254 for 1 second scanrate <i>default =</i> Not applicable
PRIMMOD Primary Module ID		<i>range =</i> Not applicable <i>default =</i> Null
PLCADDR LC Source Address		<i>range =</i> -1 to 8191 <i>default =</i> -1

PVTEMP		DegreesF	DegreesC	F = Fahrenheit; C =
Celsius;				
Thermal EUS For PV	DegreesR	DegreesK	R = Rankin; K = Kelvin	

INPTDIR Analog Input Direction	Direct Reverse		Highest energy from sensor = 100% PV Highest energy from sensor = 0% PV	
PVEUHI PV High Range In EUs			<i>range</i> =	PVEULO to PVEXEUHI
			<i>default</i> =	100.0
PVEULO PV Low Range In EUs			<i>range</i> =	PVEXEULO to PVEUHI
			<i>default</i> =	0.0
PVFLTPT LC Data Conversion Option	Unsigned		Signed	Floating
PVFORMAT PV Decimal Point Format	D0 D1	D2 D3	D0 = 9999. D1 = 999.9	D2 = 99.99 D3 = 9.999
PVCLAMP PV Clamping Option	NoClamp Clamp		No clamping of the PV value Clamp PV value at range extension limit	

LOCUTOFF	[.]	<i>range</i> =	PVEULO - PVEUHI and NaN
Low Signal CO For Flow Inputs		<i>default</i> =	NaN

PVSRCOPT PV Source Option	OnlyAuto All	PV source selection is not available and field wiring or memory fetch supplies PV. Selection from PVSOURCE is available & Operator/CL-program may supply PV.
PVSOURCE PV Source	Auto Man Sub	Applies when PVSRCOPT = All. Field wiring or memory fetch supplies PV. PV is supplied by Operator or program. A value is substituted by a CL program.

LM Analog Input Data Point

LM88-602
Page 3 of 4
06/06

NIM/PV Configuration Display(continued)

TF PV Filter Lag Time In Minutes		range = 0.0 to 60.0 (minutes) default = 0.0 (PV will not be delayed)
N/A if PNTFORM = Componnt.		
PVTV PV Target Value In EUs		range = PVEULO-PVEUHI, &NaN default = NaN
OVERVAL Overview Display Value		range = 0 to 100 default = 25

Alarming Display

N/A if PNTFORM = Componnt.

The following two example parameters represent the typical format of alarm trip points and priorities. Please refer to these as you are entering trip points and alarm priorities that follow this information.

Note: If you do not enter a trip point value for a given pair of trip points and alarm priorities, do not circle an alarm priority option for that pair (i.e., no trip point, no alarm priority).

PVLOTP PV Low Alarm Trip Point		range = PVLLTP-PVHITP, & NaN default = NaN
BADPVPR Bad PV Alarm Priority	NoAction Journal Low High Emergency Printer JnlPrint	Alarm is not reported to the system and not annunciated (R670) Alarm is historized, not reported to US, not annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Printer not historized, reported to the printer, not annunciated Alarm is historized, not reported to US, not annunciated

N/A if PNTFORM = Componnt.

\$AUXUNIT Auxiliary Unit		range = Any Configured LCN Unit ID default = NaN
\$ALDLOPT Alarm Delay Option (R620 and later)	None OffDlyLo Off Delay Lo OffDlyHi Off Delay Hi OffDlyEm Off Delay Emergency OnDlyLo On Delay Lo OnDlyHi On Delay Hi OnDlyEm On Delay Emergency	
DLYTIME Delay Time (R620 and later)		range = 0 to 9999 seconds default = 0 seconds
\$REALARM Re-alarms Interval (R660 and later)		range = 0 to 9999 minutes default = 0 minutes
PVALDB PV Alarm Deadband In %	Half (of 1%) Four	One Two Three Five EU

N/A if PNTFORM = Componnt, Only if PVALDB = EU.

PVALDBEU PV Alarm Deadband in EU		range = ≥0 default = 1.0
N/A if PNTFORM = Componnt.		
PVHITP PV High Alarm Trip Point		range = PVLOTP - PVHITP, & NaN default = NaN
PVHIPR PV High Alarm Priority	NoAction (R670) Journal Low High Emergency	

LM Analog Input Data Point

Alarming Display

		N/A if PNTFORM = Componnt			
PVLOTP	_ _ _ _ _ _ _	<i>range =</i>	PVLLTP - PVHITP, & NaN		
PV Low Alarm Trip Point		<i>default =</i>	NaN		
PVLOPR	NoAction (R670)	Journal	Low	High	Emergency
PV Low Alarm Priority					
BADPVPR	NoAction (R670)	Journal	Low	High	Emergency
Bad-PV Alarm Priority					

NIM/PV Configuration Display(continued)

		N/A if PNTFORM = Componnt.		
ALENBST		<u>Displayed</u>	<u>Logged</u>	<u>ReportedTo EIP</u>
Point Alarm Enable Status	Enable	Yes	Yes	Yes
	Disable	No	Yes	Yes
	Inhibit	No	No	No
CCSRC	_ _ _	<i>range =</i>	-1 to 8191	
Contact Cutout Source		<i>default =</i>	-1	

LM Analog Output Data Point

LM88-603
Page 1 of 2
12/01

LM AnalgOut Data Point	Engineer:	Date:
------------------------	-----------	-------

Point Assignment Display

NAME		<i>range =</i> Not applicable
Tag Name	_____	<i>default =</i> Blank
NODETYP	PM	<i>range =</i> Not applicable
Node Type	APM	<i>default =</i> PM
	HPM	
	LM	
	SM	
PNTFORM	Full	Point is fully displayed and alarmed
Point Form	Componnt	Point is partially displayed but not alarmed
PTDESC		<i>range =</i> Not applicable
Point Descriptor		<i>default =</i> Blank

EUDESC	_____	<i>range =</i> Not applicable
Engineering Units Descriptor		<i>default =</i> Blank
KEYWORD	_____	<i>range =</i> Not applicable
Keyword Descriptor		<i>default =</i> Blank
ASSOCDSP	_____	<i>range =</i> Not applicable
Associated Display		<i>default =</i> Blank
\$CDETAIL (R620 and later)	_____	<i>range =</i> Not applicable
Point Custom Display		<i>default =</i> Blank
UNIT	____	<i>range =</i> Alphanumeric
Process Unit Point Is Assigned To		<i>default =</i> Not applicable
NTWKNUM	____	<i>range =</i> 1 to 20
NIM's UCN That Contains This Point		<i>default =</i> Not applicable
NODENUM	____	<i>range =</i> 1 to 64
LMM's Address On The UCN		<i>default =</i> Not applicable
SLOTNUM	____	<i>range =</i> 1 to 482 .5 second scanrate
Slot Number		1 to 965 1 second scanrate
		<i>default =</i> Not applicable
PRIMMOD	_____	<i>range =</i> Not applicable
Primary Module ID		<i>default =</i> Null
PLCADDR		<i>range =</i> -1 to 2047, 4097 to 8191
LC Source Address	_____	<i>default =</i> -1

LM Analog Output Data Point

LM88-603

Page 2 of 2

12/01

Operating Configuration Display

OPTDIR (AnalgOut) AO Direct/Reverse Action	Direct Reverse	For final OP: 0% =>4ma; 100% =>20ma For final OP: 0% =>20ma; 100% =>4ma
PVFLTOPT LM Data Conversion Option	Unsigned	Signed Floating
\$OPTOL Output tolerance in %	_.	range = 0.0 to 106.9 default = 0.0
OUTIND (R620 and later)	Direct Reverse	4-20mA = 0 – 100% 20-4mA = 0 – 100%

Mode Configuration Display

RCASOPT Remote Cascade Option	None Ddc	N/A if PNTFORM = Componnt. <u>No</u> cascade mode of <u>any type</u> is allowed In Cas, AM point controls this point's OP
NMODE AnalOut Point's Normal Mode	None Man Cas	None, Man applies when RCASOPT = None. None, Man, Cas applies when RCASOPT Ddc. No configured "normal" operating mode Manual is the configured "normal" mode If RCASOPT equals Ddc, Cascade may be configured as the "normal" mode.

N/A if NMODE = None, or if PNTFORM = Componnt.

NMODATTR Normal Mode Attribute	None Operator Program	Parameter NMODE sets "normal" mode Operator sets "normal" operating mode Program sets "normal" operating mode
MODEPERM Mode Permissive	Permit NotPerm	Operator can change this point's mode Optr. cannot change this point's mode
\$MODESEL (R630 and later) Mode Selection List	Man Cas Prog	Man and Cas mode, and Prog mode attribute are allowed for this data point.

LM88-607
Page 1 of 6
06/06

NAME		range =	Not applicable
Tag Name		default =	Blank
NODETYPE	PM	range =	Not applicable
Node Type	APM	default =	PM
	HPM		
	LM		
	SM		
PNTFORM	Full	Point is fully displayed and alarmed	
Point Form	Componnt	Pt. is partially displayed but not alarmed	
PTDESC		range =	Not applicable
Point Descriptor		default =	Blank
EUDESC		range =	Not applicable
Engineering Units Descriptor		default =	Blank
KEYWORD		range =	Not applicable
Keyword Descriptor		default =	Blank
ASSOCDSP		range =	Not applicable
Associated Display		default =	Blank
\$CDETAIL (R620 and later)		range =	Not applicable
Point Custom Display		default =	Blank
UNIT		range =	Alphanumeric
Process Unit Point Is Assigned To		default =	Not applicable
NTWKNUM		range =	1 to 20
NIM's UCN That Contains This Point		default =	Not applicable
NODENUM		range =	1 to 64
LMM's Address On The UCN		default =	Not applicable
SLOTNUM		1 to 350 (but $\leq$ the value in NDCSLOT)	
Slot Number		default =	Not applicable
PRIMMOD		range =	Not applicable
Primary Module ID		default =	Null
NOSTATES	2	2 digital switch states can be configured	
Number Of Digital States	3	3 digital switch states can be configured	
NODINPTS	0	0 digin connections can be configured	
# Of Digital Input Connections	1	1 digin connections can be configured	
	2	2 digin connections can be configured	
NODOPTS	0	0 digout connections can be configured	
# Of Digital Output Connections	1	1 digout connections can be configured	
	2	2 digout connections can be configured	
	3	3 digout connections can be configured	

N/A if PNTFORM = Component.

STATETXT (1)		<i>range</i> = Not applicable			
State 1 Descriptor	(1) _._._._._._._._	<i>default</i> = On			
	(0) _._._._._._._._	(1) = First active state			
	(2) _._._._._._._._	(0) = Inactive state			
		(2) = Second active state			
STATETXT (0)		<i>range</i> = Not applicable			
State 0 Descriptor	(1) _._._._._._._._	<i>default</i> = Off			
	(0) _._._._._._._._	(1) = First active state			
	(2) _._._._._._._._	(0) = Inactive state			
		(2) = Second active state			
STATETXT (2)		<i>range</i> = Not applicable			
State 2 Descriptor	(1) _._._._._._._._	<i>default</i> = "State2"			
	(0) _._._._._._._._	(1) = First active state			
	(2) _._._._._._._._	(0) = Inactive state			
		(2) = Second active state			
BOXCLR(1)		Red	Green (Middle box default)	White	Black
State 1 Box Color		Cyan	Yellow	Blue	Magenta
BOXCLR(0)		Red	Green	White	Black
State 0 Box Color		Cyan	Yellow (Middle box default)	Blue	Magenta
BOXCLR(2)		Red (Lower box default)	Green	White	Black
State 2 Box Color		Cyan	Yellow	Blue	Magenta

N/A if NODOPTS = 0.

MOMSTATE	<i>None</i>	No momentary output states
Momentary Output States	Mom_0	State 0 is valid if (NOSTATES = 2)
	Mom_1	State 1 is valid if (NOSTATES = 2 or 3)
	Mom_2	State 2 is valid if (NOSTATES = 3)
	Mom_1 2	State 1 or 2 is valid if (NOSTATES = 3)

N/A if PNTFORM = Componnt.

LOGICSRC		
(Logical Input Connection Source)		
		
DISRC (Digital Input Connection Source)		
Input #	DISRC(point.parameter)	Destination
1		D1
2		D2

LM Digital Composite Data Point

LM88-607
Page 3 of 6
06/06

PV / Input Configuration Display

Applies if NODINPTS = to 1.

D1_1 D1_One PV State	PVState1 Use & display contents of STATETXT1 PVState0 Use & display contents of STATETXT0
--------------------------------	--

N/A if NODINPTS = 1.

D2D1_00 D2_D1 Zero_Zero PV State	PVState1 Use & display contents of STATETXT1 PVState0 Use & display contents of STATETXT0 PVState2 Use & display contents of STATETXT2 BadPV Use & display contents of BADPVTXT MovPV Use & display contents of MOVPVTXT
D2D1_01 D2D1 Zero_One PV State	PVState1 Use & display contents of STATETXT1 PVState0 Use & display contents of STATETXT0 PVState2 Use & display contents of STATETXT2 MovPV Use & display contents of MOVPVTXT BadPV Use & display contents of BADPVTXT
D2D1_10 D2D1 One_Zero PV State	PVState1 Use & display contents of STATETXT1 PVState0 Use & display contents of STATETXT0 PVState2 Use & display contents of STATETXT2 BadPV Use & display contents of BADPVTXT MovPV Use & display contents of MOVPVTXT
D2D1_11 D2D1 One_One PV State	PVState1 Use & display contents of STATETXT1 PVState0 Use & display contents of STATETXT0 PVState2 Use & display contents of STATETXT2 MovPV Use & display contents of MOVPVTXT BadPV Use & display contents of BADPVTXT

N/A if PNTFORM = Componnt, or if NODINPTS = 0.

PVSRCOPT PV Source Option	OnlyAuto PV source selection is not available and field wiring or memory fetch supplies PV. All Selection from PVSOURCE is available & Operator/CL-program may supply PV.
PVSOURCE PV Source	Auto Applies when PVSRCOPT = All. Man Field wiring or memory fetch supplies PV. Sub PV is supplied by Operator or program. Track A value is substituted by a CL program PV tracks the output.

Output State Configuration Display

N/A if NODOPTS = 0.

NONECONF None State Configuration	On Off
---	-------------------------

LM Digital Composite Data Point

LM88-607

Page 4 of 6

06/06

Output State Configuration Display (continued)

N/A if NODOPTS = 0

STATE1	OUTPUT 1	OUTPUT 2	OUTPUT 3
ST1_OP1 (NODOPTS = 1) State 1 - Output 1	Off On	Not applicable	Not applicable
ST1_OP2 (NODOPTS = 2) State 1 - Output 2	Off On	Off On	Not applicable
ST1_OP3 (NODOPTS = 3) State 1 - Output 3	Off On	Off On	Off On
STATE0			
ST0_OP1 (NODOPTS = 1) State 0 - Output 1	Off On	Not applicable	Not applicable
ST0_OP2 (NODOPTS = 2) State 0 - Output 2	Off On	Off On	Not applicable
ST0_OP3 (NODOPTS = 3) State 0 - Output 3	Off On	Off On	Off On
STATE 2			
ST2_OP1 (NODOPTS = 1) State 2 - Output 1 On	Off	Not applicable	Not applicable
ST2_OP2 (NODOPTS = 2) State 2 - Output 2 On	Off On	Off	Not applicable
ST2_OP3 (NODOPTS = 3) State 2 - Output 3 On	Off On	Off On	Off

N/A if NODOPTS = 0.

DODSTN (Digital Output Connection Destination)			
Output #	DODSTN(point.parameter)		NODOPTS
1			1
2			2
3			3
		PISRC (N) Permissive Interlock Source in the LC	OISRC (N) Override Interlock Source Addresses in the LC
STATE1		P1 . . .	I1 . . .
STATE0		P0 . . .	I0 . . .
STATE2	(N/A if NOSTATES = 2)	P2 . . .	I2 . . .

LM Digital Composite Data Point

LM88-607

Page 5 of 6

06/06

Output State Configuration Display (continued)

N/A if NODOPTS = 0.

LMSRC	_ . _ . _ . _	<i>range</i> = -1 - 8191
Local Manual Source in the LC		<i>default</i> = -1

Mode Configuration Display

N/A if NODOPTS = 0.

NMODATTR	None	Parameter NMODE sets "normal" mode
Normal Mode Attribute	Operator	Operator sets "normal" operating mode
	Program	Program sets "normal" operating mode
MODEPERM	Permit	Operator can change this point's mode
Mode Permissive	NotPerm	Oprr. cannot change this point's mode
\$MODESEL (R630 and later)	Man Prog	Man mode and Prog mode attribute are allowed for this data point.
Mode Selection List		
OROPT	Off	
Interlock Bypass Option	On	
BYPASS	Off	Applies when OROPT = On.
Interlock Bypass State	On	

Alarming Display

N/A if PNTFORM = Componnt, or if NODINPTS = 0.

\$AUXUNIT		<i>range</i> = Any Configured LCN Unit ID
Auxiliary Unit	_ . _	<i>default</i> = NaN
\$REALARM (R660 and later)		<i>range</i> = 0 to 9999 minutes
Re-alarming Interval	_ . _ . _ . _	<i>default</i> = 0 minutes
ALMOPT	None	No affect
Alarming Option	Cmddis	Alarm if field device did not respond within configured feedback time duration
	Offnorml	Alarm if PV and PVNORMAL differs.
FBTIME		Applies when ALMOPT = Cmddis.
Feedback Time In Seconds	_ . _ . _ . _	<i>range</i> = 1 to 1000
		<i>default</i> = 1000
PVNORMAL		Applies when ALMOPT = Offnorml.
PV Value's Normal State Text	Off	<i>range</i> = STATETXT(0) - STATETX(2)
ALENBST		Applies when ALMOPT = Offnorml, Cmddis.
Point Alarm Enable Status		
		<u>Displayed</u> <u>Logged</u> <u>Reported To EIP</u>
	Enable	Yes Yes Yes
	Disable	No Yes Yes
	Inhibit	No No No

LM Digital Composite Data Point

LM88-607
Page 6 of 6
06/06

Alarming Display (continued)

N/A if PNTFORM = Componnt, or if NODINPTS = 0.

BADPVPR Bad-PV Alarm Priority	NoAction (R670)	Journal	Low	High	Emergency	Printer	JnlPrint
BADCTLPR Bad-Control Alarm Priority	NoAction (R670)	Journal	Low	High	Emergency	Printer	JnlPrint
OFFNRMPR Off Normal Alarm Priority	NoAction Journal Low High Emergency Printer JnlPrint	Alarm is not reported to the system and not annunciated (R670) Alarm is historized, not reported to US, not annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Printer not historized, reported to the printer, not annunciated Alarm is historized, not reported to US, not annunciated					
EVTOPT Cmddiis Event Report Option	Applies when ALMOPT = None, Offnormal,						
		None	Neither Eip or Soe is allowed				
		Eip	Process special is triggered in AM/CG				
EIPPCODE Event Init. Proc. Destination	Applies when EVTOPT = Eip.						
	_ _ _ _ _ _ _	<i>range</i> =		Not applicable			
		<i>default</i> =		Null			

N/A if PNT FORM = Componnt, or if NODINPTS = 0.

CCSRC Contact Cutout Source	_____	<i>range</i> =	-1 to 8191
		<i>default</i> =	-1

LM Digital Input Data Point

LM88-608

Page 1 of 3

06/06

LM DigIn Data Point	Engineer:	Date:
---------------------	-----------	-------

Point Assignment Display

NAME Tag Name		<i>range =</i> Not applicable <i>default =</i> Blank
NODETYP Node Type	PM APM HPM LM SM	<i>range =</i> Not applicable <i>default =</i> PM
PNTFORM Point Form	Full Componnt	Point is fully displayed and alarmed Pt. is partially displayed but not alarmed
PTDESC Point Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
EUDESC Engineering Units Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
KEYWORD Keyword Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
ASSOCDSP Associated Display		<i>range =</i> Not applicable <i>default =</i> Blank
\$CDETAIL (R620 and later) Point Custom Display		<i>range =</i> Not applicable <i>default =</i> Blank
UNIT Process Unit Point Is Assigned To		<i>range =</i> Alphanumeric <i>default =</i> Not applicable
NTWKNUM NIM's UCN That This Point Is In		<i>range =</i> 1 to 20 <i>default =</i> Not applicable
NODENUM LMM's Address On The UCN		<i>range =</i> 1 to 64 <i>default =</i> Not applicable
SLOTNUM Slot Number		<i>range =</i> 1 to 1866 <i>default =</i> Not applicable
PRIMMOD Primary Module ID		<i>range =</i> Not applicable <i>default =</i> Null
DITYPE Digital Input Type	Status	Status input (open/closed contacts)
PLCADDR LC Source Address		<i>range =</i> -1 to 8191 <i>default =</i> -1

LM Digital Input Data Point

LM88-608

Page 2 of 3

06/06

Operating Configuration Display

N/A if PNTFORM = Component.

STATETXT (1)	1) _._._._._._.__	<i>range =</i>	Not applicable
State1 Description Text		<i>default =</i>	"On"
STATETXT (0)	0) _._._._._._.__	<i>range =</i>	Not applicable
State0 Description Text		<i>default =</i>	"Off"
BOXCLR (1)	Red	Green	(Upper box default) Black
State 1 Box Color	Cyan	Yellow	White Blue Magenta
BOXCLR (0)	Red	Green	White Black
State 0 Box Color	Cyan	Yellow	(Lower box default) Blue Magenta
INPTDIR		Direct	Open=>pvraw=off; Closed=>pvraw=on
Digital Input Direction		Reverse	Closed=>pvraw=off; Open=>pvraw=on
PVSRCOPT		OnlyAuto	PV source selection is not available and field wiring or memory fetch supplies PV.
PV Source Option		All	Selection from PVSOURCE is available & Operator/CL-program may supply PV.
PVSOURCE			Applies when PVSRCOPT = All.
PV Source		Auto	Field wiring or memory fetch supplies PV
		Man	PV is supplied by Operator or program
		Sub	A value is substituted by a CL program

LM Digital Input Data Point

LM88-608
Page 3 of 3
06/06

Alarming Display

		N/A if PNTFORM = Componnt.
\$AUXUNIT Auxiliary Unit	_____	<i>range</i> = Any Configured LCN Unit ID <i>default</i> = NaN
\$REALARM (R660 and later) Re-alarming Interval in Minutes	_____ <i>default</i> =	Applies when ALMOPT = Offnorml. <i>range</i> = 0 to 9999 minutes 0 minutes
ALMOPT Alarming Option	None Offnorml ChngOfSt	No affect Alarm if PV and PVNORMAL differs Alarm if PV state changes
PVNORMAL PV Value's Normal State Text	_____	Applies when ALMOPT = Offnorml. <i>range</i> = STATETXT(0) - STATETX(1) <i>default</i> = Text equal to "Off"
DLYTIME Alarm Delay In Seconds	_____	Applies when ALMOPT = Offnorml. <i>range</i> = 0 to 60 <i>default</i> = 5 (second)
OFFNRMPR Off Normal Alarm Priority or Change of State Alarm Priority	NoAction Journal Low High Emergency Printer JnlPrint	Alarm is not reported to the system and not annunciated (R670) Alarm is historized, not reported to US, not annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Printer not historized, reported to the printer, not annunciated Alarm is historized, not reported to US, not annunciated
ALENBST Point Alarm Enable Status	Enable Disable Inhibit	Applies when ALMOPT = Offnorml. <u>Displayed</u> <u>Logged</u> <u>Reported To EIP</u> Yes Yes Yes No Yes Yes No No No
EVTOPT Event Reporting Option	None Eip	Applies when ALMOPT = None, Offnorml. Eip is not allowed Process special is triggered in AM/CG Point will notify Seq. Of Events process Eip is allowed
EIPPCODE Event Init Proc Destination	_____ <i>default</i> =	Applies when EVTOPT = Eip. <i>range</i> = Not applicable Null N/A if ALMOPT = None.
CCSRC Contact Cutout Source	_____	<i>range</i> = -1 to 8191 <i>default</i> = -1

LM Digital Output Data Point

LM88-609

Page 1 of 2

12/01

LM DigOut Data Point	Engineer:	Date:
----------------------	-----------	-------

Point Assignment Display

NAME Tag Name		<i>range =</i> Not applicable <i>default =</i> Blank
NODETYP Node Type	PM APM HPM LM SM	<i>range =</i> Not applicable <i>default =</i> PM
PNTFORM Point Form	FULL Componnt	Point is fully displayed and alarmed Point is partially displayed but not alarmed
PTDESC Point Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
EUDESC Engineering Units Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
KEYWORD Point Keyword Descriptor		<i>range =</i> Not applicable <i>default =</i> Blank
ASSOCDSP Associated Display		<i>range =</i> Not applicable <i>default =</i> Blank
\$CDETAIL (R620 and later) Point Custom Display		<i>range =</i> Not applicable <i>default =</i> Blank
UNIT Process Unit Point Is Assigned To		<i>range =</i> Alphanumeric <i>default =</i> Not applicable
NTWKNUM NIM's UCN That Contains This Point		<i>range =</i> 1 to 20 <i>default =</i> Not applicable
NODENUM LMM's Address On The UCN		<i>range =</i> 1 to 64 <i>default =</i> Not applicable
SLOTNUM Slot Number		<i>range =</i> 1 to 4000 <i>default =</i> Not applicable
PRIMMOD Primary Module ID		<i>range =</i> Not applicable <i>default =</i> Null
PLCADDR Destination Address		<i>range =</i> -1 to 8191 <i>default =</i> -1
DOTYPE Digital Output Type	Status	Status type output Pulse Width Modulated type output

LM88-614
Page 1 of 3
12/01

PVFLTOPT(1)	1) Unsigned Signed Floating Boolean
(Input 1 Data Format)	
LISRC	<u>Source Point . Parameter</u>
LISRC(1)	
(Input 1 Connection)	
PVFLTOPT(2)	2) Unsigned Signed Floating Boolean
(Input 2 Data Format)	
LISRC(2)	
(Input 2 Connection)	

LM Logic Data Point

NIM Input Connections Display (continued)

PVFLTOPT(3) (Input 3 Data Format)	3) Unsigned Signed Floating Boolean
LISRC(3) (Input 3 Connection)	
PVFLTOPT(4) (Input 4 Data Format)	4) Unsigned Signed Floating Boolean
LISRC(4) (Input 4 Connection)	
PVFLTOPT(5) (Input 5 Data Format)	5) Unsigned Signed Floating Boolean
LISRC(5) (Input 5 Connection)	
PVFLTOPT(6) (Input 6 Data Format)	6) Unsigned Signed Floating Boolean
LISRC(6) (Input 6 Connection)	
PVFLTOPT(7) (Input 7 Data Format)	7) Unsigned Signed Floating Boolean
LISRC(7) (Input 7 Connection)	
PVFLTOPT(8) (Input 8 Data Format)	8) Unsigned Signed Floating Boolean
LISRC(8) (Input 8 Connection)	
PVFLTOPT(9) (Input 9 Data Format)	9) Unsigned Signed Floating Boolean
LISRC(9) (Input 9 Connection)	
PVFLTOPT(10) (Input 10 Data Format)	10) Unsigned Signed Floating Boolean
LISRC(10) (Input 10 Connection)	
PVFLTOPT(11) (Input 11 Data Format)	11) Unsigned Signed Floating Boolean
LISRC(11) (Input 11 Connection)	
PVFLTOPT(12) (Input 12 Data Format)	12) Unsigned Signed Floating Boolean
LISRC(12) (Input 12 Connection)	
LIBADOPT Logic Bad Input Handling Option	Off On Hold
	"Off" state is substituted for bad input "On" state is substituted for bad input Last good value is subst. for bad input

LM Logic Data Point

LM88-614

Page 3 of 3

12/01

NIM Logic Output Connections Display

Logic Output Destination Table

LODSTN (Logic-Output-Connection Destination)

Destination Point.Parameter

defaults = blank.blank

LOENBL

defaults = -1

range = -1 to 8191

01		
02		
03		
04		
05		
06		
07		
08		
09		
10		
11		
12		

NIM Logic Descriptors Display - N/A if PNTFORM = Componnt.

NODESC		range = 0 to 12
Number Of Generic Descriptors		default = 0
<u>Descr#</u>	<u>Generic Descriptors</u> (defaults= blanks)	
1	GENDESC(1)	
2	GENDESC(2)	
3	GENDESC(3)	
4	GENDESC(4)	
5	GENDESC(5)	
6	GENDESC(6)	
7	GENDESC(7)	
8	GENDESC(8)	
9	GENDESC(9)	
10	GENDESC(10)	
11	GENDESC(11)	
12	GENDESC(12)	

LM88-628
Page 1 of 2
06/06

Point Assignment Display

[illegible]

LM Flag Point

Operating Configuration Display

N/A if PNTFORM = Componnt.

STATETXT(1) STATE 1 DESCRIPTOR	_ _ _ _ _ _ _	<i>range</i> =	Not applicable
		<i>default</i> =	ON
STATETXT(0) STATE 0 DESCRIPTOR	_ _ _ _ _ _ _	<i>range</i> =	Not applicable
		<i>default</i> =	OFF
BOXCLR(1) State 1 Box Color	Red Cyan	Green Yellow	White Blue Black Magenta
BOXCLR(0) State 0 Box Color	Red Cyan	Green Yellow	White Blue Black Magenta

Alarming Display

N/A if PNTFORM = Componnt.

\$AUXUNIT Auxiliary Unit	_ _	<i>range</i> =	Any Configured LCN Unit ID
		<i>default</i> =	NaN
\$REALARM (R660 and later) Re-alarming Interval	_ _ _	<i>range</i> =	0 to 9999 minutes
		<i>default</i> =	0 minutes
OFFNRMPR Off Normal Alarm Priority	NoAction Journal Low High Emergency Printer JnlPrint	Alarm is not reported to the system and not annunciated (R670) Alarm is historized, not reported to US, not annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Alarm is historized, reported to US, and annunciated Printer not historized, reported to the printer, not annunciated Alarm is historized, not reported to US, not annunciated	
ALENBST Alarm Enable State	Enable Disable Inhibit	<i>default</i> =	Enable
EIPPCODE EIP POINT ID	_ _ _ _ _ _ _	<i>range</i> =	Not Applicable
		<i>default</i> =	Blank
CCSRC Contact Cutout Source	_ _ _	<i>range</i> =	-1 to 8191
		<i>default</i> =	-1

LM88-629
Page 1 of 1
12/01

PVFORMAT	D0	D1	D2
PV Decimal Format			

LM88-630
Page 1 of 1
12/01

[illegible]

