

# **Programmable Logic Controller Gateway Forms**

**PL88-500**



Implementation  
PLC Gateway

# ***Programmable Logic Controller Gateway Forms***

PL88-500  
Release 520  
7/96

---

# Copyright, Trademarks, and Notices

© Copyright 1995 by Honeywell Inc.

Revision 03 - July 15, 1996

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customer.

In no event is Honeywell liable to anyone for any indirect, special or consequential damages. The information and specifications in this document are subject to change without notice.

**TotalPlant** is a U.S. registered trademark of Honeywell Inc.  
Other brand or product names are trademarks of their respective owners.

---

## About This Publication

This publication supports **TotalPlant** Solution (TPS) System network Release 500 - 520. TPS is the evolution of TDC 3000<sup>X</sup>.

This is a reference manual for process engineers, control-system engineers, and application engineers who configure the various data points and box/slots for Programmable Logic Controllers connected to a PLCG on the TPS system.

This publication contains representations of Universal Station configuration screen displays for a PLCG. These PLCG forms are based on HG forms; therefore, the two look very similar. In most cases, you may select the default value; however, certain PLCG parameters require specific values, because only these choices are valid for a PLCG. They are highlighted in a bold typeface for your convenience.



---

# Table of Contents

---

## **1 INTRODUCTION**

- 1.1 General Form Instructions
  - 1.1.1 Line Numbers
  - 1.1.2 Defaults
  - 1.1.3 Pick and Port Notation
  - 1.1.4 Special Notes
- 1.2 References

### **FORM NAME**

### **FORM NUMBER**

|                                                            |          |
|------------------------------------------------------------|----------|
| PLCG Analog Input or Output Data Point Configuration Form  | PL88-504 |
| PLCG Analog Composite Data Point Configuration Form        | PL88-505 |
| PLCG Digital Input or Output Data Point Configuration Form | PL88-506 |
| PLCG Digital Composite Data Point Configuration Form       | PL88-507 |
| PLCG Counter Data Point Configuration Form                 | PL88-508 |
| PLCG Hiway Data Configuration Form                         | PL88-530 |
| PLCG Box Data Configuration Form                           | PL88-531 |
| PLCG Box/Slot Data Configuration Form                      | PL88-533 |



## INTRODUCTION

### Section 1

*This section provides instructions on how to fill out the Programmable Logic Controller Gateway Forms. These forms correspond to displays that are called up under the Hiway Gateway selection on the **TotalPlant** Solution (TPS) System Engineering Personality Menu when used to implement a PLCG.*

## 1.1 GENERAL FORM INSTRUCTIONS

### 1.1.1 Line Numbers

The PLCG forms have been designed so that the lines on them correspond with those on the Parameter Entry Displays (PEDs) for HG/DHP at the Universal Station. The Parameter Entry Displays will subsequently be used to enter the information from the form into the system. The lines on each form are consecutively numbered. In some cases, the line numbers may contain an alphabetic suffix letter. An alphabetic suffix indicates that the line may be exposed or suppressed on the PED, depending on the selection made in a previous line. This is explained further in sections that discuss each type of form.

### 1.1.2 Defaults

Default values are values that are assigned by the system. If you choose not to make an entry on a particular line, the default value is used. The default value for each parameter is listed on the configuration form, in the form instructions, and on the data-entry displays. In some cases, only specific entities are used for the PLCG. These are noted on the forms in bold typeface.

### 1.1.3 Pick and Port Notation

The forms have two types of entries:

1. Picks (also called touch-targets)—For selecting options. All options are on the forms. For each such entry, circle one of the options.
2. Ports—For entering data. The form shows the maximum number of characters that you can enter and the set of valid characters; write in an alphanumeric character-string.

### 1.1.4 Special Notes

Before configuring the Programmable Logic Controller Gateway, be sure to keep the following in mind:

- On form PL88-531, always configure the first PLCG of a PLCG pair as Data Hiway box number 2 (BOXNUM = 2), and configure its partner as hiway box 3. Even if there is no redundant partner, hiway box number three is still reserved and cannot be used. Both PLCGs must have BOXTYPE = HG.

- The PLCG can scan discrete status (digital inputs) that are “packed” in a register. Modicon controllers can affect this operation and possibly some emulator types. For this feature, 16 digitals may be packed into one 16-bit “holding” PLC register. The PLCG must be configured with all 16 statuses in one slot. The slot must be a digital input type slot, but the address should be the form 4xxxx, where 4 is the specifier and xxxx is the register address. Digitals must be packed relative to slot-subslot number as follows:

|                     |    |    |           |    |
|---------------------|----|----|-----------|----|
| Subslot Number      | 16 | 15 | 14-----02 | 01 |
| Register Bit Number | 16 | 15 | 14-----02 | 01 |

- All digital input slots must have the same PLC register address for this slot.
- Modicon PLC packs coils backwards in the register on BLOCK MOVE, i.e., BLOCK MOVE of coil addresses 101-116 yields coil 116 status in register bit 01, coil 115 in bit 02, etc. Not all PLCs do this reverse packing on BLOCK MOVES.
- The PLCG may be configured to accept only binary data (registers or counters) from A-B PLC-3 or PLC-5 controllers by selecting type “APLC” during configuration. Any other selection means the data will be accepted only in BCD form.

The PLC may be configured to accept data sent by A-B PLCs via unsolicited messages. During configuration, use Port No. =3 or 4 to mean Port 1 or Port 2 with unsolicited messages. Standard A-B Data Hiway rules apply. Configuration applies to each PLC definition (PC1, PC2, etc.) for each emulated DHP. Definitions may mix access types from the same physical PLC. This can be found on form PL88-533, lines 10 and 10A.

## 1.2 REFERENCES

The following publications contain useful information that you may need when filling out the forms:

| <u>Title</u>                                                 | <u>Publication No.</u> | <u>Binder</u>                                |
|--------------------------------------------------------------|------------------------|----------------------------------------------|
| Programmable Logic Controller Implementation Guidelines      | PL12-500               | Implementation/PLC Gateway                   |
| Data Entity Builder Manual                                   | SW11-511               | Implementation/Engineering Operations - 1    |
| Engineer's Reference Manual                                  | SW09-505               | Implementation/Startup & Reconfiguration - 2 |
| Programmable Logic Controller Gateway Control Functions      | PL09-500               | Implementation/PLC Gateway                   |
| Programmable Logic Controller Parameter Reference Dictionary | PL09-540               | Implementation/PLC Gateway                   |

PL88-504  
Page 1 of 4  
7/96

[illegible]

References: PLCG Parameter Reference Dictionary in the Implementation/PLC Gateway binder.  
Data Entity Builder in the Implementation/Engineering Operations - 1 binder.

**PLCG ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM**  
(Continued)

| MODE CONFIGURATION DISPLAY<br>(For Analog Output Data Point) |                                     |                 |                                   |                       |
|--------------------------------------------------------------|-------------------------------------|-----------------|-----------------------------------|-----------------------|
| 30                                                           | NORMAL MODE (NMODE)                 | MAN             | CAS                               | NONE (Default = NONE) |
| 30A                                                          | NORMAL MODE ATTRIBUTE<br>(NMODATTR) | NONE            | OPERATOR PROGRAM (Default = NONE) |                       |
| 31                                                           | CASCADE (RCASENB)                   | OFF             | ON                                | (Default = OFF)       |
| 32                                                           | OPERATOR MODE CHANGE<br>(MODEPERM)  | PERMIT          | NOPERMIT (Default = PERMIT)       |                       |
| 33                                                           | OPERATING MODE (MODE)               | (Default = MAN) |                                   |                       |

  

| PV CONFIGURATION DISPLAY<br>(For Analog Input Data Point) |                                  |               |                        |                           |
|-----------------------------------------------------------|----------------------------------|---------------|------------------------|---------------------------|
| 40                                                        | E.U. DESCRIPTOR (EUDESC)         | _ _ _ _ _ _ _ | (Default = All Blanks) |                           |
| 41                                                        | DECIMAL FORMAT (PVFORMAT)        |               | D0                     | D1 D2 D3 (Default = D0)   |
| 42                                                        | PV RANGE LOW (PVEULO)            | _ _ _ _ _ _ _ | (Default = 0.0)        |                           |
| 42A                                                       | PV DISPLAY LOW<br>(PVDSPLO)      | _ _ _ _ _ _ _ | (Default = NaN)        |                           |
| 43                                                        | PV RANGE HIGH (PVEUHI)           | _ _ _ _ _ _ _ | (Default = 100.0)      |                           |
| 43A                                                       | PV DISPLAY HIGH<br>(PVDSPHI)     | _ _ _ _ _ _ _ | (Default = NaN)        |                           |
| 44                                                        | OVERVIEW VALUE (OVERVAL)         | _ _ _ _       | (Default = 0%)         |                           |
| 45                                                        | PV RANGE OPTION<br>(PVRNGOP)     | NONE          | FULLRNG                | CLMPZERO (Default = NONE) |
| 45A                                                       | CLAMP VALUE OPTION<br>(PVCLAMP)  | NOCLAMP       | CLAMP                  | (Default = NOCLAMP)       |
| 46                                                        | CALIBRATION OFFSET<br>(CALIBOFF) | _ _ _ _ _ _ _ | (Default = 0.0)        |                           |

**PLCG ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM**  
(Continued)

| ALARMING DISPLAY<br>(For Analog Input Data Point) |                                                     |                                              |                              |                 |
|---------------------------------------------------|-----------------------------------------------------|----------------------------------------------|------------------------------|-----------------|
| 49                                                | AUXILIARY UNIT (\$AUXUNIT)                          | _ _ _                                        | (Default = - -) R520 & later |                 |
| 50                                                | ALARM FORMAT (ALFMT)                                | ALFMT00 ALFMT01                              | (Default = ALFMT00)          |                 |
| 50A                                               | PVLOTP (PVLOTP)                                     | _ _ _ _ _ _ _                                | (Default = 0.0)              |                 |
| 50B                                               | PV ALARM DEADBAND<br>(PVALDB)                       | _ _ _ _ _ _ _                                | (Default = 0.0)              |                 |
| 50C                                               | PVHITP (PVHITP)                                     | _ _ _ _ _ _ _                                | (Default = 0.0)              |                 |
| 50D                                               | DEVLOTP (DEVLOTP)                                   | _ _ _ _ _ _ _                                | (Default = 0.0%)             |                 |
| 50E                                               | DEVHITP (DEVHITP)                                   | _ _ _ _ _ _ _                                | (Default = 0.0%)             |                 |
| 51                                                | CONFIGURATION ERROR<br>ALARM PRIORITY<br>(CNFERRPR) | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER           | LOW<br>JNLPRINT |
| 52                                                | DEVIATION HIGH<br>ALARM PRIORITY<br>(DEVHIPR)       | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER           | LOW<br>JNLPRINT |
| 53                                                | DEVIATION LOW<br>ALARM PRIORITY<br>(DEVLOPR)        | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER           | LOW<br>JNLPRINT |
| 54                                                | PV HIGH<br>ALARM PRIORITY<br>(PVHIPR)               | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER           | LOW<br>JNLPRINT |
| 55                                                | PV LOW<br>ALARM PRIORITY<br>(PVLOPR)                | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER           | LOW<br>JNLPRINT |
| 56                                                | UNREASONABLE<br>ALARM PRIORITY<br>(UNREASPR)        | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER           | LOW<br>JNLPRINT |
| 57                                                | CRITICAL ALARM SCANNING<br>(CRITSCAN)               | OFF ON                                       | (Default = OFF)              |                 |
| 58                                                | CONTACT CUTOFF RANK<br>(CCRANK)                     | NEITHER PRIMARY SECNDARY                     | (Default = NEITHER)          |                 |
| 59                                                | PRIMARY POINT<br>(CCPRIPNT)                         | _ _ _ _ _ _ _                                | (Default = All Underscores)  |                 |
| 60                                                | EIP POINT ID<br>(EIPPCODE)                          | _ _ _ _ _ _ _                                | (Default = All Underscores)  |                 |
| 60A                                               | EIP EVENT TYPE<br>(EIPEVENT)                        | ANY ALARM RETURN<br>HIGH HIGH_R LOW LOW_R    | (Default = Any)              |                 |
| 61                                                | EIP ENABLE (EIPENB)                                 | ENABLE DISABLE                               | (Default = Enable)           |                 |

**PLCG ANALOG INPUT OR OUTPUT DATA POINT CONFIGURATION FORM**  
(Continued)

---

| OPERATING CONFIGURATION DISPLAY<br>(For Analog Input Data Point) |                                |                                                   |
|------------------------------------------------------------------|--------------------------------|---------------------------------------------------|
| 60                                                               | TARGET (PVTV)                  | _ _ _ _ _ _ _  (Default = 0.0)                    |
| 61                                                               | PC BOX INDEX (PNTBOXIN)        | _  (Default = 1)                                  |
| 62                                                               | PC TYPE (PNTPCY)               | ALLENBRD MODICON HONYWELL (Default =<br>ALLENBRD) |
| 62A                                                              | INPUT PC ADDRESS<br>(PCADDRI1) | _ _ _ _ _  (Default = 0)                          |
| 62B                                                              | SPECIFIER CODE (SPECIFI1)      | _  (Default = 0)                                  |
| 63                                                               | PC RANGE CODE (RNGCODE1)       | _  (Default = 0)                                  |

PL88-505  
Page 1 of 4  
7/96

## POINT ASSIGNMENT DISPLAY

[illegible]

## PV CONFIGURATION DISPLAY

|     |                           |               |                        |    |                   |
|-----|---------------------------|---------------|------------------------|----|-------------------|
| 20  | E.U. DESCRIPTOR (EUDESC)  | _ _ _ _ _ _ _ | (Default = All Blanks) |    |                   |
| 21  | DECIMAL FORMAT (PVFORMAT) | D0            | D1                     | D2 | D3 (Default = D0) |
| 22  | PV RANGE LOW (PVEULO)     | _ _ _ _ _ _ _ | (Default = 0.0)        |    |                   |
| 22A | PV DISPLAY LOW (PVDSPL0)  | _ _ _ _ _ _ _ | (Default = NaN)        |    |                   |
| 23  | PV RANGE HIGH (PVEUHI)    | _ _ _ _ _ _ _ | (Default = 100.0)      |    |                   |
| 23A | PV DISPLAY HIGH (PVDSPHI) | _ _ _ _ _ _ _ | (Default = NaN)        |    |                   |
| 24  | OVERVIEW VALUE (OVERVAL)  | _ _ _ _       | (Default = 0%)         |    |                   |

References: PLCG Parameter Reference Dictionary in the Implementation/PLC Gateway binder.  
Data Entity Builder in the Implementation/Engineering Operations - 1 binder.

**PLCG ANALOG COMPOSITE DATA POINT CONFIGURATION FORM**  
(Continued)

| PV CONFIGURATION DISPLAY |                                                     |                                              |                    |                                             |
|--------------------------|-----------------------------------------------------|----------------------------------------------|--------------------|---------------------------------------------|
| 26                       | CLAMP VALUE OPTION                                  | NOCLAMP                                      | CLAMP              | (Default = NOCLAMP)<br>(PVCLAMP)            |
| 27                       | CALIBRATION OFFSET                                  | _ _ _ _ _ _ _                                |                    | (Default = 0.0)<br>(CALIBOFF)               |
| ALARMING DISPLAY         |                                                     |                                              |                    |                                             |
| 29                       | AUXILIARY UNIT (\$AUXUNIT)                          | _ _ _                                        |                    | (Default = - -) R520 & later                |
| 30                       | ALARM FORMAT (ALFMT)                                | ALFMT00                                      | ALFMT01            | (Default = ALFMT00)                         |
| 30A                      | PVLOTP (PVLOTP)                                     | _ _ _ _ _ _ _                                |                    | (Default = 0.0)                             |
| 30B                      | PV ALARM DEADBAND<br>(PVALDB)                       | _ _ _ _ _ _ _                                |                    | (Default = 0.0)                             |
| 30C                      | PVHITP (PVHITP)                                     | _ _ _ _ _ _ _                                |                    | (Default = 0.0)                             |
| 30D                      | DEVLOTP (DEVLOTP)                                   | _ _ _ _ _ _ _                                |                    | (Default = 0.0%)                            |
| 30E                      | DEVHITP (DEVHITP)                                   | _ _ _ _ _ _ _                                |                    | (Default = 0.0%)                            |
| 31                       | CONFIGURATION ERROR<br>ALARM PRIORITY<br>(CNFERRPR) | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER | LOW<br>JNLPRINT                             |
| 32                       | DEVIATION HIGH<br>ALARM PRIORITY<br>(DEVHIPR)       | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER | LOW<br>JNLPRINT                             |
| 33                       | DEVIATION LOW<br>ALARM PRIORITY<br>(DEVLOPR)        | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER | LOW<br>JNLPRINT                             |
| 34                       | PV HIGH<br>ALARM PRIORITY<br>(PVHIPR)               | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER | LOW<br>JNLPRINT                             |
| 35                       | PV LOW<br>ALARM PRIORITY<br>(PVLOPR)                | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER | LOW<br>JNLPRINT                             |
| 36                       | UNREASONABLE<br>ALARM PRIORITY<br>(UNREASPR)        | NOACTION<br>HIGH EMERGNCY<br>(Default = LOW) | JOURNAL<br>PRINTER | LOW<br>JNLPRINT                             |
| 37                       | CRITICAL ALARM SCANNING                             | OFF                                          | ON                 | (Default = OFF)<br>(CRITSCAN)               |
| 38                       | CONTACT CUTOFF RANK                                 | NEITHER                                      | PRIMARY            | SECNDARY (Default = NEITHER)<br>(CCRANK)    |
| 38A                      | PRIMARY POINT                                       | _ _ _ _ _ _ _                                |                    | (Default = All Under-<br>(CCPRIPNT) scores) |
| 39                       | EIP POINT ID                                        | _ _ _ _ _ _ _                                |                    | (Default = All Underscores)<br>(EIPPCODE)   |

**PLCG ANALOG COMPOSITE DATA POINT CONFIGURATION FORM**  
(Continued)

| ALARMING DISPLAY                |                                       |                  |                 |                    |                          |
|---------------------------------|---------------------------------------|------------------|-----------------|--------------------|--------------------------|
| 40                              | EIP EVENT TYPE<br>(EIPEVENT)          | ANY<br>HIGH      | ALARM<br>HIGH_R | RETURN<br>LOW      | (Default = Any)<br>LOW_R |
| 41                              | EIP ENABLE (EIPENB)                   | ENABLE           | DISABLE         | (Default = Enable) |                          |
| OPERATING CONFIGURATION DISPLAY |                                       |                  |                 |                    |                          |
| 50                              | OUTPUT INDICATION<br>(OUTIND)         | DIRECT           | REVERSE         | (Default = DIRECT) |                          |
| 51                              | TARGET (PVTV)                         | _ _ _ _ _ _ _    |                 | (Default = 0)      |                          |
| 52                              | PC TYPE (PNTPCY)                      | ALLENBRD         | MODICON         | HONYWELL           | (Default = ALLENBRD)     |
| 53                              | PC BOX INDEX (INPUT)<br>(PNTBOXIN)    | _  (Default = 1) |                 |                    |                          |
| 53A                             | INPUT PC ADDRESS<br>(PCADDR11)        | _ _ _ _ _        |                 | (Default = 0)      |                          |
| 53B                             | SPECIFIER CODE (INPUT)<br>(SPECIF11)  | _                |                 | (Default = 0)      |                          |
| 54                              | PC RANGE CODE (INPUT)<br>(RNGCODE1)   | _                |                 | (Default = 0)      |                          |
| 55                              | PC BOX INDEX (OUTPUT)<br>(PNTBOX0T)   | _                |                 | (Default = 0)      |                          |
| 55A                             | OUTPUT PC ADDRESS<br>(PCADDR01)       | _ _ _ _ _        |                 | (Default = 0)      |                          |
| 55B                             | SPECIFIER CODE (OUTPUT)<br>(SPECIF01) | _                |                 | (Default = 0)      |                          |
| 56                              | PC RANGE CODE (OUTPUT)<br>(RNGCODE2)  | _                |                 | (Default = 0)      |                          |
| MODE CONFIGURATION DISPLAY      |                                       |                  |                 |                    |                          |
| 60                              | NORMAL MODE (NMODE)                   | MAN              | CAS             | NONE               | (Default = NONE)         |
| 60A                             | NORMAL MODE ATTRIBUTE<br>(NMODATTR)   | OPERATOR         | PROGRAM         | NONE               | (Default = NONE)         |
| 61                              | CASCADE (RCASENB)                     | OFF              | ON              | (Default = OFF)    |                          |
| 62                              | OPERATOR MODE CHANGE<br>(MODEPERM)    | PERMIT           | NOPERMIT        | (Default = PERMIT) |                          |
| 63                              | OPERATING MODE<br>(MODE)              | (Default = MAN)  |                 |                    |                          |



PL88-506  
Page 1 of 4  
7/96

## PLCG DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM

**POINT ASSIGNMENT DISPLAY**  
(For Digital Input or Output Data Point)

[illegible]

References: PLCG Parameter Reference Dictionary in the Implementation/PLC Gateway binder.  
Data Entity Builder in the Implementation/Engineering Operations - 1 binder.

**PLCG DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM**  
(Continued)

| OPERATING CONFIGURATION DISPLAY<br>(For Digital Output Data Point) |                                                                                             |
|--------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| 20                                                                 | UPPER BOX TEXT (STATE2)  _ _ _ _ _ _ _  (Default = UPPER)                                   |
| 21                                                                 | LOWER BOX TEXT (STATE1)  _ _ _ _ _ _ _  (Default = LOWER)                                   |
| 22                                                                 | UPPER BOX COLOR RED GREEN WHITE BLACK<br>(UBOXCLR) CYAN YELLOW BLUE MAGENTA (Default = RED) |
| 23                                                                 | LOWER BOX COLOR RED GREEN WHITE BLACK<br>(LBOXCLR) CYAN YELLOW BLUE MAGENTA (Default = RED) |
| 24                                                                 | MOMENTARY O/P IND NOMOMENT MOMENT (Default = NOMOMENT)<br>(MOOUTIND)                        |
| 25                                                                 | OUTPUT INDICATION DIRECT REVERSE (Default = DIRECT)<br>(OUTIND)                             |
| 26                                                                 | PC BOX INDEX  _  (Default = 1)<br>(PNTBOXOT)                                                |
| 27                                                                 | PC TYPE ALLENBRD MODICON HONYWELL (Default = ALLENBRD)<br>(PNTPCTY)                         |
| 27A                                                                | OUTPUT 1 PC ADDRESS  _ _ _ _ _  (Default = 0)<br>(PCADDR01)                                 |
| 27B                                                                | OUTPUT 1 BIT POSITION  _ _ _  (Default = 0)<br>(PCBIT01)                                    |
| 27C                                                                | OUTPUT 1 SPECIFIER CODE  _  (Default = 0)<br>(SPECIF01)                                     |
| 27D                                                                | OUTPUT 2 SPECIFIER CODE  _  (Default = 0)<br>(SPECIF02)                                     |

**PLCG DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM**  
(Continued)

| MODE CONFIGURATION DISPLAY<br>(For Digital Output Data Point) |                                  |          |          |      |                    |
|---------------------------------------------------------------|----------------------------------|----------|----------|------|--------------------|
| 30                                                            | NORMAL MODE (NMODE)              | MAN      | CAS      | NONE | (Default = NONE)   |
| 30A                                                           | NORMAL MODE ATTRIBUTE (NMODATTR) | OPERATOR | PROGRAM  | NONE | (Default = NONE)   |
| 31                                                            | CASCADE (RCASENB)                | OFF      | ON       |      | (Default = OFF)    |
| 32                                                            | OPERATOR MODE CHANGE (MODEPERM)  | PERMIT   | NOPERMIT |      | (Default = PERMIT) |
| 33                                                            | OPERATING MODE (MODE)            |          |          |      | (Default = MAN)    |

  

| ALARMING DISPLAY<br>(For Digital Input Data Point) |                                               |                                     |                     |                  |                              |
|----------------------------------------------------|-----------------------------------------------|-------------------------------------|---------------------|------------------|------------------------------|
| 39                                                 | AUXILIARY UNIT (\$AUXUNIT)                    | _ _ _                               |                     |                  | (Default = - -) R520 & later |
| 40                                                 | ALARM FORMAT (DIGALFMT) [Single Input]        | STATE1<br>(Default = CHNGOFST)      | STATE2              | CHNGOFST         |                              |
| 41                                                 | ALARM FORMAT (DIGALFMT) [Dual Inputs]         | INPUT1<br>BOTH                      | INPUT2<br>CHNGOFST  | EITHER           | (Default = CHNGOFST)         |
| 42                                                 | CHANGE OF STATE ALARM PRIORITY (CHOFSTPR)     | NOACTION<br>HIGH<br>(Default = LOW) | JOURNAL<br>EMERGNCY | LOW<br>PRINTER   | JNLPRINT                     |
| 43                                                 | CONFIGURATION ERROR ALARM PRIORITY (CNFERRPR) | NOACTION<br>HIGH<br>(Default = LOW) | JOURNAL<br>EMERGNCY | LOW<br>PRINTER   | JNLPRINT                     |
| 44                                                 | OFF NORMAL ALARM PRIORITY (OFFNRMPR)          | NOACTION<br>HIGH<br>(Default = LOW) | JOURNAL<br>EMERGNCY | LOW<br>PRINTER   | JNLPRINT                     |
| 45                                                 | CRITICAL ALARM SCANNING (CRITSCAN)            | OFF                                 | ON                  |                  | (Default = OFF)              |
| 46                                                 | CONTACT CUTOFF RANK (CCRANK)                  | NEITHER                             | PRIMARY             | SECNDARY         | (Default = NEITHER)          |
| 46A                                                | Non-Comp State 00 Text (ZZTEXT)               | _ _ _ _ _ _ _ _ _                   |                     |                  |                              |
| 46B                                                | PRIMARY POINT ID (CCPRIPNT)                   | _ _ _ _ _ _ _ _ _                   |                     |                  | (Default = All Underscores)  |
| 47                                                 | EIP POINT ID (EIPPCODE)                       | _ _ _ _ _ _ _ _ _                   |                     |                  | (Default = All Underscores)  |
| 48                                                 | EIP EVENT TYPE (EIPEVENT)                     | ANY<br>CHGSTATE                     | ALARM<br>STATE1     | RETURN<br>STATE2 | (Default = Any)              |
| 49                                                 | EIP ENABLE (EIPENB)                           | ENABLE                              | DISABLE             |                  | (Default = Enable)           |

**PLCG DIGITAL INPUT OR OUTPUT DATA POINT CONFIGURATION FORM**  
(Continued)

| OPERATING CONFIGURATION DISPLAY<br>(For Digital Input Data Point) |                                      |               |                 |                   |                                  |
|-------------------------------------------------------------------|--------------------------------------|---------------|-----------------|-------------------|----------------------------------|
| 50                                                                | UPPER BOX TEXT (STATE2)              | _ _ _ _ _ _ _ |                 | (Default = UPPER) |                                  |
| 51                                                                | LOWER BOX TEXT (STATE1)              | _ _ _ _ _ _ _ |                 | (Default = LOWER) |                                  |
| 52                                                                | UPPER BOX COLOR<br>(UBOXCLR)         | RED<br>CYAN   | GREEN<br>YELLOW | WHITE<br>BLUE     | BLACK<br>MAGENTA (Default = RED) |
| 53                                                                | LOWER BOX COLOR<br>(LBOXCLR)         | RED<br>CYAN   | GREEN<br>YELLOW | WHITE<br>BLUE     | BLACK<br>MAGENTA (Default = RED) |
| 54                                                                | OVERVIEW VALUE (OVERVAL)             | OFF           |                 | ON                | (Default = OFF)                  |
| 55                                                                | INPUT DIRECTION (INPTDIR)            | DIRECT        |                 | REVERSE           | (Default = DIRECT)               |
| 56                                                                | PC BOX INDEX (PNTBOXIN)              | _             | (Default = 1)   |                   |                                  |
| 57                                                                | PC TYPE (PNTPCTY)                    | ALLENBRD      | MODICON         | HONYWELL          | (Default = ALLENBRD)             |
| 57A                                                               | INPUT 1 PC ADDRESS<br>(PCADDRI1)     | _ _ _ _ _     |                 | (Default = 0)     |                                  |
| 57B                                                               | INPUT 2 PC ADDRESS<br>(PCADDRI2)     | _ _ _ _ _     |                 | (Default = 0)     |                                  |
| 57C                                                               | INPUT 1 BIT POSITION<br>(PCBITI1)    | _ _           |                 | (Default = 0)     |                                  |
| 57D                                                               | INPUT 2 BIT POSITION<br>(PCBITI2)    | _ _           |                 | (Default = 0)     |                                  |
| 57E                                                               | INPUT 1 SPECIFIER CODE<br>(SPECIFI1) | _             |                 | (Default = 0)     |                                  |
| 57F                                                               | INPUT 2 SPECIFIER CODE<br>(SPECIFI2) | _             |                 | (Default = 0)     |                                  |

PL88-507  
Page 1 of 4  
7/96

|    |                                        | POINT ASSIGNMENT DISPLAY                                              |
|----|----------------------------------------|-----------------------------------------------------------------------|
| 1  | TAG NAME (NAME)                        | _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ <br>(Default = All Underscores) |
| 2  | UNIT ID (UNIT)                         | _ _   (Default = All Blanks)                                          |
| 3  | POINT DESCRIPTOR<br>(PTDESC)           | _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _  (Default =<br>All Blanks)      |
| 4  | POINT KEYWORD (KEYWORD)                | _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _  (Default = All Blanks)         |
| 5  | PRIMARY MODULE POINT ID<br>(PRIMMOD)   | _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _  (Default = All Underscores)    |
| 6  | POINT ASSOCIATED DISPLAY<br>(ASSOCDSP) | _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _  (Default = All Blanks)         |
| 7  | HIWAY NUMBER (HWYNUM)                  | _ _   (Default = 01)                                                  |
| 8  | BOX TYPE (PNTBOXTY)                    | HLPIU MC <b>DHP</b> (Select DHP)                                      |
| 9  | INPUT BOX NUMBER<br>(BOXNUM)           | _ _   (Default = 00) ( <b>08-15 for PLCG</b> )                        |
| 10 | OUTPUT BOX NUMBER<br>(OUTBOXNM)        | _ _   (Default = 00) ( <b>08-15 for PLCG</b> )                        |
| 11 | POINT DISCLOSURE<br>(PTDISCL)          | BRIEF FULL (Default = BRIEF)                                          |
| 12 | LOAD DESTINATION<br>(LOADDEST)         | HG <b>HG_HIWAY</b> (Default = HG)                                     |
| 13 | INPUT SLOT NUMBER<br>(SLOTNUM)         | _ _   (Default = 1)                                                   |
| 14 | INPUT SUBSLOT NUMBER<br>(INPTSSLT)     | _ _   (Default = 1)                                                   |
| 15 | NUMBER OF INPUTS<br>(NMBRINPT)         | _  (Default = 1)                                                      |
| 16 | OUTPUT SLOT NUMBER<br>(OUTSLTNM)       | _ _   (Default = 1)                                                   |
| 17 | OUTPUT SUBSLOT NUMBER<br>(OUTSSLT)     | _  (Default = 1)                                                      |
| 18 | NUMBER OF OUTPUTS<br>(NMBROUT)         | _  (Default = 1)                                                      |

**PLCG DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM**  
(Continued)

| ALARMING DISPLAY                |                                                     |                                                |                                      |                      |                                  |
|---------------------------------|-----------------------------------------------------|------------------------------------------------|--------------------------------------|----------------------|----------------------------------|
| 19                              | AUXILIARY UNIT (\$AUXUNIT)                          | _ _ _                                          | (Default = - -) R520 & later         |                      |                                  |
| 20                              | ALARM FORMAT (DIGALFMT)                             | STATE1                                         | STATE2                               | CHNGOFST             | CMDDIS                           |
|                                 | [Single Input]                                      | (Default = CHNGOFST)                           |                                      |                      |                                  |
| 21                              | ALARM FORMAT (DIGALFMT)                             | INPUT1                                         | INPUT2                               | EITHER               |                                  |
|                                 | [Dual Inputs]                                       | BOTH                                           | CHNGOFST                             | CMDDIS               | (Default = CHNGOFST)             |
| 22                              | CHANGE OF STATE<br>ALARM PRIORITY<br>(CHOFSTPR)     | NOACTION<br>HIGH<br>(Default = LOW)            | JOURNAL<br>EMERGNCY                  | LOW<br>PRINTER       | JNLPRINT                         |
| 23                              | COMMAND DISAGREE<br>ALARM PRIORITY<br>(CMDDISPR)    | NOACTION<br>HIGH<br>(Default = LOW)            | JOURNAL<br>EMERGNCY                  | LOW<br>PRINTER       | JNLPRINT                         |
| 24                              | CONFIGURATION ERROR<br>ALARM PRIORITY<br>(CNFERRPR) | NOACTION<br>HIGH<br>(Default = LOW)            | JOURNAL<br>EMERGNCY                  | LOW<br>PRINTER       | JNLPRINT                         |
| 25                              | OFF NORMAL<br>ALARM PRIORITY<br>(OFFNRMPR)          | NOACTION<br>HIGH<br>(Default = LOW)            | JOURNAL<br>EMERGNCY                  | LOW<br>PRINTER       | JNLPRINT                         |
| 26                              | CRITICAL ALARM SCANNING<br>(CRITSCAN)               | OFF                                            | ON                                   | (Default = OFF)      |                                  |
| 27                              | CONTACT CUTOFF RANK<br>(CCRANK)                     | NEITHER                                        | PRIMARY                              | SECNDARY             | (Default = NEITHER)              |
| 27A                             | PRIMARY POINT<br>(CCPRIPNT)                         | _ _ _ _ _ _ _ _ _  (Default = All Underscores) |                                      |                      |                                  |
| 28                              | EIP POINT ID<br>(EIPPCODE)                          | _ _ _ _ _ _ _ _ _  (Default = All Underscores) |                                      |                      |                                  |
| 29                              | EIP EVENT TYPE<br>(EIPEVENT)                        | ANY                                            | ALARM                                | RETURN               | (Default = Any)                  |
|                                 |                                                     | CHGSTATE                                       | STATE1                               | STATE2               |                                  |
| 30                              | EIP ENABLE (EIPENB)                                 | ENABLE                                         | DISABLE                              | (Default = Enable)   |                                  |
| OPERATING CONFIGURATION DISPLAY |                                                     |                                                |                                      |                      |                                  |
| 40                              | UPPER BOX DESCRIPTOR                                | (STATE2)                                       | _ _ _ _ _ _ _ _ _  (Default = UPPER) |                      |                                  |
| 41                              | LOWER BOX DESCRIPTOR                                | (STATE1)                                       | _ _ _ _ _ _ _ _ _  (Default = LOWER) |                      |                                  |
| 42                              | UPPER BOX COLOR<br>(UBOXCLR)                        | RED<br>CYAN                                    | GREEN<br>YELLOW                      | WHITE<br>BLUE        | BLACK<br>MAGENTA (Default = RED) |
| 43                              | LOWER BOX COLOR<br>(LBOXCLR)                        | RED<br>CYAN                                    | GREEN<br>YELLOW                      | WHITE<br>BLUE        | BLACK<br>MAGENTA (Default = RED) |
| 44                              | MOMENTARY O/P INDICATION<br>(MOOUTIND)              | NOMOMENT                                       | MOMENT                               | (Default = NOMOMENT) |                                  |

**PLCG DIGITAL COMPOSITE DATA POINT CONFIGURATION FORM**  
(Continued)

| OPERATING CONFIGURATION DISPLAY |                                       |                 |               |                    |                      |
|---------------------------------|---------------------------------------|-----------------|---------------|--------------------|----------------------|
| 45                              | OUTPUT INDICATION<br>(OUTIND)         | DIRECT          | REVERSE       | (Default = DIRECT) |                      |
| 46                              | OVERVIEW VALUE (OVERVAL)              | OFF             | ON            | (Default = OFF)    |                      |
| 47                              | INPUT DIRECTION<br>(INPTDIR)          | DIRECT          | REVERSE       | (Default = DIRECT) |                      |
| 48                              | PC TYPE (PNTPCY)                      | ALLENBRD        | MODICON       | HONYWELL           | (Default = ALLENBRD) |
| 49                              | PC BOX INDEX (INPUT)<br>(PNTBOXIN)    | __              | (Default = 1) |                    |                      |
| 49A                             | INPUT 1 PC ADDRESS<br>(PCADDR1)       | _ _ _ _         | (Default = 0) |                    |                      |
| 49B                             | INPUT 1 BIT POSITION<br>(PCBIT1)      | _ _             | (Default = 0) |                    |                      |
| 49C                             | INPUT 2 PC ADDRESS<br>(PCADDR2)       | _ _ _ _         | (Default = 0) |                    |                      |
| 49D                             | INPUT 1 SPECIFIER CODE<br>(SPECIF1)   | __              | (Default = 0) |                    |                      |
| 49E                             | INPUT 2 BIT POSITION<br>(PCBIT2)      | _ _             | (Default = 0) |                    |                      |
| 50                              | PC BOX INDEX (OUTPUT)<br>(PNTBOXOT)   | __              | (Default = 1) |                    |                      |
| 50A                             | OUTPUT 1 PC ADDRESS<br>(PCADDR01)     | _ _ _ _         | (Default = 0) |                    |                      |
| 50B                             | OUTPUT 1 BIT POSITION<br>(PCBIT01)    | _ _             | (Default = 0) |                    |                      |
| 50C                             | OUTPUT 1 SPECIFIER CODE<br>(SPECIF01) | __              | (Default = 0) |                    |                      |
| MODE CONFIGURATION DISPLAY      |                                       |                 |               |                    |                      |
| 51                              | NORMAL MODE (NMODE)                   | MAN             | CAS           | NONE               | (Default = NONE)     |
| 51A                             | NORMAL MODE ATTRIBUTE<br>(NMODATTR)   | OPERATOR        | PROGRAM       | NONE               | (Default = NONE)     |
| 52                              | OPERATOR MODE CHANGE<br>(MODEPERM)    | PERMIT          | NOPERMIT      | (Default = PERMIT) |                      |
| 53                              | OPERATING MODE<br>(MODE)              | (Default = MAN) |               |                    |                      |



PL88-508  
Page 1 of 2  
7/96

[illegible]

References: PLCG Parameter Reference Dictionary in the Implementation/PLC Gateway binder.  
Data Entity Builder in the Implementation/Engineering Operations - 1 binder.

**PLCG COUNTER DATA POINT CONFIGURATION FORM**  
(Continued)

---

OPERATING CONFIGURATION DISPLAY

---

|     |                                      |                                                |                        |
|-----|--------------------------------------|------------------------------------------------|------------------------|
| 30  | E.U. DESCRIPTOR (EUDESC)             | _ _ _ _ _ _ _ _                                | (Default = All Blanks) |
| 31  | DECIMAL POINT POSITION<br>(AVFORMAT) | 00      01      02      03                     | (Default = 00)         |
| 32  | SCALE FACTOR (AVCONV)                | _ _ _                                          | (Default = 1.0)        |
| 33  | PRESET VALUE (PRESET)                | _ _ _ _ _ _ _                                  | (Default = 0.0)        |
| 34  | PC BOX INDEX (PNTBOXIN)              | _                                              | (Default = 1)          |
| 35  | PC TYPE (PNTPCTY)                    | ALLENBRD MODICON HONYWELL (Default = ALLENBRD) |                        |
| 35A | INPUT PC ADDRESS<br>(PCADDRI1)       | _ _ _ _                                        | (Default = 0)          |
| 35B | INPUT SPECIFIER CODE<br>(SPECIFI1)   | _                                              | (Default = 0)          |

PL88-530  
Page 1 of 2  
7/96

## POINT ASSIGNMENT DISPLAY

# DUAL DIGITAL INPUT NONCOMPLEMENTARY TEXT

|   |                     |                                        |
|---|---------------------|----------------------------------------|
| 5 | TEXT1<br>(NCMPTXT1) | _ _ _ _ _ _ _ _ _  (Default = BADPV)   |
| 6 | TEXT2<br>(NCMPTXT2) | _ _ _ _ _ _ _ _ _  (Default = INBETWN) |



NOTE: For certain parameters, there is only one valid choice for the PLCG,  
which is indicated in **THIS TYPEFACE**.

PL88-531  
Page 1 of 2  
7/96

### PLCG BOX DATA POINT CONFIGURATION FORM

| BOX POINT DISPLAY<br>(FOR PRIMARY PLCG) |                                |                            |                                      |                                                     |
|-----------------------------------------|--------------------------------|----------------------------|--------------------------------------|-----------------------------------------------------|
| 1                                       | HIWAY NUMBER<br>(HWYNUM)       | _ _                        | (Default = 1)                        |                                                     |
| 2                                       | BOX NUMBER<br>(BOXNUM)         | _ _                        | (Default = 0) <b>(2 for Primary)</b> |                                                     |
| 3                                       | BOX TYPE<br>(BOXTYPE)          | CB<br>LEPIU<br>MC<br>H4500 | AU<br>CBRCD<br>MCRCD<br><b>HG</b>    | HLPIU<br>EC<br>DHP<br>GPCI<br>NOTCONFIG (Enter DHP) |
| 4                                       | BOX ASSIGNMENT<br>(BOXASSN)    | <b>THISHG</b>              | REMOTEHG                             | ADDEDHG (Default = THISHG)                          |
| 5                                       | LOAD DESTINATION<br>(LOADDEST) | <b>HG</b>                  | HG_HIWAY                             |                                                     |

  

| BOX POINT DISPLAY<br>(FOR BACKUP PLCG) |                             |                            |                                     |                                                     |
|----------------------------------------|-----------------------------|----------------------------|-------------------------------------|-----------------------------------------------------|
| 1                                      | HIWAY NUMBER<br>(HWYNUM)    | _ _                        | (Default = 1)                       |                                                     |
| 2                                      | BOX NUMBER<br>(BOXNUM)      | _ _                        | (Default = 0) <b>(3 for Backup)</b> |                                                     |
| 3                                      | BOX TYPE<br>(BOXTYPE)       | CB<br>LEPIU<br>MC<br>H4500 | AU<br>CBRCD<br>MCRCD<br><b>HG</b>   | HLPIU<br>EC<br>DHP<br>GPCI<br>NOTCONFIG (Enter DHP) |
| 4                                      | BOX ASSIGNMENT<br>(BOXASSN) | <b>THISHG</b>              | REMOTEHG                            | ADDEDHG (Default = THISHG)                          |



NOTE: For certain parameters, there is only one valid choice for the PLCG,  
which is indicated in **THIS TYPEFACE**.

PL88-533  
Page 1 of 8  
7/96

### PLCG BOX/SLOT DATA CONFIGURATION FORM

| BOX POINT DISPLAY |                                       |
|-------------------|---------------------------------------|
| 1                 | HIWAY NUMBER<br>(HWYNUM)              |
| 2                 | BOX NUMBER<br>(BOXNUM)                |
| 3                 | BOX TYPE<br>(BOXTYPE)                 |
| 4                 | BOX ASSIGNMENT<br>** (BOXASSN)        |
| 5                 | LOAD DESTINATION<br>** (LOADDEST)     |
| 6                 | DHP BOX SIZE<br>(BOXSIZE)             |
| 7                 | BOX PROTOCOL<br>(BOXPROT)             |
| 8                 | BOX STARTUP<br>(BOXSTART)             |
| 9                 | SCAN TIME(SEC)<br>(SCANTIME)          |
| 10                | PC1 MODEL TYPE<br>(PC1TYPE)           |
| 10A               | PORT NUMBER<br>(PC1PORT)              |
| 10B               | PORT ADDRESS<br>(PC1PORTA)            |
| 10C               | KEEP ALIVE ADDRESS<br>(PC1ALIVE)      |
| 10D               | KEEP ALIVE BIT POSITION<br>(PC1ALVBT) |
| 10E               | SPECIFIER<br>(PC1ALVSP)               |
| 11                | PC2 MODEL TYPE<br>(PC2TYPE)           |

(Default = 1)

(Default = 0) (**8 - 15 for DHPs**)

|       |       |            |                       |
|-------|-------|------------|-----------------------|
| CB    | AU    | HLPIU      | LLPIU                 |
| LEPIU | CBRCD | EC         | ECRCD                 |
| MC    | MCRCD | <b>DHP</b> | OPSTA                 |
| H4500 | HG    | GPCI       | NOTCONFG (Select DHP) |

**THISHG** REMOTEHG ADDEDHG (Default = THISHG)

HG **HG\_HIWAY** (Default = HG)

REGULAR **EXTENDED** (Default = REGULAR)

ALLENBRD MODICON HONYWELL (Default = ALLENBRD)

**COLD** HOT (Default = COLD)

(Default = 0) (00 for EPLCG)

|                           |                        |          |                     |               |
|---------------------------|------------------------|----------|---------------------|---------------|
| NOTCONFG                  | M384                   | M484     | M584                | (For Modicon) |
| (Default = NOTCONFG)----- |                        |          |                     |               |
| NOTCONFG                  | APLC                   | APLC2    | APLC215             |               |
| APLC220                   | APLC230                | AMINPLC2 | (For Allen-Bradley) |               |
| (Default = NOTCONFG)----- |                        |          |                     |               |
| NOTCONFG                  | IPC620 (For Honeywell) |          |                     |               |
| (Default = NOTCONFG)----- |                        |          |                     |               |

(Default = 1)

(Default = 0)

(Default = 0)

(Default = 0)

(Default = 0)

|          |                        |          |                       |                |
|----------|------------------------|----------|-----------------------|----------------|
| NOTCONFG | M384                   | M484     | M584                  | (For Modicon)* |
| -----    |                        |          |                       |                |
| NOTCONFG | APLC                   | APLC2    | APLC215               |                |
| APLC220  | APLC230                | AMINPLC2 | (For Allen-Bradley)** |                |
| -----    |                        |          |                       |                |
| NOTCONFG | IPC620 (For Honeywell) |          |                       |                |
| -----    |                        |          |                       |                |

\*For Modicon type 984 or for Modicon emulators, choose M584.

\*\*For A-B PLC-3 or PLC-5 using binary data, choose APLC, otherwise choose APLC230.

PLCG BOX/SLOT DATA CONFIGURATION FORM  
(Continued)

| BOX POINT DISPLAY                         |                                  |         |          |                     |
|-------------------------------------------|----------------------------------|---------|----------|---------------------|
| 11A PORT NUMBER<br>(PC2PORT)              | __  (Default = 1)                |         |          |                     |
| 11B PORT ADDRESS<br>(PC2PORTA)            | _ _ _ _  (Default = 0)           |         |          |                     |
| 11C KEEP ALIVE ADDRESS<br>(PC2ALIVE)      | _ _ _ _ _  (Default = 0)         |         |          |                     |
| 11D KEEP ALIVE BIT POSITION<br>(PC2ALVBT) | _ _ _  (Default = 0)             |         |          |                     |
| 11E SPECIFIER<br>(PC2ALVSP)               | _ _  (Default = 0)               |         |          |                     |
| 12 PC3 MODEL TYPE<br>(PC3TYPE)            | NOTCONFIG                        | M384    | M484     | M584 (For Modicon)  |
|                                           | NOTCONFIG                        | APLC    | APLC2    | APLC215             |
|                                           | APLC220                          | APLC230 | AMINPLC2 | (For Allen-Bradley) |
|                                           | NOTCONFIG IPC620 (For Honeywell) |         |          |                     |
| 12A PORT NUMBER<br>(PC3PORT)              | __  (Default = 1)                |         |          |                     |
| 12B PORT ADDRESS<br>(PC3PORT)             | _ _ _ _  (Default = 0)           |         |          |                     |
| 12C KEEP ALIVE ADDRESS<br>(PC3ALIVE)      | _ _ _ _ _  (Default = 0)         |         |          |                     |
| 12D KEEP ALIVE BIT POSITION<br>(PC3ALVBT) | _ _ _  (Default = 0)             |         |          |                     |
| 12E SPECIFIER<br>(PC3ALVSP)               | _ _  (Default = 0)               |         |          |                     |
| 13 PC4 MODEL TYPE<br>(PC4TYPE)            | NOTCONFIG                        | M384    | M484     | M584 (For Modicon)  |
|                                           | NOTCONFIG                        | APLC    | APLC2    | APLC215             |
|                                           | APLC220                          | APLC230 | AMINPLC2 | (For Allen-Bradley) |
|                                           | NOTCONFIG IPC620 (For Honeywell) |         |          |                     |
| 13A PORT NUMBER<br>(PC4PORT)              | __  (Default = 1)                |         |          |                     |
| 13B PORT ADDRESS<br>(PC4PORTA)            | _ _ _ _  (Default = 0)           |         |          |                     |
| 13C KEEP ALIVE ADDRESS<br>(PC4ALIVE)      | _ _ _ _ _  (Default = 0)         |         |          |                     |
| 13D KEEP ALIVE BIT POSITION<br>(PC4ALVBT) | _ _ _  (Default = 0)             |         |          |                     |
| 13E SPECIFIER<br>(PC4ALVSP)               | _ _  (Default = 0)               |         |          |                     |

PLCG BOX/SLOT DATA CONFIGURATION FORM  
(Continued)

BOX POINT DISPLAY

|       |                                       |                        |         |          |         |                     |
|-------|---------------------------------------|------------------------|---------|----------|---------|---------------------|
| 14    | PC5 MODEL TYPE<br>(PC5TYPE)           | NOTCONFG               | M384    | M484     | M584    | (For Modicon)       |
| ----- |                                       |                        |         |          |         |                     |
|       |                                       | NOTCONFG               | APLC    | APLC2    | APLC215 |                     |
|       |                                       | APLC220                | APLC230 | AMINPLC2 |         | (For Allen-Bradley) |
| ----- |                                       |                        |         |          |         |                     |
|       |                                       | NOTCONFG               | IPC620  |          |         | (For Honeywell)     |
| ----- |                                       |                        |         |          |         |                     |
| 14A   | PORT NUMBER<br>(PC5PORT)              | _  (Default = 1)       |         |          |         |                     |
| 14B   | PORT ADDRESS<br>(PC5PORTA)            | _ _ _  (Default = 0)   |         |          |         |                     |
| 14C   | KEEP ALIVE ADDRESS<br>(PC5ALIVE)      | _ _ _ _  (Default = 0) |         |          |         |                     |
| 14D   | KEEP ALIVE BIT POSITION<br>(PC5ALVBT) | _ _  (Default = 0)     |         |          |         |                     |
| 14E   | SPECIFIER<br>(PC5ALVSP)               | _  (Default = 0)       |         |          |         |                     |
| 15    | PC6 MODEL TYPE<br>(PC6TYPE)           | NOTCONFG               | M384    | M484     | M584    | (For Modicon)       |
| ----- |                                       |                        |         |          |         |                     |
|       |                                       | NOTCONFG               | APLC    | APLC2    | APLC215 |                     |
|       |                                       | APLC220                | APLC230 | AMINPLC2 |         | (For Allen-Bradley) |
| ----- |                                       |                        |         |          |         |                     |
|       |                                       | NOTCONFG               | IPC620  |          |         | (For Honeywell)     |
| ----- |                                       |                        |         |          |         |                     |
| 15A   | PORT NUMBER<br>(PC6PORT)              | _  (Default = 1)       |         |          |         |                     |
| 15B   | PORT ADDRESS<br>(PC6PORTA)            | _ _ _  (Default = 0)   |         |          |         |                     |
| 15C   | KEEP ALIVE ADDRESS<br>(PC6ALIVE)      | _ _ _ _  (Default = 0) |         |          |         |                     |
| 15D   | KEEP ALIVE BIT POSITION<br>(PC6ALVBT) | _ _  (Default = 0)     |         |          |         |                     |
| 15E   | SPECIFIER<br>(PC6ALVSP)               | _  (Default = 0)       |         |          |         |                     |
| 16    | PC7 MODEL TYPE<br>(PC7TYPE)           | NOTCONFG               | M384    | M484     | M584    | (For Modicon)       |
| ----- |                                       |                        |         |          |         |                     |
|       |                                       | NOTCONFG               | APLC    | APLC2    | APLC215 |                     |
|       |                                       | APLC220                | APLC230 | AMINPLC2 |         | (For Allen-Bradley) |
| ----- |                                       |                        |         |          |         |                     |
|       |                                       | NOTCONFG               | IPC620  |          |         | (For Honeywell)     |
| ----- |                                       |                        |         |          |         |                     |

PLCG BOX/SLOT DATA CONFIGURATION FORM  
(Continued)

| BOX POINT DISPLAY |                                       |                                      |          |                              |
|-------------------|---------------------------------------|--------------------------------------|----------|------------------------------|
| 16A               | PORT NUMBER<br>(PC7PORT)              | _  (Default = 1)                     |          |                              |
| 16B               | PORT ADDRESS<br>(PC7PORTA)            | _ _ _  (Default = 0)                 |          |                              |
| 16C               | KEEP ALIVE ADDRESS<br>(PC7ALIVE)      | _ _ _ _  (Default = 0)               |          |                              |
| 16D               | KEEP ALIVE BIT POSITION<br>(PC7ALVBT) | _ _  (Default = 0)                   |          |                              |
| 16E               | SPECIFIER<br>(PC7ALVSP)               | _  (Default = 0)                     |          |                              |
| 17                | PC8 MODEL TYPE<br>(PC8TYPE)           | NOTCONFIG                            | M384     | M484 M584 (For Modicon)      |
|                   |                                       | NOTCONFIG                            | APLC     | APLC2 APLC215                |
|                   |                                       | APLC220                              | APLC230  | AMINPLC2 (For Allen-Bradley) |
|                   |                                       | NOTCONFIG                            | IPC620   | (For Honeywell)              |
| 17A               | PORT NUMBER<br>(PC8PORT)              | _  (Default = 1)                     |          |                              |
| 17B               | PORT ADDRESS<br>(PC8PORTA)            | _ _ _  (Default = 0)                 |          |                              |
| 17C               | KEEP ALIVE ADDRESS<br>(PC8ALIVE)      | _ _ _ _  (Default = 0)               |          |                              |
| 17D               | KEEP ALIVE BIT POSITION<br>(PC8ALVBT) | _ _  (Default = 0)                   |          |                              |
| 17E               | SPECIFIER<br>(PC8ALVSP)               | _  (Default = 0)<br>(Default = NONE) |          |                              |
| 18                | SLOT 1 TYPE<br>(PIUCRDY)              | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |
| 19                | SLOT 2 TYPE                           | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |
| 20                | SLOT 3 TYPE                           | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |
| 21                | SLOT 4 TYPE                           | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |
| 22                | SLOT 5 TYPE                           | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |
| 23                | SLOT 6 TYPE                           | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |
| 24                | SLOT 7 TYPE                           | NONE                                 | DIGIN    | DIGOUT (Default = NONE)      |
|                   |                                       | ANALOGIN                             | ANALOGOT | COUNTER                      |

**PLCG BOX/SLOT DATA CONFIGURATION FORM**  
(Continued)

| BOX POINT DISPLAY |              |          |          |                         |
|-------------------|--------------|----------|----------|-------------------------|
| 25                | SLOT 8 TYPE  | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 26                | SLOT 9 TYPE  | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 27                | SLOT 10 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 28                | SLOT 11 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 29                | SLOT 12 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 30                | SLOT 13 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 31                | SLOT 14 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 32                | SLOT 15 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 33                | SLOT 17 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 34                | SLOT 18 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 35                | SLOT 19 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 36                | SLOT 20 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 37                | SLOT 21 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 38                | SLOT 22 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 39                | SLOT 23 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |
| 40                | SLOT 24 TYPE | NONE     | DIGIN    | DIGOUT (Default = NONE) |
|                   |              | ANALOGIN | ANALOGOT | COUNTER                 |

**PLCG BOX/SLOT DATA CONFIGURATION FORM**  
(Continued)

| BOX POINT DISPLAY |                                   |                  |                       |                           |
|-------------------|-----------------------------------|------------------|-----------------------|---------------------------|
| 41                | SLOT 25 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 42                | SLOT 26 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 43                | SLOT 27 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 44                | SLOT 28 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 45                | SLOT 29 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 46                | SLOT 30 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 47                | SLOT 31 TYPE                      | NONE             | DIGIN                 | DIGOUT                    |
|                   |                                   | ANALOGIN         | ANALOGOT              | COUNTER (Default = NONE)  |
| 48                | CHANGE DETECTION<br>(CHNGFLAG)    | <b>NOTCONFIG</b> | DETECT                | SET (Default = NOTCONFIG) |
| 49                | VARIABLE DEADBAND<br>(BOXVDB)     | OFF              | ON                    | (Default = OFF)           |
| 50                | EVENT PROCESSING<br>(EVENTPRC)    | DISABLE          | <b>ENABLE</b>         | (Default = DISABLE)       |
| 51                | TOG INTERVAL 1                    | _ _ _ _          | (Default = 0 seconds) |                           |
| ***               | (BOXTOG1)                         |                  |                       |                           |
| 52                | TOG INTERVAL 2                    | _ _ _ _          | (Default = 0 seconds) |                           |
| ***               | (BOXTOG2)                         |                  |                       |                           |
| 52A               | SLOT 1 TOG INTERVAL<br>(TOGINTSL) | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52B               | SLOT 2 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52C               | SLOT 3 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52D               | SLOT 4 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52E               | SLOT 5 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52F               | SLOT 6 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52G               | SLOT 7 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |
| 52H               | SLOT 8 TOG INTERVAL               | INTERVL1         | INTERVL2              | (Default = INTERVL1)      |

PLCG BOX/SLOT DATA CONFIGURATION FORM  
(Continued)

| BOX POINT DISPLAY         |          |                               |
|---------------------------|----------|-------------------------------|
| 52I SLOT 9 TOG INTERVAL   | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52J SLOT 10 TOG INTERVAL  | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52K SLOT 11 TOG INTERVAL  | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52L SLOT 12 TOG INTERVAL  | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52M SLOT 13 TOG INTERVAL  | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52N SLOT 14 TOG INTERVAL  | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52O SLOT 15 TOG INTERVAL  | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AA SLOT 17 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AB SLOT 18 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AC SLOT 19 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AD SLOT 20 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AE SLOT 21 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AF SLOT 22 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AG SLOT 23 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AH SLOT 24 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AI SLOT 25 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AJ SLOT 26 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AK SLOT 27 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AL SLOT 28 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AM SLOT 29 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AN SLOT 30 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |
| 52AO SLOT 31 TOG INTERVAL | INTERVL1 | INTERVL2 (Default = INTERVL1) |



## READER COMMENTS

Honeywell IAC Automation College welcomes your comments and suggestions to improve future editions of this and other publications.

You can communicate your thoughts to us by fax, mail, or toll-free telephone call. We would like to acknowledge your comments; please include your complete name and address.

**BY FAX:** Use this form and fax to us at (602) 313-4108

**BY TELEPHONE:** In the U.S.A., use our toll-free number 1\*800-822-7673 (available in the 48 contiguous states except Arizona; in Arizona dial 1-602-313-5558).

**BY MAIL:** Use this form; detach, fold, tape closed, and mail to us.

Title of Publication: **Programmable Logic Controller Gateway Forms**

Issue Date: **7/96**

Publication Number: **PL88-500**

Writer: **Bill Damours**

**COMMENTS:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**RECOMMENDATIONS:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

NAME \_\_\_\_\_ DATE \_\_\_\_\_

TITLE \_\_\_\_\_

COMPANY \_\_\_\_\_

ADDRESS \_\_\_\_\_

CITY \_\_\_\_\_ STATE \_\_\_\_\_ ZIP \_\_\_\_\_

TELEPHONE \_\_\_\_\_ FAX \_\_\_\_\_





**Honeywell**

---

**Industrial Automation and Control**  
Honeywell Inc.  
16404 North Black Canyon Highway  
Phoenix, Arizona 85023-3033

*Helping You Control Your World*