JOHANSSON ENGINEERING

06 — How Long Will It Last

This journal tracks the remaining life of your vessels. Update it after each wall thickness measurement or formal inspection. If a vessel reaches its calculated end of life, it must be taken out of service or have a documented lifetime extension analysis.

Which Vessels Need This Journal?

> Only Class A and B vessels with limited lifetime need this journal (AFS 2017:3, 4 Kap. §18). If corrosion, fatigue, or creep could shorten the vessel's life, track it here.

NR	VESSEL ID	CORROSION?	FATIGUE?	CREEP?
1		Y / N	Y / N	Y / N
2		Y / N	Y / N	Y / N
3		Y / N	Y / N	Y / N
4		Y / N	Y / N	Y / N
5		Y / N	Y / N	Y / N

Design Data

> Get this from the manufacturer data sheet or design documentation.

NR	VESSEL ID	MATERIAL	WALL (MM)	MIN. REQUIRED (MM)	ALLOWANCE (MM)
1					
2					
3					
4					
5					

> **Allowance** = Wall minus Min. required. This is how much material can corrode away before the vessel is unsafe.

Wall Thickness Measurements

> After each ultrasonic measurement, add a row. Calculate the corrosion rate and remaining life.

Vessel Nr ___ ID: _____

DATE	LOCATION	MEASURED (MM)	RATE (MM/YR)	LIFE LEFT (YR)	INSPECTOR

> **Rate** = (previous - current) / years between. **Life left** = (measured - min. required) / rate.

Trend: Stable / Getting worse / Getting worse fast

Vessel Nr ___ ID: _____

DATE	LOCATION	MEASURED (MM)	RATE (MM/YR)	LIFE LEFT (YR)	INSPECTOR

Trend: Stable / Getting worse / Getting worse fast

Vessel Nr ___ ID: _____

DATE	LOCATION	MEASURED (MM)	RATE (MM/YR)	LIFE LEFT (YR)	INSPECTOR

Trend: Stable / Getting worse / Getting worse fast

(Print extra copies for more vessels)

Lifetime Summary

NR	VESSEL ID	MAIN PROBLEM	LIFE LEFT	STATUS
1			yr	S / M / C / E
2			yr	S / M / C / E
3			yr	S / M / C / E
4			yr	S / M / C / E
5			yr	S / M / C / E

> **S** = Safe (plenty of life left) | **M** = Monitor (getting close) | **C** = Critical (needs engineering assessment) | **E** = Expired (must not be pressurised)

Updated By

Name	
Signature	
Date	