BOB Agent Setup | Kuppam Solar Site | Setup in progress | 3 systems connected | All changes saved | Save and exit

1 Select action — 2 Configure — 3 Test — 4 Activate

5 of 7 configuration decisions completed

Action selected: Discharge battery to support demand

Objective configured Edit

Maintain supply reliability

Controlled asset configured Edit

Battery 1 — Available · 72% · 8 MW max

Trigger configured Edit

Demand gap 3 MW for 5 min

Safety limits configured Edit

Max 6 MW · 30 min · 55% reserve

Safety limits configured Edit

Max 6 MW · 30 min · 55% reserve

How should I carry out this action?

- ○ **Recommend only**
  I identify the situation and suggest an action. A user starts it manually.
- ○ **Approval required**
  I prepare the action and wait for an authorized user to approve it.
- ● **Automatic within limits** — Recommended
  I execute automatically when all trigger and safety conditions are satisfied.

Effective policy — Immutable

This policy applies only when the configured trigger and safety conditions are met. Anything outside these boundaries requires approval.

- ☑ BOB may discharge automatically up to 6 MW.
- ☑ Anything above 6 MW requires approval.
- ☑ Reserve is 55%.
- ☑ Immutable floor is 30%.

Approval exceptions

These exceptions do not change the effective policy. They only define when approval is required before execution.

- ☑ Proposed discharge exceeds 6 MW
- ☑ Proposed duration exceeds 30 minutes
- ☑ Battery charge may fall below 55%
- ☑ Grid import is also required
- ☑ More than one battery is required
- ☑ Forecast confidence is below 85%
- ☑ Battery health is not Normal
- ☑ Live battery data is delayed by more than 2 minutes

Approver configuration

Primary approver: **Site operator**	Backup approver: **Utility control manager**
Approval response time: **10 minutes**	Escalation: **Remind after 5 min, escalate after 5 min, cancel after 10 min**

Safe behavior when approval expires or times out

If approval is not received within the configured response time, the request is cancelled and the action is not executed. BOB will continue monitoring the trigger and re-propose the action only when conditions are met again.

- ☑ The action is cancelled and will not execute automatically.
- ☑ BOB will continue monitoring the trigger and re-propose the action when conditions are met again.

Automatic execution will remain unavailable until this action passes testing and is activated.

Confirm automation settings | Customize

Ask BOB to adjust limits or explain any setup option...

Configured actions 1 action | Add action

Support demand using Battery 1 — Configuring

5 of 7 settings complete

CONFIGURED

- ☑ Objective: Maintain supply reliability
- ☑ Battery: Battery 1
- ☑ Trigger: Demand gap 3 MW for 5 min
- ☑ Limits: Max 6 MW · 30 min · 55% reserve
- ☑ Automation: Being configured

MISSING

Recovery

Notifications