BOB Agent Setup | Kuppam Solar Site | Setup in progress | 3 systems connected | All changes saved | Save and exit

Select action — Configure — Test — 4 Activate

7 of 7 configuration decisions completed · All required gates satisfied

Action selected: Discharge Battery 1 to support demand

Objective configured Edit

Maintain supply reliability · Automatic discharge up to 6 MW

Controlled asset configured Edit

Battery 1 — Available · 72% · 8 MW max · Verified permission granted

Trigger configured Edit

Demand gap 3 MW for 5 min · Battery charge above 60% · Shortfall forecast for at least 15 minutes

Safety limits configured Edit

Max discharge 6 MW · Max duration 30 min · Max energy 3 MWh · Min reserve 55% · Manufacturer recommendation 50% · Immutable floor 30%

Automation configured

Automatic discharge up to 6 MW · Approval required abov

Recovery behavior configured

Request approval to import up to 4 MW from the grid

Notifications configured

All critical events

Configuration test passed

3 of 3 required test categories complete: normal executic

Battery discharge is ready for activation. Review the configuration before giving me permission to execute automatically.
Supervised mode means BOB will execute automatically within configured limits, but approval is required above those limits.

Final Review & Activation Summary

Supervised Mode Active | Auto up to 6 MW · Approval above 6 MW

ACTION

Discharge Battery 1 to support site demand · Objective: Maintain supply reliability · Automatic discharge up to 6 MW

TRIGGER

Demand gap above 3 MW · Condition lasts at least 5 minutes · Battery charge above 60% · Shortfall forecast for at least 15 minutes

LIMITS

Maximum discharge: 6 MW · Maximum duration: 30 minutes · Maximum energy: 3 MWh · Minimum reserve: 55% · Manufacturer recommendation: 50% · Immutable floor: 30%

AUTOMATION

Automatic discharge up to 6 MW · Approval required above 6 MW

APPROVALS

Primary approver: Site operator · Backup approver: Utility control manager · Response window: 10 minutes

RECOVERY

Request approval to import up to 4 MW from the grid

Configured actions

3 actions | Add action

Support demand using Battery 1 — Ready to activate

7 of 7 settings complete

View details | Edit | Test

Charge battery using surplus solar — Draft

3 of 7 settings complete · Not ready for activation

Continue setup

Sell surplus electricity — Connection required

Electricity market not connected · Not ready for activation

Connect market

Activate Battery 1 discharge action?

BOB will be allowed to discharge Battery 1 automatically up to 6 MW within the configured limits. Approval will still be required above 6 MW.

- Max discharge 6 MW
- Max duration 30 min
- Max energy 3 MWh
- Min battery reserve 55%
- Approval required outside these limits

☑ I understand that BOB may execute this action automatically up to 6 MW within these limits, and approval will still be required above 6 MW.

Cancel | Activate action