



LOCOMOTIVE SHED, SABARMATI
MECHANICAL

3 Phase

TI PROFORMA OF THREE PHASE LOCO

Loco No./Type/Home Shed..... Shift..... Date.....

Reference:- Scheduled Maintenance Manual ABB (Indian Railways)

S.N	Items to Check	Remarks
1	Verify the driver remarks from log book for 10 days and attend.	
2	Record the DDS and analyze if any abnormality noticed inform PPIO.	

BOOKING OF DRIVER IF ANY

.....

.....

.....

.....

.....

ANY OTHER DEFECTS NOTICED DURING VISUAL CHECKING:

.....

.....

.....

.....

Sr. No.	Work Centre	Name of Technician
A.	Pneumatic	
B.	Bogie	

SSE/ Incharge

JE/SSE/Shift.....

SN	Items to Check								Std. Value	Remarks		
1.	BOGIE AND UNDER FRAME :											
1.1	When the loco arrives at the shed, temperature should note temperature of the following item. The ambient exceed +28°											
1.2	All axle boxes Temperature											
	1	2	3	4	5	6	7	8	9	10	11	12
1.3	MSU bearing (TEMP)											
	1		2		3		4		5		6	
	DE	NDE	DE	NDE	DE	NDE	DE	NDE	DE	NDE	DE	NDE
1.4	Check bogie fittings visually for any loose, damaged, cracked or dragged parts.								Goods Condition			
1.5	Visually inspect all damper for leakage/damages.								No Crack			
1.6	Inspect the Primary and Secondary springs for any cracks.								No Leakage			
1.7	Check the fasteners of guide rods and dampers for security.								Intact			
2.	TRACTION LINK											
2.1	Check the condition of link rods and safety wire.								Normal			
2.2	Inspect the traction link assembly for any damages.								No Damage			
2.3	Check the intactness of fasteners and its locking.								Intact			
2.4	Check Aclathon ring against any crack or shifting.								No Crack			
2.5	Check the intactness of all bolts of inner/outer retaining of Aclathon ring housing								Intact			
3.	WHEEL SET AND AXLE BOX											
3.1	Visually check the condition of wheels for any abnormality i.e. crack. Cavity, scoring and No Crack grooving.								No Crack			
3.2	Check for skidding if skid inform PPIO.								Normal			
3.3	Check Intactness of brake disk bolt.								Intact			
3.4	Check the intactness of axle box cover and ensure the availability of earth return shunt.								Intact			
		<u>R</u>	<u>F</u>	<u>T</u>		<u>R</u>	<u>F</u>	<u>T</u>				
	1				7							
	2				8							
	3				9							
	4				10							
	5				11							
	6				12							
4.	GEAR CASE :											
4.1	Check the gear cases and Hurth coupling for any damages.								No Damage			
4.2	Visually check intactness of all fasteners of gear cases.								Intact			
4.3	Check the oil level in the gear cases. Top up the oil required.								Top Up			
5.	BRAKE GEAR AND BRAKE BLOCK:											
5.1	Check brake rigging for loose, damaged and worn out parts.								Ensure			
5.2	Check operation of parking brakes (manual releasing) (for WAP-52, WAG-9)								Ensure			
5.3	Check the bogie isolating cock should be in proper position.								Ensure			
5.4	Check the brake Block key security.								Ensure			
5.5	Check for the wear of brake pads/block if below minimum limit replaces.								Ensure			
5.6	Check the safety sling in brake adjusting equipment. (WAP-7, WAG-9)								Ensure			
5.7	Check safety sling intactness on all brake hangers. (WAP-7, WAG-9).								Ensure			
5.8	Check the locking plate provided on brake hanger pins, (WAP-7, WAG-9)								Ensure			

SN	Items to Check	Std. Value	Remarks
5.9	Check the length of brake shoe holder magazine. (WAP-7, WAG-9)	Ensure	
6	Check the play in Brake hangers on all wheels, (WAP-7, WAG-9)	No Play	
6.1	Check the adjusting Equipment is properly intact. (WAP-7, WAG-9)	Intact	
6.2	Check brake hanger for crack and rubbing. (WAP-7, WAG-9)	No Crack	
6.3	Visually Examine the Draft gears / CBC couplers for any damages / abnormalities.	Ensure	
6.4	Check for correct closing and opening of CBC's	Ensure	
6.5	Liberal apply the grease to the face of CBC's	Applied	
6.6	Check the operation of screw couplings.	Ensure	
6.7	Visually Check loco side buffer for any crack and intactness of bolts.	Intact	
6.8	Check the condition of cattle guard and Rail guards for any damages / cracks and check the Intactness of their fasteners.	No Crack	
7.	SPERIBLOCK:		
7.1	Check the condition of spheriblock in axle guide link.	Normal	
7.2	Check the condition of spheriblock of traction motor	Normal	
7.3	Check the condition of spheriblock of Gear case.	Normal	
8.	AUX, COMPRESSOR (CPA):		
8.1	Check oil level top up if required.	Ensure	
8.2	Check tightness of all nut bolt and foundation bolt.	Intact	
9.	MAIN COMPRESSOR:		
9.1	Check for any abnormal sound during Running of CP.	Ensure	
9.2	Check the intactness of base bolts, rubber blocks and support bracket	Intact	
9.3	Check safety sling of both compressor	Ensure	
9.4	Check for oil leakage and also check the oil level, Top up if required.	Top Up	
9.5	Check the delivery pipe line for air leakage.	Ensure	
9.6	Check the working of air dryer. Inspect air dryer for any damage.	Working	
9.7	Visually check the MR Tanks/Drain cocks for any damages/ abnormality.	No Damage	
10.	AUXILIARY SYSTEM:		
10.1	Check the condition of duct and flexible hose of the blowers.	Normal	
11	BODY AND FRONT CABS:		
11.1	Check and clean the front lookout glasses.	Cleaned	
11.2	Check footsteps and their foundation for any damages / cracks.	No Crack	
11.3	Check the condition and operation of doors and window.	OK	
12.	HOSE PIPE:		
12.1	Check the BP/FP pipes for any hit marks / cracks	No Crack	
12.2	Replace the BP/FP rubber pipes if CRO.	Replace	
12.3	Check the condition of operation of angle cocks.	Check	
12.4	Check the intactness of sand pipes.	Intact	
12.5	Fill up the sand boxes with dry sand at correct level.	Top Up	
13.	PROPULSION SYSTEM:		
13.1	Visually check radiator for any leakage or damage.	No leakage	
14.	BRAKE SYSTEM:		
14.1	Check for the correct operation of Brake cylinder actuator.	Ensure	
14.2	Check the TBU/PBU for air leakage.	No leakage	
14.3	Check the working of driver's direct air brake (SA9)	Ensure	
14.4	Check the working of automatic brake valve (A9)	Ensure	
14.5	Check the working of parking brake.	Ensure	
14.6	Check for air leakage in pneumatic brake system.	No leakage	

SN	Items to Check	Std. Value	Remarks
15.	ROOF INSPECTION:		
15.1	Visually check the Pantos and Panto pans for any Abnormality / damages.	Normal	
15.2	Check the condition of flexible shunts of Pantos.	Normal	
15.3	Check the raising and lowering of both Pantos.	Ensure	
15.4	Check the roof for foreign material such as wire/cloth piece.	Clean	
15.5	Check the Intactness for roof bars.	Intact	
15.6	Check the Intactness and damage of surge arrestor.	Intact	
15.7	Examine the insulator (Panto foot insulator, eyelet rod insulator, roof line insulator, VCB insulator) for any crack, flashing, chipping and damage.	Normal	
15.8	Clean the insulators with soft, clean and dry cloth.	Clean	
15.9	Working of wipers (both cabs) Check the water level in tank.	WKG	
16	Working of sanders (both cabs).	WKG	
16.1	Working of Horn	WKG	
16.2	Ensure horn back plate tightness	35 NM	
17	GENERAL :		
17.1	Check correctness or reading of BP, FP, MR, BC and AFI gauge.	Ensure	
17.2	Working of PVEF	WKG	
17.3	Ensure availability of fire extinguisher, wooden wedge, spare BP/FP Pipe U Clamp and screw coupling.	Ensure	