

[kone oshibki rasshifrovka kodov neispravnostej](#) id: 6720401498

Prom Electric - ремонт промышленной электроники

г. Санкт-Петербург

+7 (812) 952-38-45

+7 (921) 952-38-45

mail@prom-electric.ru

<https://prom-electric.ru>

При работе промышленной электроники Kone в грузоподъемных механизмах, лифтах, системах вентиляции, теплоснабжения или автоматизированном производственном оборудовании часто возникают неисправности, распознать которые можно считав коды ошибок и произведя расшифровку этих кодов по инструкции на конкретную модель электронного оборудования.

Частотные преобразователи Kone V3F16L, KDL16L, KDL16R, V3F16ES, V3F16R, KDL16S, V3F10, V3F18, V3F20, V3F25, V3F80 имеют следующие распространенные ошибки:

Наиболее частые ошибки Kone(error list):

Ошибка 0001 (error 0001) - driver long time after a period of the position signal 30/B30 running time does not change;

Ошибка 0004 (error 0004) - three consecutive synchronous operation failed. Three consecutive synchronous operation of the system are not receiving proper leveling signal slowdown after three failed to stop at the

end of the station;

Ошибка 0007 (error 0007) - Area 308,030 switch stuck after the start time is not detected falling edge 30/B30 signal. Door zone has been effective operation of the switch to the destination 30/B30;

Ошибка 0008 (error 0008) - NVRAM damaged or capacity is not enough when the power transmission capacity is not enough to detect NVRAM;

Ошибка 0014 (error 0014) - Area check the circuit did not release any of two consecutive .486.443.1.443:2 without (ACO / ACL) run to the destination floor;

Ошибка 0015 (error 0015) - Area check circuit does not pull any one .486.443.1.443:2 consecutive times without (ACO / ACL) run to the destination floor;

Ошибка 0021 (error 0021) - safety circuit fails. Safety circuit input a no voltage is immediately stopped. Safety circuit switched;

Ошибка 0022 (error 0022) - Hall door barrier. 3 no-voltage input safety circuit stop immediately. Hall door turns;

Ошибка 0023 (error 0023) - door lock will not work. Safety circuit voltage input 2 no stop immediately;

Ошибка 0025 (error 0025) - start of system failure when the elevator did not stop the main contactor release does not start;

Ошибка 0026 (error 0026) - drive system failure. Driven system detects a fault (v3FCK not light) does not start;

**Узнайте условия проведения диагностики и
ремонта частотных преобразователей Kone
V3F16L, KDL16L, KDL16R, V3F16ES, V3F16R,
KDL16S, V3F10, V3F18, V3F20, V3F25, V3F80,
отправив запрос на mail@prom-electric.ru**