

Net F/T Force/Torque Sensor

Welcome	System Status: Healthy
Snapshot	
Demo	
Settings	Communications
Thresholding	These settings control how the Net F/T communicates with external equipment. Most settings require the Net F/T to be powered off and then back on before they take effect.
Configurations	To save the values, you must click <i>Apply</i> .
Communications	Ethernet Network Settings
System Info	DIP switch 9 must be <i>off</i> to enable IP Address Mode. If DIP switch 9 is <i>on</i> , then the IP address is set to 192.168.1.1 regardless of the <i>IP Address Mode</i> settings below. A LAN connection must be present at power up for DHCP to function. If DHCP is enabled and no DHCP server is found, then the static IP address will be used.
ATI Web Site	

IP Address Mode: ☒ DHCP ☐ Static IP see above note regarding DIP switch 9

Static IP Address:

Static IP Subnet Mask:

Static IP Default Gateway:

EtherNet/IP Protocol: ☐ Enabled ☒ Disabled

Ethernet/IP O2T Data: ☐ Enabled ☒ Disabled

Ethernet/IP Data Format: ☒ 32-bit Signed Data ☐ 16-bit Unsigned Data

Ethernet MAC Address:

Fieldbus Module Settings

The fieldbus module is not supported in this product.

Fieldbus Module Firmware:

Fieldbus Module Enabled: ☐ Enabled ☒ Disabled

CAN Network Settings

If power is not provided to the Pwr/CAN connector, then *CAN Bus Base Address*, *DeviceNet MAC ID*, and *Baud Rate* are not correctly reported and communications over the Pwr/CAN connector are not available.

Protocol: ☒ CAN Bus ☐ DeviceNet

CAN Bus Base Address: set by DIP switches 1 to 6

DeviceNet MAC ID: set by DIP switches 1 to 6 (inaccurate without DeviceNet connection)

Baud Rate: kHz set by DIP switches 7 and 8

Raw Data Transfer (RDT) Settings

RDT data is routed through the local network and does not get routed through the default gateway.

RDT Interface: ☒ Enabled ☐ Disabled demo application requires RDT to be enabled

RDT Output Rate (1 to 7000): Hz value may be rounded up; see manual for details

RDT Buffer Size (1 to 40):

Multi-Unit Synchronization: ☐ Enabled ☒ Disabled

Multi-Unit Id (1 to 9):

Modbus TCP Settings

Modbus Server ☐ Enabled ☒ Disabled

Modbus Client ☐ Enabled ☒ Disabled

Modbus Client's Tx Interval (ms)

Modbus Client's Server IP Address:

Modbus Client's Server Write Register:

Modbus Client's Server Read Register

Apply

Cancel

ATI Industrial Automation
1031 Goodworth Dr. | Apex, NC 27539 USA
Phone: +1 919-772-0115 | Fax: +1 919-772-8259
info@ati-ia.com | <http://www.ati-ia.com/>

Firmware Version 2.2.56 | System Runtime 0000:01:08:11