#### Mercedes-Benz Maintenance System — Passenger Cars

### **REGULAR MAINTENANCE INSPECTION** — Every **15,000** Miles



service

All 1983 Models (With additional work at 30,000 miles)

Customer:	Work Order No.:
Address:	License No.:
City & State:	Mileage:
Zip Code or Province:	Time Promised:
Maintenance Work to be Performed:	Special Maintenance Work Performed at
☐ MB Maintenance Service with oil change and oil filter service.	Extra Cost:  Sliding Roof: Clean guide channels and lubricate
Oil: Brand-Viscosity	lightly. ☐ Lighting System: Check headlights and aim.
Additional Maintenance Work to be Performed Every 30,000 Miles:   Radiator Coolant:	☐ Battery: Clean housing and terminals; grease terminals lightly. ☐ Car wash.
☐ Radiator Coolant:°F FILL/DRAIN/CHECK. Add rust inhibitor.	☐ ☐ Wax and Polish.
☐ Drain and renew brake fluid. (once a year, preferabl in Spring). Use only specified brake fluid.	
	☐ Once a year renew brake fluid.
M-B Individual Maintenance Jobs Performed as Needed:  Section I. Lubrication Service	Special Instructions from Customer:
Engine oil change with oil filter service.	
Oil: Brand-Viscosity	
☐ Section III: Safety Inspection.	
Visual Inspection: Check For Leakage and Gene ☐ Engine ☐ Rear Axle ☐ Steering ☐ Brakes ☐ Transmission ☐ Shock Absorbers	ral Condition.
Result:	
Cookionalista di	
	Service with Oil Filter Change
	The Transport of the Control of the
300 CD Turbo	- The second sec
	- TS-000000
O D S S S S S S S S S S S S S S S S S S	
22	Control of
Oil Change □ □ □ □ 0101 Engine oil and filter change	(continued)

## **Section I: Lubrication Service with Oil Filter Change** (continued)

240 D 300 D - 300 CD Turbo 300 SD - 300 TD Turbo 380 SEL 380 SL - 380 SEC	Inspection for Leaks and Condition Check for chafing and proper routing of lines	240 D 300 D - 300 CD Turbo 300 SD - 300 TD Turbo 380 SEL 380 SL - 380 SEC	Check and Correct Fluid Level Check for leakage
	<ul> <li>O050 All units: engine, transmission, rear axle, steering gear, power steering pump, shock absorbers</li> <li>O051 Lines and Hoses on: engine, automatic transmission, power steering</li> <li>Cooling and heating system</li> <li>Clutch actuating system</li> <li>Level control system (300 TD only)</li> <li>Fuel system</li> </ul>		2610 Standard transmission 2710 Automatic transmission 3510 Rear axle 4611 Power steering 8210 Windshield washer system 2910 Clutch actuating system 8312 Air conditioning/climate control system 3211 Level control system (300 TD only) 4210 Brake system 5410 Battery 2010 Engine cooling system (check antifreeze)
			Lubrication Service 7220 Door hinges 7221 Door locks 8820 Outside rear view mirror 8821 Engine hood 3022 Engine throttle linkage and control shaft

### **Section II Engine Maintenance**

240 D 300 D - 300 CD Turbo	SD - 30	380 SEL	380 SL - 380 SEC		
				0932	Air filter element, clean*
				0560	Valve clearance, adjust
				1350	V-belts, check condition, retighten*
				3050	Engine control linkage, check for wear and ease of movement
				1580	Spark plugs, replace, Federal version only
				1550	Spark plugs, check, replace if necessary*

\*California version: Recommended maintenance as defined by California Air Resources Board regulations. Mercedes-Benz urges that the maintenance be performed.

Section	Ш	Safety	Ins	pection
---------	---	--------	-----	---------

urbo Turbo		Company of the Compan	CONTRACTOR OF THE STATE OF THE	_	9					
<u> </u>				2	은					-
Turbo D Turbo EC				Turbo	Terb Terb					
						SEC				
19 19 SE(		. The West Asset Comments			1	22				
300 C										
300 380		The state of the s		0	300	380				
300 CD 300 TI 380 SE		* ****		300	က	က				
						! '.				
2 S S 3				0	S	S		and the same of th		
		and the contraction of the contr	11.00					*****		
240 300 330 380 380				240 300	300	8	Retighte	en nuts and	bolts—Adi	nere to
~~~~				2 8	m m	(1)	tighteni	ng torque sp	pecification	ıs!
	4650		dition				4671 Ste	ering gear mo	unting	
		of linkage, check								
	4050	Wheels, remove and reinstall, check ri	me				Check 1	or Proper F	unction	
	4000	for condition, check inside of wheels f	07			П	5451 Dir	ootion clanele	instrument o	nd control
		dirt accumulation	OI			لسان	J451 Dill	ection signals,	motiument a	na control
		dirt accumulation					ligh	แร		
	4051	Tire tread wear and other damage, che	eck.				8251 Hea	ad lamps, exte	rior lamps	
Rotate wheels if required										
		•			$\sqcup$ $\sqcup$		8252 Wir	ndshield wiper	s, windshield	washer
	4060	Correct tire pressure								
	4252	Disc brakes, check and clean.			_					
	7252	Remove brake pads for this purpose			₩ 7	Γire t	read dept	h and brake	performance	3
					•		·			
	4250	Brake lines, check for damage						<del>T</del>		
	4261	Parking brake, adjust		) F	Front	-Le	eft	Fron	t-Right	
	4201	raining brake, aujust		1				1		
	3353	Front axle: Check ball joints for		1				ł		
		condition and rubber boots for leaks		1 1	N.	ı	KP	IN.	KP	
				٠ ا	14.	ı	IXI	114.	181	
	4290	Brake test on test stand/road test.								
		Break in parking brake as specified			Rear-	10	F+	Don.	r-Right	
		· · · · · · · · · · · · · · · · · · ·		·	ical.	LLE	11	nea	nigiit	
	9150	Check seat belts for damage								
				1 1	N.		KP	IN.	KP	
				<u>'</u>				I	·····	

	Additional Main Every 30,000 Miles	tenance W	ork	en e	
240 D 300 D - 300 CD Turbo 300 SD - 300 TD Turbo 380 SEL 380 SL - 380 SEC		300 CD - 300 T - 380 S			
Oil and Filter Chang	е		Engine		
	ssion, fluid and filter		0750 Idle spe	ed, check and readjust if neces	ssary
change 0753 Fuel prefilter, chec	k			ed adjusting knob, check and tif necessary	
☐ ☐ ☐ 0780 Fuel main filter, re	place element		1350 V-belts,	check condition and retighten	
O980 Air filter element, r	<u> </u>	000	0760 Check s	start of delivery, only once after niles	
O981 Air filter elements, pump	replace, engine and air			sensor, replace, once after 30,	000
		ПП	1580 Spark p	lugs, replace	

(continued)

# Additional Maintenance Work Every 30,000 Miles

240 D 300 D - 300 CD Turbo 300 SD - 300 TD Turbo 380 SEL 380 SL - 380 SEC	Chassis
	4256 Parking brake, check cables for free
	operation 4152 Drive shaft, check flex discs for wear
	2551 Clutch, check lining thickness
	Once a Year
	4280 Renew brake fluid (preferably in spring)
	6030 Clean water channels. Perform in spring, if possible
	7730 Sliding roof: Clean and lightly grease rails and sliding blocks. Perform in spring, if possible
	Every Three Years
	2080 Renew coolant with antifreeze
00	Additional Maintenance Work every 60,000 Miles 0780 Fuel filter, replace

Date	Service Manager (Signature)