Station: ebV2 UPD-board number: _____

Date: 21-Aug-2025 *stationd* UDP port: _____

Configuration types

Letter	Use
A	Bank A
B	Bank B
C	Bank C
P	Powered on boot (i.e. Output is asserted without control on boot)
H	High side and high current switch
HL	High side / Low side (push pull) switch
L	Low side (pull down) switch
S	Soft-start switch
n	Non voltage configurable pin
x	Pin modified from default board build

NB: Pin setup for *stationd* found in ~/uniclogs-stationd/config.ini

radio (IPV4): _____

station (IPV4): _____

jump host (IPV4): _____

UniClOGS gateway (IPV4): _____

NB: Use *./find_hosts.sh*

Pin usage

Pin	Config	Command	Code	Power up	Setup
A0	P5Hn			on	
A1	5Hn	sdr-b200 power off/on		off	off
A2	12Hn			off	
A3	12Hn	uhf pa-power on/off		off	off
A4	12Hx	l-band pa-power on/off		off	off
A5	12Hx	rotator power on/off		off	on
A6	12Hx			off	
A7	5H	radio-host power off/on		off	on

Pin usage

Pin	Config	Command	Code	Power up	Setup
B0	PL			on	
B1	L			off	
B2	L	uhf rf-ptt off/on		off	off
B3	L	l-band rf-ptt off/on		off	off
B4	HL			off	
B5	HL	lu tx-relay power on/off		off	off
B6	HL			off	
B7	HL	Uhf tr-relay on/off		off	off

Pin usage

Pin	Config	Command	Code	Power up	Setup
C0	PHL			on	
C1	HL			off	
C2	HL			off	
C3	HL			off	
C4	HL			off	
C5	HL			right	
C6	HL	uhf lna on/off [ext device 1]		off	off
C7	HL	uhf polarization right/left [ext device 2]		right	right

Created: 3-Dec-2023 Created from UPD SOP Document

Modified: 13-Jul-2024 Updated for current station layout

Modified: 21-Aug-2025 Updated for actual ebv2; First build

Modified: 23-Aug-2023 Corrected B5 designation and typos