

Ship repair / rework to:

Sender / Return address:

Reishauer AG

Industriestrasse 40

CH-8304 Wallisellen

Address:.....

.....

.....

.....

.....

Contact name:.....

.....

Reishauer description

Item number:

Serial number:

Customer description

Tool number:

Gear description/name:

Machine parameters

Clamping pressure:bar

clamping force of tail stock:.....N

rpm of C-Axis:min⁻¹

Tool life

Number of clamping cycles:

Documentation and description of objection

Diagram of last workpiece: ☐ as attachment

Objection:

- ☐ workpiece can not be loaded
- ☐ workpiece does not clamp
- ☐ concentric runout not o.k.
- ☐ axial runout not o.k.

- ☐ Expansion is too low
- ☐ clamping bush is worn
- ☐ clamping bush is scratched
- ☐ clamping device is leaking

- ☐ base is worn
- ☐ collision
- ☐ see remark

Remark:

.....

.....

.....

Gear specifications:

Drawing and gear specifications for workpiece: ☐ as attachment / ☐ no attachment

Attention !
**To control the clamping device the control ring is necessary
Please provide the corresponding control ring for each clamping device**

attachements:

Problem	Possible Cause	Action	Responsibility
radial or axial runout out of tolerance [Measurements performed using runout master and a micron dial indicator]	Contamination on locating surfaces	1. Disassemble arbor and base from machine 2. Clean all mounting surfaces 3. Reassemble base and arbor 4. Verify runout [measure with micron dial indicator and master]	Trained Staff
	Damage to locating / mounting surfaces	1. Disassemble arbor and base from machine 2. Inspect and clean all mounting surfaces 3. If damaged return to Reishauer for repair otherwise continue with step 4 4. Reassemble base and arbor 5. Verify runout [measure with micron dial indicator and master]	Trained Staff (Inspection) Reishauer corporation (Repair)
	Arbor does not seat properly due to machine actuating piston not being fully retracted	1. Disassemble arbor from base 2. Retract actuating piston with resetting device -> see operating manual from machine 3. Reassemble base and arbor 4. Verify runout [measure with micron dial indicator and master]	Trained Staff
	Arbor may not have been correctly installed Ex: Bolts not properly torqued	1. Disassemble arbor from base 2. Inspect and clean all mounting surfaces 3. Reassemble base and arbor -> see operating manual from machine 4. Verify runout [measure with micron dial indicator and master]	Trained Staff
Clamping fixture does not clamp part or part slips while clamped [Clamping ability is verified using a torque master] [Arbor diameter / expansion measured using a micrometer]	clamping bush worn	1. Measure the unexpanded clamping bushing diameter and compare to specification [with a micrometer] 2. If less than specification send back to Reishauer for repair	Trained Staff (Inspection) Reishauer corporation (Repair)
	Clamping bushing does not expand enough due to loss of oil	1. Verify the clamping pressure is correct, if not adjust and recheck expansion [measured with a micrometer] 2. Check clamping stroke control as less than 2 mm of piston stroke will activate 3-Point Check Fault (if equipped) 3. Check piston length on bottom of arbor as it should be exposed a minimum of 5 mm 4. Send back to Reishauer for repair	Trained Staff (Inspection) Reishauer corporation (Repair)
	Clamping fixture does not expand enough due to internal mechanical failure	1. Verify that the clamping pressure is correct, if not, adjust and recheck expansion [measured with a micrometer] 2. If not to specification, send back to Reishauer for repair	Trained Staff (Inspection) Reishauer corporation (Repair)
	Clamping bushing sleeve seal is defective due to over expansion	1. Send back to Reishauer for repair	Trained Staff (Inspection) Reishauer corporation (Repair)
3-Point-Check does not properly function	Part incorrectly positioned	1. Verify loader is properly positioning the part, if not reattach the loader	Trained Staff
	Excessive air exhaust through clamping fixture caused by air bubble from the arbor or base	Verify the 3-Point-Check system has a 10 to 12 unit difference with a part on and off, if it is less than 10 units then send it back for repair	Trained Staff (Inspection) Reishauer corporation (Repair)