

編號	宣告類別	符號	位址	型態	初始值	符號註解
1	VAR	Conveyor Speed WR	D108	WORD	N/A	
2	VAR	HMItoPLC EMC	D1004.0	BOOL	N/A	
3	VAR	HMI Robot ActionNo	D1010	INT	N/A	HMI Robot動作編號
4	VAR	HMI Robot NoodleCabinetNo	D1011	INT	N/A	HMI麵櫃編號
5	VAR	HMI Robot CutNo	D1012	INT	N/A	HMI麵切編號
6	VAR	HMI Robot OutputCabinetNo	D1013	INT	N/A	HMI出麵櫃編號
7	VAR	HMItoPLC StepMask	D1014	INT	N/A	HMI 半自動選取 Step Bit Mask
8	VAR	PLCtoHMI EMC	D1108.0	BOOL	N/A	
9	VAR	Machine Mode	D1109	WORD	N/A	0=Manual、1=Semi、10=Single bowl automatic、2
10	VAR	SemiAuto Running	D1110.5	BOOL	N/A	半自動流程執行中
11	VAR	PLCtoHMI RobotManualStatus	D1120	INT	N/A	Robot單動狀態
12	VAR	PLCtoHMI RobotManualAckId	D1121	WORD	N/A	Robot單動命令回覆序號
13	VAR	PLCtoHMI RobotManualResult	D1122	INT	N/A	Robot單動結果碼
14	VAR	PLCtoHMI RobotManualAlarm	D1123	INT	N/A	Robot單動異常代碼
15	VAR	PLCtoHMI Robot Idle	D1124.0	BOOL	N/A	
16	VAR	PLCtoIPC RequestValid	D1203	WORD	N/A	PLC 任務有效旗標
17	VAR	IPC CommStatus	D1209.0	BOOL	N/A	IPC 通訊狀態：0=Offline、1=Online
18	VAR	IPCtoPLC Busy	D1302	WORD	N/A	IPC 執行中
19	VAR	Robot Manual ActionNo	D3080	INT	N/A	送給Robot的動作編號
20	VAR	Robot Manual NoodleCabinet	D3081	INT	N/A	送給Robot的麵櫃編號
21	VAR	Robot Manual CutNo	D3082	INT	N/A	送給Robot的麵切編號
22	VAR	Robot Manual OutputCabinet	D3083	INT	N/A	送給Robot的出麵櫃編號
23	VAR	Robot Manual NoodleTypeNo	D3084	INT	N/A	送給Robot的麵種編號，固定為1
24	VAR	Robot Manual Step	D3090	INT	N/A	Robot單動流程步驟
25	VAR	Robot Manual ParameterOK	D3091.0	BOOL	N/A	Robot單動參數檢查結果
26	VAR	Robot Exchange Finish	D3091.1	BOOL	N/A	Robot交換流程完成
27	VAR	Robot Manual StartReq	D3091.2	BOOL	N/A	Robot單動啟動要求
28	VAR	Robot Manual Permit	D3091.3	BOOL	N/A	Robot手動操作允許
29	VAR	Robot Exchange AlarmCode	D3092	INT	N/A	Robot交換FB異常代碼
30	VAR	Robot Manual CommandIndex	D3093	WORD	N/A	Robot單動命令序號
31	VAR	IPC FirstMaterialPending	N/A [Auto]	BOOL	N/A	
32	VAR	Bowl Dispenser Cmd Run	N/A [Auto]	BOOL	N/A	
33	VAR	IPC CommandTrigger	N/A [Auto]	BOOL	N/A	發送任務觸發訊號
34	VAR	IPC PreCaptureThenFirst	N/A [Auto]	BOOL	N/A	
35	VAR	IPC CommandRecipeNo	N/A [Auto]	WORD	N/A	準備發送的配方
36	VAR	ALM Rst	N/A [Auto]	BOOL	N/A	
37	VAR	Bowl Dispenser Busy	N/A [Auto]	BOOL	N/A	
38	VAR	Bowl Dispenser Cmd HMItoP	N/A [Auto]	BOOL	N/A	
39	VAR	Conveyor Initialize	N/A [Auto]	BOOL	N/A	
40	VAR	Conveyor Initialize Done	N/A [Auto]	BOOL	N/A	
41	VAR	NoodleBasket 1	N/A [Auto]	DUT NoodleBasket	N/A	
42	VAR	Initialize Done	N/A [Auto]	BOOL	N/A	
43	VAR	Err HMI CommTimeout	N/A [Auto]	BOOL	N/A	
44	VAR	IPC CommandError	N/A [Auto]	BOOL	N/A	IPC 任務失敗
45	VAR	IPC CommandCode	N/A [Auto]	WORD	N/A	準備發送的任務代碼
46	VAR	IPC CommandDone	N/A [Auto]	BOOL	N/A	IPC 任務完成脈波
47	VAR	NashiRobot Down0	N/A [Auto]	NashiRobot Down	N/A	
48	VAR	NashiRobot Initial 0	N/A [Auto]	NashiRobot Initial	N/A	
49	VAR	IPC CommandErrorCode	N/A [Auto]	WORD	N/A	命令失敗代碼
50	VAR	HMI CMD AckIndex BUF	N/A [Auto]	WORD	N/A	PLC Internal HMI 命令 AckIndex 暫存，給 PRG
51	VAR	HMI CMD ResponseCode BUF	N/A [Auto]	INT	N/A	PLC Internal HMI 命令 ResponseCode 暫存，給
52	VAR	Bowl Dispenser Cmd	N/A [Auto]	BOOL	N/A	
53	VAR	Robot Initialize Done	N/A [Auto]	BOOL	N/A	
54	VAR	SemiAuto StartReq	N/A [Auto]	BOOL	N/A	半自動啟動脈波
55	VAR	RobotZoneOwner	N/A [Auto]	INT	N/A	0：沒有人占用共用工作區 1：生麵送入鍋動作占用 2：煮好麵倒入碗動作占用 3：UR1占用 4：UR2占用
56	VAR	Noodlebasket3 Down	N/A [Auto]	BOOL	N/A	
57	VAR	SemiAuto StepMask	N/A [Auto]	WORD	N/A	本次要執行的 Step Mask
58	VAR	Noodlebasket1 Up	N/A [Auto]	BOOL	N/A	
59	VAR	Noodlebasket2 Up	N/A [Auto]	BOOL	N/A	
60	VAR	Noodlebasket2 Down	N/A [Auto]	BOOL	N/A	
61	VAR	NoodleBasket 3	N/A [Auto]	DUT NoodleBasket	N/A	
62	VAR	Noodlebasket1 Down	N/A [Auto]	BOOL	N/A	
63	VAR	Noodlebasket3 Up	N/A [Auto]	BOOL	N/A	
64	VAR	Err Active	N/A [Auto]	BOOL	N/A	
65	VAR	EMC	N/A [Auto]	BOOL	N/A	
66	VAR	ALM Active	N/A [Auto]	BOOL	N/A	
67	VAR	Conveyor Run	N/A [Auto]	BOOL	N/A	
68	VAR	EMC Active	N/A [Auto]	BOOL	N/A	
69	VAR	NoodleBasket 2	N/A [Auto]	DUT NoodleBasket	N/A	
70	VAR	UnitFIFO	N/A [Auto]	DUT UnitFIFO	N/A	
71	VAR	CookTime Soft Set	N/A [Auto]	INT	N/A	
72	VAR	CookTime Hard Set	N/A [Auto]	INT	N/A	
73	VAR	CookTime Normal Set	N/A [Auto]	INT	N/A	
74	VAR	Robot Idle	T0	TIMER	N/A	
75	VAR	ALM Conveyor Initialize Tim	T1	TIMER	N/A	
76	VAR	ALM Conveyor Comm Time	T3	TIMER	N/A	
77	VAR	Auto BowlArrivedSensor	N/A [Auto]	BOOL	N/A	X0.1與模擬輸入合併
78	VAR	Auto Station20Sensor	N/A [Auto]	BOOL	N/A	X0.2與模擬輸入合併
79	VAR	Auto Station30Sensor	N/A [Auto]	BOOL	N/A	X0.3與模擬輸入合併
80	VAR	Auto Station40Sensor	N/A [Auto]	BOOL	N/A	最右端注湯及出料站碗到位感測器
81	VAR	Auto BowlDropZoneFree	N/A [Auto]	BOOL	N/A	落碗至X0.2入口路段可以接受新碗
82	VAR	Auto BowlDropRequest	N/A [Auto]	BOOL	N/A	全自動流程要求執行落碗
83	VAR	Auto BowlDropGrant	N/A [Auto]	BOOL	N/A	仲裁後允許執行落碗
84	VAR	Auto BowlDropStartPulse	N/A [Auto]	BOOL	N/A	啟動既有落碗程式的單Scan脈波
85	VAR	Soup SingleCmd	N/A [Auto]	BOOL	N/A	單次注湯啟動命令
86	VAR	Soup DonePulse	N/A [Auto]	BOOL	N/A	注湯完成脈波，只保持一個Scan
87	VAR	PLCtoHMI OrderCompleteUnit	D1135	DINT	N/A	最後完成的碗編號，使用D1135至D1136
88	VAR	PLCtoHMI OrderCompleteInd	D1137	DWORD	N/A	訂單完成流水號