



Date Prepared: July 2024

(Name)

EQUUS SOPREMA COLPHENE BSW

Below-ground single layer waterproofing

Specification No: 4131EB

Date: ____/ /

Projec	t & Address:	Fisher & Paykel —Home & Shed Buildings							
		830 Great South Road, Penrose, Auckland							
Certified Applicator:		Alliance Waterproofing							
Building Contractor:		Naylor Love							
Building Owner/Property Manager:									
1. Statement of Intent									
(b) A (a) A	This checklist is to be completed by both the Equus Applicator and the Building Contractor, as a step by step record of compliance with both the Equus Specification provided for the contract, and the requirements of the Manufacturer for Warranty. A copy of this checklist must be forwarded to the nearest Regional Office of Equus Industries Ltd. A Warranty will not be issued by Equus Industries Ltd. without a copy of this Checklist being filed. A copy of this checklist should form part of the Contract Documentation filed with the Property Manager on job completion.								
2. Area	s Treated								
The areas to which Membrane is applied are detailed below, with reference to plans (where appropriate).									
Areas of below ground tanking—detail reference 4131EB 4.2 / 4.3 / 4.4 and Aquafin 2-KM									
3. Sign Off									
We confirm that all applicable processes listed in Section 4 have been correctly completed and that sign-off on each stage has been made by a person with the authority to do so.									
For:			(Signature)						
(Building Contractor)								
Date: _	1 1		(Name)						
For: _	Equus Applicator)		(Signature)						



AQUAFIN 2-K/M—Checklist And Method Statement

* Denotes those processes which must be signed off by the Building Contractor as well.

No.	Process	Completed On	Building Contractor	Equus Contractor	Notes
1.*	Ensure all concrete surfaces are cleaned sufficiently for application of Equus Chevacryl Admix primer.				
2.	Apply Equus Chevacryl Admix 50/50 primer to concrete substrate.				
3.	Apply Equus Epistixx AC primer to all ferrous substrate. Allow to cure.				
4.	Apply first coat of Aquafin 2-K/M Plus by brush or trowel at approx. 2kgs per m ² .				
6.	Apply an Equus Schomburg Aquafin 2-K/M Plus reinforcement bandage to nominated areas—penetrations, concrete to termination bar				
8.	Apply second coat of Aquafin 2-K/M Plus by brush at approx. 2kgs per m ² .				
9.	Check for pinholes and touch up as necessary by means of brush.				
10.	System to be inspected on completion.				