

1. Inspection report internal crane

Contents:

1 fundamental data onboard crane

2 checklist

3 notes

Site:	
WTG number:	
WTG type:	

1 Fundamental data internal crane

Manufacturer onboard crane	
Type	
Year build	
Serial number	
Type plate and test badge	

Summary

Inspectors	
Date	
Result of inspection	
Repair required	
Next inspection	



Site ,date

Technician,responsible

Stamp,signature

2 Checklist

Generell	nk	ok	refer notes,N°
Reading of the operating hours			

Electrical equipment	nk	ok	refer notes,N°
Interrupt the voltage supply to the crane by removing the CEE plug from the top box in the powerhouse.			
Check that the circuit diagram is in position in the switch cabinet and is still legible			
Check that the warning signs on the switch cabinet, motor terminal box and power supply rails are in position and still legible			
Check all cables for signs of outer damage and firm attachment to the terminals			
Check all the screwed cable glands for signs of outer damage and a firm fit			
Open the switch cabinet cover and check the firm fit of the cables. Check whether the inside of the switch cabinet is free of dirt and/or humidity. Check that the snap-hook for hanging up the operating unit is in position and working.			
Check the operating unit for outer damage, a firm cable fit and make sure strain relief is working.			
Check the limit switches for signs of outer damage, a firm cable fit and ease of movement of the switching rockers			
Set up the voltage supply again. Check whether movement of the load crane corresponds to the symbols on the operating unit.			
Check that the motor brake is working. When the operating unit is actuated, the brake switches with an audible "click"			

Machine technology	nk	ok	refer notes,N°
Check the rope for mechanical damage such as breaks, pinching, bends or unwound strands by winding it off the drum completely and on again. Check the firm fit of the screws on the rope clamps on the drum. Grease the rope with a suitable rope grease with corrosion protection additives.			
Check the load hook for mechanical damage and check • the opening width of the hook opening • the perfect fit of the connection to the rope (rope eye stiffener and crimp sleeve) • the existence of rope weight and pressure spring • the existence and perfect condition of the tubular			
Carry out a visual inspection of the drive unit for damage and leaks. Listen for unusual noises during operation. Motor and gear are maintenance-free and do not require any lubrication.			
Use a feeler gauge to check the brake gap, it has to be 0.3 - 0.8 mm.			
Check the limit switch rockers to make sure they are present and move easily.			

Check that the crane bridge is safely locked in place and that the locking lever is a firm fit			
Check that the crab is safely locked in place and that the locking lever is a firm fit			
Check the deflection rollers and the respective components (rig pin, washer and spring cotter) to make sure they are in position and have no mechanical damage			
Check all the screw joints to make sure they are in position and a firm fit			
Check all the rollers on the bridge and on the crab for mechanical damage and to make sure they move easily by pushing the bridge and the crab by hand.			
Check all the stop buffers to make sure they are in position and have no mechanical damage.			
Check all the components to make sure the coating (paint, galvanizing) is in good condition. Suitable materials must be used to remedy damage to the corrosion protection. Bright steel parts e.g. roller bearings must be protected by a suitable preservation wax			

Ancor point safety equipment			
Load test			

3 Notes:



2. Photo Documentation

Insert Images



General Service S.L.
<http://gs-climbing.com>

C/Calzada N°23
Edif. Panalmedina, Bajo
29770 Torrox/España/de Málaga

Contacts:
Portugal & Europa:
info@gs-climbing.com
00351 919411147
0049 1774826175





3. Additional Fields

General Service S.L.
<http://gs-climbing.com>

C/Calzada N°23
Edif. Panalmedina, Bajo
29770 Torrox/España/de Málaga

Contacts:
Portugal & Europa:
info@gs-climbing.com
00351 919411147
0049 1774826175

